


# Food and Agricultural Wastewater Utilization and Treatment

Sean X. Liu



Blackwell  
Publishing

# **Food and Agricultural Wastewater Utilization and Treatment**

# **Food and Agricultural Wastewater Utilization and Treatment**

**Sean X. Liu**

Department of Food Science  
Rutgers University



**Sean X. Liu, Ph.D.**, is Professor in the Department of Food Science and serves as the Director of the Bioresource Engineering Graduate Program at Rutgers University in New Jersey. He has a Bachelor's degree in chemical engineering from East China University of Science and Technology and Master's and Ph.D. degrees, also in chemical engineering, from Kansas State University. He is the author of more than 50 technical journal articles, book chapters, reports, and proceedings related to wastewater treatment and food processing.

© 2007 Blackwell Publishing  
All rights reserved

Blackwell Publishing Professional  
2121 State Avenue, Ames, Iowa 50014, USA

Orders: 1-800-862-6657  
Office: 1-515-292-0140  
Fax: 1-515-292-3348  
Web site: [www.blackwellprofessional.com](http://www.blackwellprofessional.com)

Blackwell Publishing Ltd  
9600 Garsington Road, Oxford OX4 2DQ, UK  
Tel.: +44 (0)1865 776868

Blackwell Publishing Asia  
550 Swanston Street, Carlton, Victoria 3053, Australia  
Tel.: +61 (0)3 8359 1011

Authorization to photocopy items for internal or personal use, or the internal or personal use of specific clients, is granted by Blackwell Publishing, provided that the base fee is paid directly to the Copyright Clearance Center, 222 Rosewood Drive, Danvers, MA 01923. For those organizations that have been granted a photocopy license by CCC, a separate system of payments has been arranged. The fee codes for users of the Transactional Reporting Service is ISBN-13: 978-0-8138-1423-0 /2007.

First edition, 2007

Library of Congress Cataloging-in-Publication Data

Liu, Sean X.

Food and agricultural wastewater utilization and treatment/Sean X. Liu.—1st ed.  
p. cm.

Includes bibliographical references and index.

ISBN 978-0-8138-1423-0 (alk. paper)

1. Agricultural wastes—Management. 2. Sewage—Purification. I. Title.

TD930.L578 2007

628'.746—dc22

2007012759

The last digit is the print number: 9 8 7 6 5 4 3 2 1

# CONTENTS

---

<i>Preface</i>	<i>ix</i>
<b>Chapter 1</b> Introduction	3
Characteristics of Agricultural and Food Wastewater	3
Material Balances and Stoichiometry	21
Fluid Flow Rate and Mass Loading	24
Kinetics and Reaction Rates	24
Theoretical Modeling and Design of Biological Reactors	28
Process Economics	31
<b>Chapter 2</b> Basic Microbiology in Wastewater Treatment	35
Introduction	35
Structures of Cells	36
Important Microorganisms in Wastewater	37
Microbial Metabolism	44
Nitrification	46
Denitrification	48
<b>Chapter 3</b> Physicochemical Wastewater Treatment Processes	51
Introduction	51
Equalization Basins	52
Screening	54
Flotation	57
Sedimentation	58
Coagulation and Flocculation	65
Filtration Processes	70
Adsorption	73
Chemical Oxidation	79
Membrane Separations	80
Ion Exchange	102
Chapter Remarks	110

<b>Chapter 4</b>	<b>Biological Wastewater Treatment Processes</b>	<b>113</b>
	Introduction	113
	Kinetics of Biochemical Systems in Wastewater Microbiology	115
	Idealized Biochemical Reactors	121
	Completely Mixed Aerated Lagoon (CMAL)	125
	Trickling Filter (TF)	127
	Rotating Biological Contactor (RBC)	131
	Combined Aerobic Processes	137
	Contact Anaerobic Systems	138
<b>Chapter 5</b>	<b>Advanced Wastewater Treatment Processes</b>	<b>145</b>
	Biological Removal of Nitrogen: Nitrification and Denitrification	147
	Physicochemical Removal of Nitrogen	149
	Biological Removal of Phosphorus	150
	Physicochemical Removal of Phosphate	153
	Membrane Processes for Advanced Wastewater Treatment	156
	VOC Removal with Pervaporation	160
	Disinfections	160
<b>Chapter 6</b>	<b>Natural Systems for Wastewater Treatment</b>	<b>167</b>
	Introduction	167
	Stabilization Ponds	169
	Land Treatment Systems	181
	Wetland Systems	198
	Floating Aquatic Plant Systems	204
<b>Chapter 7</b>	<b>Sludge Treatment and Management</b>	<b>215</b>
	Sludge Quality and Characteristics	216
	Sludge Thickening (Concentration)	217
	Sludge Stabilization	221
	Reed Beds	225
	Conditioning of Sludge	229
	Dewatering	231
	Land Applications and Surface Disposal	239
	Incineration	242

<b>Chapter 8</b>	Innovative Technologies for Value-Added Substance/Energy Recovery from Wastewaters	247
	Introduction	247
	Recoverable Carbohydrates, Fats, and Proteins for Human and Animal Consumption	249
	Recoverable Aroma Flavoring Compounds from Food Processing Wastewaters	252
	Recoverable Food/Agricultural By-Products for Nonfood Uses	252
	Energy or Fuel Generation from Wastewaters	254
	Potential Applications of Industrial Commodities Derived from Sludge Treatment	255
<b>Chapter 9</b>	Economics of Food and Agricultural Wastewater Treatment and Utilization	261
	Introduction	261
	Estimating the Unit Cost of Treating Food and Agricultural Wastewater	262
	Estimating Overall Costs of Wastewater Treatment Processes with Substance and Energy Recovery	268
<b>Index</b>		271

## PREFACE

---

This book was developed in response to the growing problem of food and agricultural wastewater management faced in both developing and developed countries as the world population continues to increase and, at the same time, industrialized food production has seen its most stunning growth in many nations—from Argentina, to Brazil, to China. Currently, it is recognized that the increasing amount of the wastewater from these industrial scale processing plants can no longer be totally resolved by discharging or applying to agriculture fields. Substantial amounts of food and agriculture wastewater have to be treated extensively to satisfy regulatory mandates and environmental laws.

Wastewater generated from agricultural and food operations has distinctive characteristics that set it apart from common municipal wastewater managed by public or private wastewater treatment plants throughout the world: It is biodegradable and nontoxic, but it has high concentrations of biochemical oxygen demand (BOD) and suspended solids (SS). The constituents of food and agriculture wastewater are often complex to predict due to the differences in BOD and pH in effluents from vegetable, fruit, and meat products and due to the seasonal nature of food processing and postharvesting. Increasingly, food and agricultural industries find themselves in need of coping with a growing and costly problem of wastewater treatment and disposal.

On the other hand, environmental management firms that are relegated to the task of managing food and agriculture wastewater realize that they need to do some retooling with respect to dealing with the problem at hand, because wastewater varies significantly with localities. Also, there is certain realization in the food and agricultural processing industries that wastewater from food and agriculture often contains some valuable commodities that are recoverable and can be harvested to offset the cost of overall wastewater management.



This book incorporates the most recent advances in agricultural and food wastewater treatment and valuable material recovery in the existing wastewater treatment technologies. This comprehensive volume will help food technologists and environmental and agricultural engineers/scientists in industries and governmental entities in their quest to improve food and agricultural wastewater management. This book can also be used as an upper-level undergraduate or first-year graduate textbook for food science, agricultural engineering, biological engineering, bioresource engineering, and environmental science or environmental engineering disciplines. Chemical engineering students will also find this book valuable in preparing their careers in food and other allied industries.

Chapters 1, 2, 3, and 4 cover the fundamental principles of conventional biological and physicochemical wastewater treatment. Chapter 5 introduces the reader to advanced wastewater treatment technologies relevant to agricultural and food wastewater issues. Chapter 6 describes several wastewater management practices using natural systems that include land applications. Even as land applications of agricultural and food wastewater have been restricted in many parts of the world, the practice still has an important role in overall agricultural and food wastewater management.

Sludge of wastewater treatment is often a problem of significant levels, and the techniques of effectively treating and stabilizing the sludge from wastewater treatment is documented in Chapter 7. Chapter 8 explains current technologies and methods in recovering valuable substances and energy from agricultural and food wastewater that can offset the overall cost of wastewater management. Chapter 9 looks into the overall economic picture of the combined treatment-and-recovery approach of agricultural and food wastewater treatment and provides several simple matrices of economical evaluations of overall agricultural and food wastewater management.

### ***Acknowledgments***

The author would like to thank his family for their warm support, patience, and understanding in this yearlong endeavor. The Department of Food Science and the graduate faculty of Bioresource Engineering at Rutgers University have provided the author with the necessary intellectual scaffolding that ultimately leads to this book. However, any error or omission found in the book is the sole responsibility of the author.

*Food and Agricultural Waste Water Utilization and Treatment*

Sean X. Liu

Copyright © 2007 by Blackwell Publishing

# **Food and Agricultural Wastewater Utilization and Treatment**

1

## INTRODUCTION

---

### **Characteristics of Agricultural and Food Wastewater**

Whenever and wherever food, in any form, is handled, processed, packed and stored, there will always be an unavoidable generation of wastewater. Wastewater is the most serious environmental problem in the manufacturing and processing of foods. Most of the volume of wastewater comes from cleaning operations at almost every stage of food processing and transportation operations. The quantity and general quality (i.e., pollutant strength, nature of constituents) of this processing wastewater generated have both economic and environmental consequences with respect to its treatability and disposal.

The cost for treating the wastewater depends on specific characteristics of it. Two significant characteristics that dictate the cost for treatment are the daily volume of discharge and the relative strength of the wastewater. Other characteristics become important as system operations are affected and specific discharge limits are identified (i.e., suspended solids). The environmental consequences in inadequately removing the pollutants from the waste stream can have serious ecological ramifications. For example, if inadequately treated wastewater were to be discharged to a stream or river, a eutrophic condition would develop within the aquatic environment due to the discharge of biodegradable, oxygen-consuming materials. If this condition were sustained for an extended period of time, the ecological balance of the receiving stream, river, or lake (i.e., aquatic microflora, plants, and animals) would be upset. Continual depletion of the oxygen in these waters would also give rise to the development of obnoxious odors and unsightly scenes.

Knowledge of characteristics of food and agricultural wastewater is

essential to the development of economical and technically viable wastewater management systems that are in compliance with current environmental policy and regulations. Management methods that may have been adequate with other industrial wastewaters may be less feasible with food and agricultural wastewater unless the methods are modified to reflect the characteristics of the wastewater and opportunities it may hold. The wastewaters produced in agricultural processing and food processing vary in quantity and quality, with those streams from food processing typically having low strength and high volume and those coming from animal farming operations tending to have high strength and low volume. These differences in quantity and quality dictate the type and capacity of wastewater management systems that should be deployed.

A clear understanding of the characteristics of food and agricultural wastewater permits management decision on treatment and utilization methods that are effective and economical; this point is further spelled out in Table 1.1. For example, a low-strength, high-volume wastewater containing a small amount of organic colloidal particulates may require a stand-alone biological wastewater treatment facility or just a plate-and-frame filter press; the decision is both technical and economical. Another generalized observation is that the bulk of oxygen-demanding substances is in the liquid phase for food processing wastewater; most oxygen-demanding substances in the wastewater of a high-intensity livestock farming operation are in the form of solid particulates. Some food processing operations occur seasonally (processing of fruits and vegetables); this seasonality adds complexity to the wastewater management systems that handle different sources of food and agricultural wastewater year-round, and clearly the understanding of wastewater characteristics helps plan ahead for this abnormality of process operations. Knowledge of wastewater characteristics also allows strategic planning of water recycling and reuse and recovery of valuable components in the wastewater.

As in most wastewaters, the components present in agricultural and food wastewater run a gamut of many undefined substances, almost all organic in nature. Organic matters are substances containing compounds in possession of mainly elements C, H, and O. The carbon atoms in the organic matters (also called *carbonaceous compounds*) may be oxidized both chemically and biologically to yield CO<sub>2</sub> and energy. It is possible that some sources of wastewaters from certain food processing operations in a processing plant may have limited numbers of possible contaminants present; however, these wastewaters tend to mix with other streams of wastewaters

**Table 1.1.** Wastewater treatment options available to remove various categories of pollutants in food and agricultural wastewater.

Pollutants in Wastewaters	Management Options
Dissolved organic species	Biological treatment; adsorption; land applications; recovery and utilization
Dissolved inorganic species	Ion exchange; reverse osmosis; evaporation/distillation; adsorption
Suspended organic materials	Physicochemical treatment; biological treatment; land applications; recovery and utilization
Suspended inorganic materials	Pretreatment (screen); physicochemical treatment (sedimentation, flotation, filtration, coagulation)

from the same work site, making it virtually impossible to catalog the substances in the effluents from the plant. Thus, the characteristics of agricultural and food wastewater can be viewed as a set of well-defined physicochemical and biological parameters that are critical in designing and managing agricultural and food wastewater treatment facilities.

### ***General characteristics of wastewaters in agriculture and food processing***

Wastewater from food processing operations is defined by the food itself. Food and agricultural wastewater contains dissolved organic solids from various operations and debris from mechanical processing of foods, such as peeling and trimming, and hydrodynamic impacts in washing and transporting. Agricultural and food processing operations inevitably use large quantities of water to wash—and, in some instances, cool—food items. Canning wastewaters are essentially the same as home kitchen waste because the wastewater is accumulated from various processes involved in the canning operations, such as trimming, sizing, juicing, pureeing, blanching, and cooking. Vegetables also require large amounts of water to blanch and cool. Almost all operations in food or agricultural processing involve cleaning plant floors, machinery, and processing areas; the water used is often mixed with detergents that sometimes are doubled as lubricants for the food processing machinery.

Depending on particular processing operations, water used in the operations is often reused with or without treatment when this practice is economical and legal. As fresh water supply diminishes in many parts of the world, water reuse is often seen as a must for all practical reasons. Reusing and recycling water can result in a considerable reduction in water usage; however, one should keep in mind that if the reused water is intended for edible food items, the food safety issue arising from the reused water should be examined diligently and thoroughly. After all, food safety remains the overriding concern in all food processing and manufacturing operations.

There are common pollutants present in the majority of food and agricultural wastewater and effluents from each stage of the typical wastewater treatment processes (see the following chapters for more information); they are free and emulsified oil/grease, suspended solids, organic colloids, dissolved inorganics, acidity or alkalinity, and sludges. Table 1.1 is a summary of the processes available to treat food and agricultural wastewater.

Each food processing plant produces wastewaters of different quantity and quality. No two plants, even with similar processing capacity of food products, will generate wastewaters of the same quantity and quality because there are too many variables (technical or otherwise) in the process that ultimately define characteristics of wastewater. Furthermore, even different periods of food processing in the same plant may produce different wastewater streams with different characteristics. It is therefore essential to understand that the generalized description of wastewaters from fruit and vegetable processing needs to be understood as an approximation to explaining a complex issue. Any quantitative information shown here or anywhere else shall be considered as averaged data. Typical characteristics, estimated volume, and estimated organic loading of wastewater generated by the food processing industry in the state of Georgia, U.S.A., are tabulated in Table 1.2.

All major food and agricultural processing operations generate wastewater streams; however, the amount and strength of the wastewater streams vary with the major segments of the food and agricultural processing industry. Table 1.3 summarizes the sources of the wastewater streams and possible treatment processes. As shown in Table 1.3, not all agro-food processing operations generate substantial wastewater that warrants on-site wastewater treatment facilities. The following summary of the major segments of the agro-food processing operations requiring

**Table 1.2.** Typical characteristics, estimated volume, and estimated organic loading of wastewater generated by the food processing industry in Georgia (source: Magbunua, 2000).

Industry Group	Estimated Wastewater Volume, Million Gallons/year	Typical Characteristics	Estimated Organic Loading, Tons/Year BOD
Meat and poultry products	10,730	1,800 mg/l BOD 1,600 mg/l TSS 1,600 mg/l FOG 60 mg/l TKN	80,600
Dairy products	500	2,300 g/l BOD 1,500 mg/l TSS 700 mg./l FOG	14,900
Canned, frozen and preserved fruits and vegetables	2,080	500 mg/l BOD 1,100 mg/l TSS	4,300
Grain and grain mill products	130	700 mg/l BOD 1,000 mg/l TSS	300
Bakery products	530	2,000 mg/l BOD 4,000 mg/l TSS	4,400
Sugar and confectionery products	140	500 mg/l BOD	300
Fats and oils	350	4,100 g/l BOD 500 mg./l FOG	7,000
Beverages	3,660	8,500 mg/l BOD	91,000
Miscellaneous food preparations and kindred products	700	6,000 mg/l BOD 3,000 mg/l TSS	5,600
<b>TOTAL</b>	<b>18,810</b>		<b>208,600</b>

*Abbreviations:* BOD: biological oxygen demand; TSS: total suspended solids; FOG: fats, oils, and grease, TKN: total Kjeldahl nitrogen.

wastewater treatment is presented for the reader to appreciate the unique pollution issues in these segments, even though it is clear that there is considerable similarity among many segments of the food and agricultural processing industry. Additional information about the characteristics of wastewaters in all major segments of the food and agricultural processing industry can be found from Middlebrooks' book (1979).

**Table 1.3.** Summary of wastewater sources and treatment strategies in major food and agricultural processing.

Agro-Food Operations	Sources of Wastewater Streams	Treatment Strategies
Vegetables and fruits	Sorting, trimming, washing, peeling, pureeing, in-plant transport, canning and retort, dehydration, and cleanup	Primary and secondary treatment processes
Fishery	Eviscerating, trimming, washing, precooking, canning and retort, and cleanup	Primary and secondary treatment processes
Poultry and meat	Animal waste, killing and bleeding, scalding (poultry), eviscerating, washing, chilling, and cleanup	Primary and secondary treatment processes
Dairy	By-products, spills, leaks, line cleaning, and cleanup	Biological wastewater treatment
Corn wet milling	Steeping water, washing, and cleanup	Mainly screen, activated sludge processes, and secondary sedimentation
Sugar refining	Process water and cooling water	Recycling and discharge to municipal wastewater systems
Oil and fat	Steaming, solvent recovery, degumming, soapstock water, neutralization, and cleanup	Primary, secondary treatment, and sludge treatment processes
Nonalcoholic beverage	Cleanup	Discharge to municipal wastewater systems
Alcohol beverage	Washing, cooling, leaks, and cleanup	Biological wastewater treatment and stabilization ponds
Flavoring extracts	Washing, evaporator condensate, steam distillation, and cleanup	Biological wastewater treatment or direct discharge to municipal wastewater systems
Egg product	Washing, leaks, and cleanup	Biological wastewater treatment and aerobic lagoon
Other food production	Leaks and cleanup	Depending on specific products and locality



**Table 1.4.** Common unitary processes of fruit and vegetable processing that generate wastewater.


Process	Wastewater Comes From . . .
Washing and rinsing	The entire process; may use detergent or chlorinated water
Sorting (grading)	Density grading operation only
In-plant transport	Water conveys products from one location to the other
Peeling	Hot water or high-pressure water spray; may involve chemicals (caustic soda) or detergents
Pureeing and juicing	Condensated evaporated water
Blanching	Hot water or steam for blanching
Canning and retort	Washing cans and steam for retort and cooling with water
Drying or dehydration	Condensated evaporated water
Mixing and cooking	Leaking of liquid products
Cleanup	Cleaning up at every stage

*Wastewaters from fruit and vegetable processing*

The fruit and vegetable industries are as assorted as the names imply—these industries process in a number of ways the great variety of fruits and vegetables grown in the United States. The categories of processing include canning, freezing, dehydrating, and pickling and brining. The quantity and quality of wastewater streams from the industries vary considerably with the operations of the processing and seasons.

Fruit and vegetable processing plants are major water users and waste generators. In all stages of food processing (unitary processes), raw foods must be rendered clean and wholesome and food processing plants must be maintained sanitary all the time. Several common unitary operations of fruit and vegetable processing that generate wastewater are shown in Fig. 1.1.


Some of these unitary operations are intuitively obvious waste generating (e.g., washing and rinsing); others are less so (e.g., in-plant transport). Table 1.4 provides a brief explanation of several unitary processes that generate wastewater. For the most part, these wastewaters have been shown to be biodegradable, although salt is not generally removed during the treatment of olive storage and processing brines, cherry brines, and sauerkraut brines.



**Figure 1.1.** Unitary processes of fruit and vegetable processing that generate wastewater.

The effluents from fruit and vegetable processing operations consist of mainly carbohydrates, such as sugars, starches, pectins, vitamins, and other components of the cell walls that have been severed during processing. Of the total organic matters, 70–80% is in the dissolved form; they are not easily removed from wastewater by conventional mechanical means, although physicochemical processes such as adsorption and chemical oxidation or membrane-based technologies such as membrane filtration are capable of removing dissolved solids in relatively low concentrations at higher costs (see Chapter 3 for adsorption and chemical oxidation and membrane filtration). Obviously, biological wastewater treatment methods will work best in this type of wastewater streams.

The majority of the literature review regarding characterization of fruit and vegetable processing wastewaters focuses on wastewater streams from canning of fruits and vegetables (e.g., Soderquist et al., 1975); the wastewaters from other processing operations of fruits and vegetables are of importance as well. Blanching of vegetables for freezing is a process that requires a large amount of water, and the quantity of wastewater generated is also proportionally high. Fig. 1.2 shows a flow diagram of water reuse



**Figure 1.2.** A diagram of a four-stage counterflow system for reuse of water in a pea cannery.

in a pea cannery. Postharvesting agricultural wastewater could also be a source of wastewater. Washing and rinsing water used in cleaning fresh produce and fruits are sometimes reused; however, wastewater is still generated in the process and has to be treated eventually. There is a possibility of recovering valuable substance from wastewater streams in fruit and vegetable processing, such as flavors from blanching waters; however, it is often technically complex and economically impractical to extract the valuables among a large number of undesirables in these streams with current technologies.

#### *Wastewaters from the fishery industry*

The production processes used in the fishery industry generally include the following: harvesting, storing, receiving, eviscerating or butchering, precooking, picking or cleaning, preserving, and packaging. Harvesting provides the basic raw materials (fishes) for processing and subsequent distribution to the consumer. Once fishes are aboard the fishing vessel, the catch either is taken directly to the processor, or is iced or frozen for later delivery. Preprocessing may be undertaken aboard before the catch is sent to the processing plant. It may include beheading shrimp at sea, eviscerating fish or shellfish at sea, and other operations to prepare the fish for

butchering. Wastes from the butchering and evisceration that are sizable are usually collected in the dry form, or screened from the wastewater stream, and processed as a fishery by-product.

The receiving operation usually involves unloading the vessel, weighing, and transporting by conveyor or suitable container to the processing area. The catch may be processed immediately or transferred to cold storage.

Sometimes, cooking or precooking crab and other shellfishes or tuna may be practiced in order to prepare the fish or shellfish for removal of meat and the cleaning operation. The inedible fish or seafood parts, such as skin, bone, gills, shell, and similar parts, are easily removed after precooking. The steam condensate, or *stick water*, from the tuna or crab precooking is often collected and further processed as a by-product. Wastes generated during this procedure are sometimes collected and saved for by-product processing. Depending on the species, the cleaning operation may be either manual or mechanical. With fresh fish or fresh shellfish, the meat product is packed into a plastic container and refrigerated for shipment to a distribution center or directly to a retail outlet. If shelf life of the product is required for an extended period of time before consumption, preservation techniques must be used to prevent spoilage from bacterial activities and enzymatic autolysis. Freezing, canning, pasteurization, drying, and refrigeration are the most common preservation techniques used in the fishery industry.

Characteristics of fishery wastewaters are often dependent on several factors: method of processing (mechanical or manual), fish species, and fish products. However, even with similar processing plants using the same method of processing on the same species of fish and producing the same fish products, the quality of wastewaters (in terms of BOD [biological oxygen demand], COD [chemical oxygen demand], or TSS [total suspended solids]) varies with location and even with season. It should be mentioned that there is no substitution for direct determination of the quality of fishery wastewater in the effluent being investigated.

Like all wastewaters under consideration for treatment, the issue of treatability of seafood or fishery wastewater is often shaped by the discharge limits set up by the government agencies or an international body enforced through international treaties. Specifically, the discharge limits of BOD<sub>5</sub>, TSS, and fat/oil/grease (FOG) are enforced based on the variety of fish species. Table 1.5 is a summary of discharge limits imposed by the United States Environmental Protection Agency (USEPA) in 1985. It is

**Table 1.5.** Summary of discharge limits for the fishery industry imposed by the United States Environmental Protection Agency in 1985 (*source*: USEPA).

Fish Species	BOD <sub>5</sub> (mg/l)	TSS (%)	FOG (mg/l)
Tuna	20.0	8.3	2.1
Salmon	2.7	2.6	0.31
Other finfish	1.2	3.1–3.6	1.0–43
Crab	0.3–10	2.2–19	0.6–1.8
Shrimp	63–155	110–320	36–126
Clam and oyster	N/A	24–59	0.6–2.4


prudent to consult with the local authorities on issues related to discharge limits of fishery wastewaters.

Fishery wastewaters are rich in fats and proteins. According to Middlebrooks (1979), a processing plant for finfish processing can produce 3.32 kg/ton BOD, 0.348 kg/ton grease/oil, and 1.42 kg/ton suspended solids in the wastewater if using manual processing, or 11.9 kg/ton BOD, 2.48 kg/ton grease/oil, and 8.92 kg/ton suspended solids in the wastewater if using mechanical means. This has generated a lot of interest in recovering these materials to offset totally or partially the costs of treating the fishery wastewater. Like proteins, the presence of FOG in the fishery wastewaters is mainly due to the processing of fishes. Canning, for example, generates grease and oil after fish products are heated.

#### *Wastewaters from meat and poultry processing*

The meat and poultry processing industry (excluding rendering but including seafood processing) uses an estimated 150 billion gallons of water annually. Although a portion of the water used by the industry is reused or recycled, most of the water becomes wastewater. Similar to those wastewater streams from the fishery industry, the wastewaters from meat and poultry processing are high in fat/oil/grease and proteins.

The poultry industry handles billions of pounds of chickens (called *broilers*, weighing from 2.5 lb to 4.5 lb) and turkeys each year, and processing plants vary ranging from 50,000 birds to 250,000 birds per day. The main poultry operations involve receiving and storing, slaughtering, defeathering, eviscerating, packing, and freezing. Nearly all these operations involve using water, and many pollutants in the wastewater stream are created in the receiving and storing operation where manure and un-



**Figure 1.3.** A flow chart of a poultry processing plant.

consumed feed are washed down from the broilers. The water usage and wastewater generation is illustrated in Fig. 1.3.

A meat processing plant consists of a slaughterhouse and/or a packing-house. The slaughtering process has four basic operations: killing, hide removal/hog dehairing, eviscerating/trimming, and cooling of carcasses (USEPA, 1974). Each of these operations contributes to the wastewater stream; however, before herding the animals to their final destinations, the animals are held in the livestock holding pens generating additional wastewater streams. The wastewater streams from these holding pens primarily come from the spilling from the water troughs, from cleanup, and from wastes laid by the animals.

*Wastewaters from the dairy industry*

The dairy industry is one of the most important agricultural processing industries in the United States and has grown steadily in the last decades.

Wastewaters originate from two major dairy processing—from fluid

milk at the receiving station and bottling plants, but increasingly more importantly at the processing plants that produce condensed milk, powdered milk, condensed whey and dry whey, butter, cheese, cultured product, ice cream, and cottage cheese. The milk itself has a BOD<sub>5</sub> of 100,000 mg/l and washing plants that produce butter and cheese may produce a wastewater with BOD<sub>5</sub> of 1,500 to 3,000 mg/l. Dairy processing uses raw materials beyond milk and milk-related materials; nondairy ingredients such as flavors, sugar, fruits, nuts, and condiments are utilized in manufacturing ice cream, yogurt, and flavored milk, and frozen desserts. The pollutants can enter the wastewater streams through spills, leaks, and wasting of by-products. Apart from whey, which is acidic, most dairy wastewater streams are neutral or slightly alkaline, but they tend to become acidic rapidly due to the lactic acid produced as a result of fermentation of lactose.

Most dairy product processing operations are multiproduct facilities. Among these dairy processing operations there may be receiving stations, bottling plants, creameries, ice cream plants, and cheese-making plants; all these operations may contribute to wastewater streams in the dairy industry. Controlling product loss and recovery of by-products (e.g., whey protein) can improve not only yields, thus profits, but also the amount and strength of dairy wastewater streams.

Dairy wastewaters are amenable to biological wastewater treatment and this is the principal method used in the dairy industry; according to USEPA (1974), there were 64 activated sludge plants, 34 trickling filters, 6 aerobic lagoons, one stabilization pond, 4 combined systems, 2 anaerobic digestion facilities, and 1 sand filtration for secondary effluent operating in the dairy industry in the United States. Most dairy processing plants treat their wastewaters to a level that is acceptable to municipal wastewater treatment facilities.

#### *Wastewaters from oil and fat processing*

Edible oil extraction involves solvent extraction of oil-bearing seeds or animal fats (there are mechanical expressers for olive oil and sesame oil) and refining steps of removing undesirables from extracted oil. In addition to cleanup and washing, which use water thus generating wastewater, the following all contribute to wastewater streams in edible oil production plants: deodorization that involves the injection of steam; refining that involves removing free fatty acids, phosphatides, and other impurities with caustic soda; and oil recovery from the extracted meal using water. The wastewaters from the oil production and refining industry, without doubt, are

amenable to biological wastewater treatment. There are several pollutants in the wastewater streams from the edible oil extraction and refining; they are free and emulsified oils, grease, suspended solids, and dissolved organic and inorganic solids. Along with the sludges that come from either primary or secondary treatment processes, many common wastewater treatment processes may be employed to remove these pollutants. Trace amounts of solvents such as hexane may be removed by adsorption or steam/air stripping. Another environmentally friendly method of removing hexane from wastewater is pervaporation (Peng et al., 2003).

### ***Parameters for physicochemical treatment of wastewater***

#### *pH*

pH is a measurement of the acidity of the wastewater and an indication of growth conditions for the microbial communities used in biological wastewater treatment regimens. pH values vary greatly with the sources of agricultural and food wastewater and with the environmental conditions and duration of storage of the wastewater collected, because these factors dictate the amount of certain substances and decomposition of biological matters as well as emissions of ammonia compounds.

#### *Solids content*

Solids in wastewaters come in two forms: suspended solids (nondissolvable) and dissolved solids. Suspended solids are nuisances because they can either settle on the bottom of the receiving water body or float on the surface of the water body. Either way will affect the ecological balances of the receiving water body. Solids that readily settle are usually measured with an Imhoff cone, in which a known amount of water sample is poured in the cone and the amount of the solids settled at given times is recorded and compared with the admissible amount of settling solids in the wastewater for discharge. The acceptable settling solids level is usually determined by environmental regulations and as a rule of thumb, discharge of wastewater or treated wastewater is not acceptable if the result of Imhoff testing shows that the water sample contains settling solids after 10 minutes of testing.

Suspended solids are usually measured with a porous fiberglass filter of known pore size, in which a known amount of well-mixed water sample passes through. The dry mass accumulation on the filter is the amount of nondissolvable solids.



Oils and greases represent another realm of suspended solids. These floating substances from some food operations have a tendency to clog the pipes and stick to the surfaces of any material. They are also easily oxidized, producing objectionable odors. In any case, oils and greases should be removed. The amount of oil and grease may be measured with the solvent extraction method found in the standard methods (Eaton et al., 2005).

Soluble solids are laboratory measured with evaporation and subsequent weighing of the remaining dry mass of a known amount of water filtrate sample that is collected from the suspended solids measurement or similar pretreatment to remove suspended solids. Soluble solids are significant in some sources of food wastewater (e.g., fishery, dairy industries) and thus are important in formulating wastewater treatment and resource recovery strategy.

#### *Temperature*

It is generally accepted that the temperature of discharged wastewater to a receiving water body cannot exceed 2–3°C of the ambient temperature in order to maintain population balance of the aquatic ecosystem of the receiving water body. Wastewater from some food operations such as retort should be cooled before discharge or biological treatment.

#### *Odor*

Odor by itself is not a pollutant, although prolonged and intense exposure has been attributed to adverse effects on wastewater treatment plant workers, and even residents living near the plant, with symptoms such as headache and nausea. Food wastewater contains significant amounts of organic matters and when the organic matters decompose into volatile amines, diamines, and sometimes ammonia or hydrogen sulfide, odor transpires and it can be overwhelming. The other source of wastewater odor generated in food processing is the blanching operation of certain vegetables such as cauliflower and cabbage. The incentive of developing odor abatement strategy in food and agricultural wastewater management is obvious: the public perception and acceptance of a food processing plant is often nostrilic not nostalgic.


#### *Parameters for biological treatment of wastewater*

The organic matters in food and agricultural wastewater are considerable and complex. Instead of attempting to identify each organic component of

wastewater, wastewater professionals use the parameters for biological wastewater treatment to classify the organic matters. The most common parameters are the oxygen demand values. The oxygen demand refers to the amount of oxygen that is needed to stabilize the organic content of the wastewater. The two most common oxygen demand methods of defining organic matters in wastewater are the *biochemical oxygen demand* and the *chemical oxygen demand*.

#### *Biochemical oxygen demand*

*Biochemical oxygen demand (BOD)* estimates the degree of organic content by measuring the oxygen required for the oxidation of organic matter by the aerobic metabolism of microbial communities. A characteristic simple carbonaceous compound is fructose, and this is oxidized as follows (Equation 1.1):



The common procedures of BOD measurements are dilution method and respirometric method.

The dilution method is the most common method in use for the wastewater industry and consists of diluting wastewater samples with a nutrient solution (to provide essential minerals for microbial activities), according to wastewater strength, within airtight bottles that are also saturated with air (for facilitating aerobic metabolism), and measuring the dissolved oxygen at the start and periodic intervals of the analysis. A five-day period is generally engaged, and the BOD measured thereafter is called *BOD*<sub>5</sub>. The authoritative procedures of BOD analysis can be found in the standard methods (Eaton et al., 2005). One cautionary note for BOD analysis is that it involves the degradation of organic matters by a microbial population in the testing bottles; the microbial count is important for the analysis and insufficient microbial count will underestimate the BOD. This issue is particularly critical for the food wastewater analysis because some food processing operations involve thermal processing or other sterilizations, and the wastewater generated in those operations may not have sufficient microbial count for accurate analysis of BOD in the wastewater. The possible remedy for this is to measure the wastewater from those operations constantly for a long period of time or to add the adapted “seed” of bacteria to the wastewater. The dilution method is the time-honored but time-consuming method. An upgraded version of the method involves the use

of a dissolved oxygen electrode in the BOD<sub>5</sub>, enabling continuous readings of the dissolved oxygen during the five-day period. Commercial products of the BOD<sub>5</sub> analysis instruments based on the dilution method are available.


Another phenomenon that could alter the BOD analysis result, though not occurring in all food and agricultural wastewaters, is nitrification of the wastewater. Nitrification is a biochemical process of converting organic nitrogen (e.g., proteinaceous compounds) into nitrate (Liu et al., 2003). This is an aerobic process and therefore uses additional oxygen. One method of inhibiting nitrification is to use inhibitive chemicals such as allyl thiourea, methylene blue or 2-chloro-6-(trichloromethyl) pyridine (Metcalf and Eddy, Inc., 2002).

Respirometric method is an alternative to the dilution method in BOD analysis. It accelerates BOD analysis by combining biochemical processes with faster chemical reaction. The basic design of the respirometric method is the use of a continuously stirred bottle with partially filled wastewater (and a headspace), which is connected to a reservoir of alkali (usually potassium chloride) that absorbed the CO<sub>2</sub> generated from the degradation of organic matters in the wastewater sample. The pressure changes in the headspace of the BOD bottle will be constantly monitored for consumption of O<sub>2</sub> in the wastewater sample. Even with the hybrid BOD analysis methods, the BOD analysis is slow and unsuitable for process control purposes in a wastewater treatment plant. Another approach to measuring the organic content of wastewater, chemical oxygen demand, is developed to complement the BOD analysis.

#### *Chemical oxygen demand*


*Chemical oxygen demand (COD)* is an estimator of the total organic matter content of wastewaters. COD approach is based on the chemical oxidation of the organic matters in the wastewater: either oxidation of the organic matters by permanganate or oxidation by potassium dichromate (K<sub>2</sub>Cr<sub>2</sub>O<sub>7</sub>). COD analysis using dichromate is the most common method today and is used to continuously monitor biological wastewater treatment systems. The value of COD for a given wastewater stream is usually higher than that of BOD<sub>5</sub> due to the fact that not only organic matters can be oxidized, but nonorganic matters can as well. It is common to correlate the values of COD to the values of BOD<sub>5</sub> and use the rapid COD analysis method (about two hours) to determine the organic content of the wastewater sample. The COD test utilizes K<sub>2</sub>Cr<sub>2</sub>O<sub>7</sub> in boiling concentrated sul-

phuric acid (150°C), in the presence of a silver catalyst ( $\text{Ag}_2\text{SO}_4$ ), to facilitate the oxidation. The detailed procedures of COD test can be found in the standard methods (Eaton et al., 2005). The following reaction describes the oxidation of organic carbonaceous compounds in the presence of  $\text{K}_2\text{Cr}_2\text{O}_7$  and the catalyst (Equation 1.2):



The COD is calculated by titrating the remaining dichromate of known amount or by spectrophotometrically measuring the  $\text{Cr}^{3+}$  ion at 606 nm (or remaining  $\text{Cr}_2\text{O}_7^{2-}$  at 440 nm). The titration method is, though more time-consuming, more accurate than the spectrophotometry method.

A common interference in the COD testing is chloride in the wastewater, which is readily oxidized by dichromate (Equation 1.3):



This interference that overestimates the COD level in the wastewater may be prevented with the addition of mercuric sulphate ( $\text{HgSO}_4$ ) to remove  $\text{Cl}^-$  in the form of an  $\text{HgCl}_2$  precipitate (Bauman, 1974). The above COD method is called the *open reflux method* in the standard methods (Eaton et al., 2005). Another COD testing method is called *closed reflux method* (Eaton et al., 2005). In this setting, the oxidation takes place in the closed tubes filled with a small wastewater sample mixed with  $\text{Ag}_2\text{SO}_4$  and  $\text{HgSO}_4$ . The tubes are heated to hasten the oxidation and, as a result, results in shorter times. The COD is determined spectrophotometrically. Several commercial designs based on this method are available in the form of an apparatus or kit with solution ampoules and pre-measured reagents.

### *Total organic carbon*

*Total organic carbon (TOC)* is a method based on the combustion of organic matters in the wastewater sample to  $\text{CO}_2$  and water, dehydration of the combustion gases, and running the gases through an infrared analyzer. The analyzer reads out the amount of  $\text{CO}_2$  from the combustion, which is proportional to the amount of carbon in the wastewater sample. Sometimes, presence of inorganic carbon compounds such as carbonates and bicarbonates in the wastewater may distort TOC readings. The problem may be eliminated with purging of inert gases. Commercial TOC devices em-

ploy a different strategy: they have two combustion tubes to accommodate combustions of inorganic carbon compounds at 150°C and organic carbon compounds at 950°C. The necessary use of furnace in the TOC analysis renders this method more expensive, thus preventing TOC analysis from being widely used.

### ***Nitrogen and phosphorus***

The sources of nitrogen (N) and phosphorus (P) in food and agricultural wastewater may include artificial fertilizers, synthetic detergents used in cleaning food processing equipment, and metabolic compounds from proteinaceous materials. These elements are nutrients for microbial flora; however, if they are present in excess, they may cause proliferation of algae in the receiving water body, adversely affecting the ecological balance. Increasingly, many wastewater treatment plants employ advanced wastewater treatment technologies to reduce or eliminate the amount of N and P in the discharge.

### ***Sampling***


Accurate characterization of food and agricultural wastewater depends on accurate sampling of wastewater. Special attention should be paid to the representative sampling of a wastewater stream. Commercial sampling instruments are widely available and a simple in-house lab-scale continuous sampler can be set up with relatively modest means (Metcalf and Eddy, Inc., 2002). The procedure for a particular parameter of wastewater management may be found in the standard methods (Eaton et al., 2005).

## **Material Balances and Stoichiometry**

In dealing with food and agricultural wastewater, whether formulating treatment and utilization strategy or planning the initial stage of a comprehensive management project, a basic understanding of the effects of mass flow rate or loading factors on process designs is essential.

*Stoichiometry* is the material accounting for a chemical reaction. Given enough information, one can use stoichiometry to calculate masses, moles, and percents within a chemical equation that is an expression of a


chemical process. Consider a simple reaction where a reactant A converts into resultant B (Equation 1.4):



where  $a$  and  $b$  are termed as stoichiometric coefficients and thus positive proportionality constants. Equation 1.4 tells us that for every  $a$  moles of reactant A consumed there will be  $b$  moles of resultant B produced. If, initially, A has a mole concentration of  $N_{A0}$  and B has a starting concentration of  $N_{B0}$ , then at any given time the reactant A and resultant B will be  $N_A$  and  $N_B$ . They are related to each other by the following expression (Equation 1.5):

$$(N_{A0} - N_A)/a = (N_B - N_{B0})/b$$

In this expression,  $(N_{A0} - N_A)$  represents the consumption of A in moles at the time while  $(N_B - N_{B0})$  accounts for the gain of B in moles. Equation 1.5 may be used to calculate  $N_A$  or  $N_B$  when other terms in Equation 1.5 are known. For a more general chemical reaction with the following form (Equation 1.6):




there will be the following (Equation 1.7):

$$(N_{A0} - N_A)/a = (N_{B0} - N_B)/b = (N_C - N_{C0})/c = (N_D - N_{D0})/d$$

All terms are in moles.

Stoichiometric equations stipulate the important principle of mass conservation: mass can neither be created nor be destroyed; it can only transform from one form or state to another. However, a stoichiometric expression can provide only a snapshot of the underlying chemical reaction at a given time; it does not reveal how fast the chemical reaction occurs. For that attribute, we introduce a new term called *chemical reaction rate*. Consider the chemical reaction we used in Equation 1.4:



In this case, we denote the rate of consumption of A per unit volume (molar unit) in a reactor as  $r_A$  and the rate of generation of B per unit vol-

ume in the reactor as  $r_B$ . And we know the following by intuition and the stoichiometric equation (Equation 1.8):

$$b r_A = a r_B$$

It should be emphasized that all units discussed so far are mole-based. In many biological wastewater treatment process designs and calculations, the units are most likely mass-based. The relationship between mass-based units and mole-based units is shown in Equation 1.9:

$$[\text{mole-based units}] = [\text{mass-based units}]/[\text{molecular weight}]$$

It is, however, difficult to establish the exact molecular structures of all microorganisms involved in a wastewater treatment process; therefore, mass-based units have to be used. In this scenario, stoichiometric equations cannot be used; the relationship between reaction rates needs to be obtained from experiments.

Stoichiometry is a specific form of material balance for reactions and is expressed in mole-based units. In real-world situations, those reactions take place in reactors or other forms of containers. Their designs and layouts will affect the amount of materials consumed and new substances generated in the reactions. Because of this realization, we shall use mass balance equations to describe macroscopically the dynamics of materials in a treatment system. We usually start developing mass balance equations on the treatment system with a control volume, a representative portion of the real system that can be integrated over the entire domain of the system. The changes of materials in the control volume should satisfy the law of mass conservation (Equation 1.10):

$$[\text{species in}] - [\text{species out}] + [\text{generation}] = [\text{species accumulation}]$$

In mass units, Equation 1.10 can be expressed mathematically as the following (Equation 1.11):

$$m_{\text{in}} - m_{\text{out}} + r_A V_c = d(CV_c)/dt$$

where  $m_{\text{in}}$  is the mass flow rate of species entering the control volume,  $m_{\text{out}}$  is the mass flow rate of species exiting the volume,  $V_c$  is the control volume, and  $C$  is the mass concentration of the species. With appropriate

boundary conditions of the system, fluid flow characteristics, and the initial condition of the species, Equation 1.11 can be integrated over these conditions to yield the quantities of the variables in the equation.

Equation 1.11 depicts an unsteady state system where the amount of the species varies with the reaction time. For a steady state system, Equation 1.11 is reduced to the following (Equation 1.12):

$$m_{\text{in}} - m_{\text{out}} + r_A V_c = 0$$

### **Fluid Flow Rate and Mass Loading**


Almost all wastewater treatment plants are designed based on the annual average daily flow rate of wastewater being processed. However, it should be noted that every plant has to take into account the actual daily flow rate, characteristics of wastewater, and the combination of flow rate and composition (called *mass-loading*) of the wastewater stream. In an on-site wastewater treatment facility that deals with wastewater streams from a fixed food processing operation, flow rate and mass-loading are not complicated issues in designing and managing wastewater. But for the wastewater streams from various sources subject to changes in flow rate and mass loadings, the peak conditions, whether it is peak flow rate or mass loading, need to be considered as well.

### **Kinetics and Reaction Rates**

Chemical or biochemical kinetics is the study of chemical or biochemical reactions with respect to reaction rates, effect of conditions reactions are subject to, rearrangement of molecules, formation of intermediates, and involvement of catalyst. The word *kinetics* is originated from the Greek *kinesis*, meaning movement. Thus, the kinetics of chemical or biochemical reactions are mainly concerned with rate of reaction and anything else affecting it.

In general, the reaction rate depends on the concentration of reactants. It may also depend on the concentrations of other species that do not appear in the stoichiometric equation. The dependence of reaction rate on concentrations of reactants can be expressed mathematically in terms of the reaction rate constant and the powers of concentrations of reactants. Recall Equation 1.6 for a general reaction form:





The rate of reaction can be expressed as the following (Equation 1.13):

$$r = kC_A^a C_B^b$$

where  $k$  is the reaction rate constant,  $a$  and  $b$  are exponents that may or may not be equal to those coefficients appearing in Equation 1.6, and  $C_A$  and  $C_B$  are concentrations of reactants A and B. The summation of  $a$  and  $b$  is called *reaction order*—i.e., reaction order for the reaction shown in Equation 1.6 is  $(a+b)$ . Generally, reactions are categorized as zero-order, first-order, second-order, or mixed-order (higher-order) reactions, based on the value of  $(a+b)$ . The unit of  $k$  is  $(\text{concentration})^{1-a-b} (\text{time})^{-1}$ .

### ***Zero-order reactions***

Zero-order reactions (order = 0) have a constant rate. This rate is independent of the concentration of the reactants. The rate law is  $r = k$ , with  $k$  having the units of  $(\text{concentration})^1 (\text{time})^{-1}$ , e.g., M/sec.

### ***First-order reactions***

A first order reaction (order = 1) has a rate proportional to the concentration of one of the reactants. A common example of a first-order reaction is the phenomenon of radioactive decay. The rate law is  $r = kC_A$  (or  $C_B$  instead of  $C_A$ ), with  $k$  having the units of  $(\text{time})^{-1}$ , e.g.,  $\text{sec}^{-1}$ .

### ***Second-order reactions***


A second-order reaction (order = 2) has a rate proportional to the concentration of the square of a single reactant or the product of the concentration of two reactants: rate =  $kC_A^2$  (or substitute B for A or  $k$  multiplied by the concentration of A times the concentration of B), with the unit of the rate constant  $k = (\text{concentration})^{-1} (\text{time})^{-1}$ , e.g.,  $\text{M}^{-1}\text{sec}^{-1}$ .

### ***Mixed-order or higher-order reactions***

Mixed-order reactions, such as some biochemical reactions, have a fractional order for their rate, e.g., rate =  $kC_A^{1/3}$ . The unit of the rate constant  $k$  is  $(\text{concentration})^{2/3} (\text{time})^{-1}$ , e.g.,  $\text{M}^{2/3}/\text{sec}$ .

**Catalytic reactions**

Almost all biochemical reactions involve catalysts, enzymes that are specialized proteins synthesized by microorganisms. A *catalyst* is a substance (enzyme for biocatalyst) that increases the rate of reaction without undergoing *permanent* (bio)chemical change. The primary function of a catalyst is to lower the activation energy of a reaction so that the reaction can be easily carried out but does not affect the reaction equilibrium. In biochemical reactions, the enzyme is believed to possess certain active sites consisting of amino acid side chains or functional groups to which the specific functional groups of substrate molecules bind. Thus, the enzyme is reaction-specific. The active sites of the enzyme act as the donors or acceptors of electrons from the substrate molecules and speed up the reaction. It is assumed that the enzymatic reaction involves a series of step-by-step elementary reactions forming complexes with substrate molecules along the way and is described by Michaelis-Menten kinetics (Equation 1.14):



The terms  $k_1$ ,  $k^{-1}$ , and  $k_2$  are rate constants for, respectively, the association of substrate and enzyme, the dissociation of unaltered substrate from the enzyme, and the dissociation of product (= altered substrate) from the enzyme. The overall rate of the reaction ( $r_p$ ) is limited by the step ES to E + P, and this will depend on two factors—the rate of that step (i.e.,  $k_2$ ) and the concentration of enzyme that has substrate bound, i.e.,  $C_{ES}$  (Equation 1.15):

$$r_p = k_2 C_{ES}$$

At this point, we make two assumptions. The first is the availability of a vast excess of substrate, so that  $C_S$  is markedly larger than  $C_E$ . Secondly, it is assumed that the system is in pseudosteady state, i.e., that the ES complex is being formed and broken down at the same rate, so the overall  $C_{ES}$  is constant. The formation of ES will depend on the rate constant  $k_1$  and the availability of enzyme and substrate, i.e.,  $C_E$  and  $C_S$ . The breakdown of  $C_{ES}$  can occur in two ways, either the conversion of substrate to product or the nonreactive dissociation of substrate from the complex. In both instances, the  $C_{ES}$  will be significant. Thus, at steady state we can write the following (Equation 1.16):

$$k_1 C_E C_S = (k_{-1} + k_2) C_{ES}$$

In the following term (Equation 1.17):

$$(k_{-1} + k_2) / k_1 = K_m$$

$K_m$  is named the *Michaelis-Menten constant*.

The total amount of enzyme in the system must be the same throughout the experiment, but it may either be free (unbound) E or in complex with substrate,  $C_{ES}$ . If we term the total enzyme  $C_{E0}$ , this relationship is expressed as the following (Equation 1.18):

$$C_{E0} = C_E + C_{ES}$$

in which  $C_{E0}$  represents initial enzyme concentration.

Inserting Equations 1.18 and 1.17 into Equation 1.16 and rearranging the resulting equation leads to the following (Equation 1.19):

$$C_{ES} = C_{E0}C_S / (K_m + C_S)$$

So substituting this right side into Equation 1.15 in place of  $C_{ES}$  results in the following (Equation 1.20):

$$r_p = k_2 C_{E0}C_S / (K_m + C_S)$$

The maximum rate, which we can call  $r_{max}$ , would be achieved when all active sites of the enzyme molecules have saturated with substrate molecules. Under conditions when  $C_S$  is much greater than  $C_E$ , it is reasonable to assume that all  $C_E$  will be in the form  $C_{ES}$ . Therefore,  $C_{E0} = C_{ES}$ . We may substitute the term  $r_{max}$  for  $r$  and  $C_{E0}$  for  $C_{ES}$  in Equation 1.15. This gives us the following (Equation 1.21):

$$r_{max} = k_2 C_{E0}$$

So, we now have the following (Equation 1.22):

$$r_p = r_{max} C_S / (K_m + C_S)$$

This equation is commonly referred to as the *Michaelis-Menten equation*.

The significance of Michaelis-Menten equation is that when  $r_p$  is half of  $r_{max}$ , from Equation 1.22, we would have the following (Equation 1.23):

$$C_S = K_m$$

The  $K_m$  of the enzyme is the substrate concentration at which the reaction occurs at half of the maximum rate and is therefore an indicator of the affinity that the enzyme has for a given substrate, and hence the stability of the enzyme-substrate complex. This interpretation may be better presented by plotting  $r_p$  vs.  $C_S$ , which is called the *Michaelis plot*.

It is obvious that at low  $C_S$ , it is the availability of substrate that is the limiting factor. Therefore, as more substrate is added there is a rapid increase in the initial rate of the reaction—any substrate is rapidly gobbled up and converted to product. At the  $K_m$ , 50% of active sites have the substrate occupied. At higher  $C_S$ , a point is reached (at least theoretically) where all sites of the enzyme have substrate occupied. Adding more substrate will not increase the rate of the reaction—hence, the leveling-out observed in the Michaelis plot.

In order to use the Michaelis-Menten equation, we need to know the values of  $K_m$  and  $r_{max}$ . The common approach is to linearize the Michaelis-Menten equation by plotting  $1/r_p$  vs.  $1/C_S$  (named the *Lineweaver-Burk linearization*), which results in a slope of the linearized line,  $K_m/r_{max}$  and an intercept on the  $1/r_p$  axis,  $1/r_{max}$ . Other linearization schemes of the Michaelis-Menten equation, such as Hanes and Hofstee schemes, would accomplish the same objective as the Lineweaver-Burk linearization.

## **Theoretical Modeling and Design of Biological Reactors**

Theoretical modeling of biological wastewater reactors using mathematical equations allows engineers and designers to test their strategies and evaluate their treatment options virtually, therefore reducing the amounts of time and money as well as the potential hazardous incidents that could happen to an actual experimentation. In the existing system, a robust model can be used to optimize the operational strategies. The development of the model often involves the selection of suitable equations that accurately describe fluid flow in the reactor and biochemical reactions in the form of microbial growth on organic and inorganic materials in the reactor. Many equations derived hereafter are more or less simplified equations of the generic reactor types. This approach has its own advantages: first, it acknowledges that the most biological reactors in use for wastewater treatment are quite similar to the generic reactors described below; second, the methodologies of derivation of the equations for the

generic reactors are valid for more “realistic” or complex reactors. Some of those equations related to reaction kinetics—mass balance, stoichiometry, and chemical thermodynamics—have been explained previously. The overriding goal of this section is to combine fluid flow with kinetics in several geometrical environments of the generic reactor types to derive the reaction rate expressions and concentration profiles of substrates in the reactors. For the sake of simplicity, we focus our attention initially on single reactions occurring in the liquid phase of constant density in single reactors.

### **Batch reactors**

In a batch reactor, at any given time after the reactor starts, there is feed neither coming in nor coming out. The mass balance of a batch reactor from Equation 1.11 will be the following (Equation 1.24):

$$0 - 0 + r_A V_c = d(CV_c)/dt$$

For a constant volume, the above equation is the following (Equation 1.25):

$$r_A = dC_A/dt$$

This may be integrated from the initial concentration of A,  $C_{A0}$  to the final concentration  $C_{Af}$ , i.e., the following (Equation 1.26):

$$\int dt = t = \int dC_A/r_A$$

The exact relationship between  $r_A$  and  $C_A$  (kinetics) needs to be known in order to solve Equation 1.26 to establish the concentration history of reactant A.

For zero-order reactions (order = 0),  $r = k$ , so Equation 1.25 develops into the following (Equation 1.27):

$$t = \int dC_A/r_A = \int dC_A/k = (C_{A0} - C_{Af})/k$$

For first-order reactions (order = 1),  $-r = kC_A$ , so Equation 1.25 becomes the following (Equation 1.28):

$$t = \int dC_A/r_A = -\int dC_A/kC_A = \ln(C_{A0}/C_{Af})/k$$

For second-order reactions (order = 2),  $-r = k(C_{B0} - C_{A0} + C_A)C_A$ , so Equation 1.25 turns into the following (Equation 1.29):

$$C_{Af}/C_{A0} = (C_{Bf}/C_{B0})\exp[-(C_{B0} - C_{A0})kt]$$

where  $C_{Bf} = C_{Af} - C_{A0} + C_{B0}$  and  $C_{B0}$  is the initial concentration of reactant B.

If  $C_{A0} = C_{B0}$ ,  $-r = kC^{2A}$ , and Equation 1.25 will yield the following (Equation 1.30):

$$kt = 1/C_{Af} - 1/C_{A0}$$

### ***Continuously stirred tank reactors (CSTRs)***

Continuously stirred tank reactors (CSTRs) are widely used in biological wastewater treatment processes and can be schematically viewed as tanks with input and output while a mechanical or pneumatic device provides the means of thoroughly mixing the liquid phase in tanks. In CSTRs, the liquid inside the reactor is completely mixed. The mixing is provided through an impeller, rising gas bubbles (usually oxygen), or both. The most characteristic feature of a CSTR is that it is assumed that the mixing is uniform and complete so that the concentrations in any phase do not change with position within the reactor.

The dissolved oxygen in the tank is the same throughout the bulk liquid phase. Because of this uniformity of oxygen distribution in the reactor, a CSTR for wastewater treatment operations has the advantage of decoupling aerator or stirrer from the reaction as long as oxygen is well provided for (no need to consider pesky fluid mechanics), thus simplifying process design and optimization. Under the steady state, where all concentrations within the reactor are independent of time, we can apply the following materials balance on the reactor (Equation 1.31):

$$\left[ \begin{array}{c} \text{Rate of addition} \\ \text{to reactor} \end{array} \right] + \left[ \begin{array}{c} \text{Rate of accumulation} \\ \text{within reactor} \end{array} \right] = \left[ \begin{array}{c} \text{Rate of removal} \\ \text{from reactor} \end{array} \right]$$

Replacing the statements in the above expression with mathematical symbols leads to the following (Equation 1.32):

$$FC_{A0} + V_R r_A = FC_A \quad F(C_{A0} - C_A) = -V_R r_A$$

where  $F$  is volumetric flow rate of feed and effluent liquid streams.

Rearrangement of Equation 1.32 yields the following (Equation 1.33):

$$r_A = \frac{F}{V_R}(C_A - C_{A0}) = D(C_A - C_{A0})$$

where  $D = F/V_R$  and is called *dilution rate*. The term characterizes the holding time or processing rate of the reactor under steady state condition. It is the number of tankful volumes passing through the reactor tank per unit time and equal to the reciprocal of the mean holding time of the reactor.

Because of lack of time dependence of concentrations in CSTR and thus differential form of reactor analysis as in a batch reactor, CSTRs have the advantage of being well-defined, easily reproducible reactors and are used frequently in many cell growth kinetics studies, despite the relatively high cost and long time for achieving steady state. Batch reactors, which can be as simple as a sealed beaker or flask and used in large numbers simultaneously in an incubator shaker, are still widely used for their inexpensive, quick, and unbridled benefits. No matter what type of reactor is used, the goal of studying cell growth kinetics should be based on the intended application and scope of the use of the kinetics. Only then, the experimental design and implementation may be formulated.

## Process Economics

Process economics is the next step of a wastewater treatment and management design project after preliminary selections of wastewater treatment processes have been completed in accordance with the project objectives. The economical considerations of the wastewater treatment and management project, including aspects of material and energy recovery, are among the most important factors that influence the final decision of the project.

To develop meaningful cost estimates, the data from the wastewater characterization and other possible alternatives to the selected processes should be available. The cost estimates of the unit operations in wastewater treatment and management operations can be evaluated with the cost correlations developed by the EPA (1983). The cost correlations for alternative processes should also be gathered prior to the final estimation.

### ***Capital costs***

Capital costs usually refer to the process unit construction costs; the land costs; the costs of treatment equipment; financial costs in association with loan and services; costs of environmental impact or other community-imposed costs; and the costs of engineering, administration, and contingencies.

### ***Operational costs and facility maintenance***

There are several important factors that determine the operational costs: energy costs, labor costs, materials and chemical costs, costs of transportation of treated sludge and treated wastewater, and discharge costs.

The relative importance of these costs is highly dependent on locality and the quality of the influent and effluent of the wastewater treatment plant.

### **Further Reading**

Middlebrooks, E.J. 1979. *Industrial Pollution Control, Vol. 1: Agro-Industries*. New York: John Wiley & Sons.

### **References**

- Bauman, F.J. 1974. "Dichromat reflux chemical oxygen demand. A proposed method for chlorine correction in highly saline wastes," *Analytical Chemistry* 46:1336–1338.
- Eaton, Andrew D., Clesceri, Lenore S., Rice, Eugene W., Greenberg, Arnold E., and Mary Ann H. Franson, 2005. *Standard Methods for Examination of Water & Wastewater: Centennial Edition (Standard Methods for the Examination of Water and Wastewater)*, Washington D.C.: American Public Health Association.
- Liu, S.X., Hermanowicz, S.W., and M. Peng. 2003. "Nitrate removal from drinking water through the use of encapsulated microorganisms in alginate beads," *Environmental Technology*, 22:1129–1134.
- Magbunua, B. 2000. *An Assessment of the Recovery and Potential of Residuals and By-Products from the Food Processing and Institutional Food Sectors in Georgia*. Athens, GA: University of Georgia Engineering Outreach Services.
- Metcalf and Eddy, Inc. 2002. *Wastewater Engineering: Treatment and Reuse*, 4th edition. New York: McGraw-Hill Science/Engineering/Math.
- Middlebrooks, E.J. 1979. *Industrial Water Pollution Control*. New York: John Wiley & Sons.
- Peng, M., Vane, L.M., and S.X. Liu. 2003. "Recent Advances in VOC Removal from Water by Pervaporation," *Journal of Hazardous Materials* B98:69–90.



- Soderquist, M.R., Blanton, G.I., and D. W. Taylor. 1975. *Characterization of Fruit and Vegetable Processing Wastewaters*. Water Resources Research Institute, Oregon Agricultural Experiment Station Technical Paper No. 3388, Oregon State University.
- United States Environmental Protection Agency (USEPA). 1974. *Development Document for Effluent Limitations Guidelines and New Source Performance Standards for the Red Meat Processing Segment of the Meat Product and Rendering Processing Point Source Category*. Washington D.C.: USEPA.
- . 1983. *Construction Costs for Municipal Wastewater Treatment Plants: 1973–1982*. EPA Publication 430983004. Washington, D.C.: USEPA.

## 2


# BASIC MICROBIOLOGY IN WASTEWATER TREATMENT

---

### **Introduction**

Microorganisms have several critical functions in wastewater treatment processes. The microbial component of the aquatic ecosystem provides the purifying capacity of natural waters in which microorganisms respond to the rise of organic pollutant concentration by increased growth and metabolism. The self-regulated purification mechanism in natural waters subscribes to the same fundamental principles of biological pollutant abatement as those used in biological wastewater treatment processes. In addition to the abundant food for microorganisms, food and agricultural wastewaters also contain microorganisms themselves. With a controlled and suitable environment for optimal growth and metabolism of microorganisms, all the organic matters that exist in the wastewater streams can be biodegraded.

Microorganisms utilize organic materials for the production of energy by cellular respiration and for the synthesis of cellular material such as proteins for maintenance and production of new cells. The utilization of organic matters by microorganisms can be summarized with an equation of the overall reaction of wastewater treatment(Equation 2.1):



where P stands for phosphate.


In wastewater treatment, bacteria are the ones responsible for degradation of organic matters. Other microorganisms such as fungi, algae, protozoa, and higher organisms also contribute to the biotransformation of organic materials in wastewaters.

A basic understanding of the key biological organisms, microbial organisms or otherwise—bacteria, fungi, algae, protozoa, and metazoan (crustaceans)—is essential in development of strategies for food and agricultural wastewater treatment and utilization. With the exception of wastewater streams right off certain food processing operations such as retort, food and agricultural wastewater provides an ideal growth media where diverse communities of microorganisms can thrive. These organisms play an important role in all stages of biological wastewater treatment, and they also have some influences on sludge formulation and characteristics. It is without exaggeration to say that a biological wastewater treatment process could not even survive if not for the existence of mixed communities of ravenous microorganisms feeding on organic matters and each other. The exact compositions of these communities will depend on the outcome of competition of food supplies and environmental conditions such as pH and temperature. The information of microbial communities at each stage of biological wastewater treatment is important for designers and planners of food and agricultural wastewater management.

Although living things, as we know since our grammar-school days, are classified as in the plant kingdom or animal kingdom, microorganisms belong to a unique kingdom called *Protista*. Mixed communities of microorganisms have plantlike constituents such as algae and animallike inhabitants such as protozoa. These are simple life forms with various structures of their cells.

### **Structures of Cells**

Cell types include prokaryotes, which encompass all bacteria, and eukaryotes, which are cells in all living cells except bacteria and viruses. Bacterial cells are molecules surrounded by a semipermeable membrane and which in turn is covered by a porous cell wall. The protoplasm in the membrane contains nuclear material that is not bounded by any other material separating it from the protoplasm. Organelles are complex and well-defined internal structures surrounded by membranes. Characteristic organelles comprise cell nucleus, mitochondria, and ribosome. Fig. 2.1 shows a diagram of a cell structure of a bacterium.



**Figure 2.1.** A schematic diagram of a bacterial cell.

## Important Microorganisms in Wastewater

### *Bacteria and fungi*

Bacteria are the most important and the largest components of the microbial community in all biological wastewater treatment processes. Depending on the biological process and pH, the number concentration of bacteria is different, with activated sludge (aggregates of healthy aerobic bacteria living in colonial structures called flocs) having the largest number concentration of bacteria. Bacteria range in size from approximately 0.5 to 5  $\mu\text{m}$  and take one of four major shapes: sphere (cocci), straight rod, curved rod (vibrio), and spiral (spirilla). They appear singly, in pairs, in packets, or in chains. Bacteria are classified into two major groups: heterotroph (which use organic matters as both energy and carbon sources for synthesis) and autotroph (which use inorganic matters for energy source and  $\text{CO}_2$  for carbon source). The heterotrophs can be further subdivided into three categories: aerobic (using free oxygen for decomposing organic matters), anaerobic (using no free oxygen for decomposing organic matters), and facultative (thriving both in aerobic and in anaerobic environments).

Aerobic bacteria require free dissolved oxygen to decompose organic materials (Equation 2.2):




This microbial reaction is autocatalytic, meaning that the bacteria that function as catalysts are also produced by the reaction. Aerobic bacteria are predominant in biological wastewater treatment processes such as activated sludge and trickling filters and other biological processes that utilize free oxygen for their biochemistry. Aerobic bioconversion of organic matters is a biochemically efficient and rapid process that produces resulting products with highly oxidized compounds such as  $\text{CO}_2$  and water.

The metabolism of aerobic bacteria is much higher than that of anaerobic bacteria. This augmentation means that 90% fewer organisms for aerobic metabolism are needed compared to the anaerobic process, or that treatment is accomplished in 90% less time. This provides a number of advantages, including a higher percentage of organic removal. Aerobic bacteria living in flocs are kept in suspension by the mechanical action used to introduce oxygen into the wastewater. This mechanical action exposes the floc to the organic matters while biological treatment takes place. Following digestion, a gravity clarifier separates and settles out the floc.

Anaerobic bacteria live and reproduce in the absence of free oxygen. They utilize compounds such as sulfates and nitrates for energy, and their metabolism is substantially reduced. In order to remove a given amount of organic matters in an anaerobic environment, the organic matters must be exposed to a significantly higher quantity of bacteria and/or engaged for a much longer period of time. A representative use for anaerobic bacteria would be in a septic tank. The slower metabolism of anaerobic bacteria requires that the wastewater be held several days in order to achieve even a nominal 50% reduction in organic matters. The advantage of using the anaerobic process is that mechanical equipment is not required. Anaerobic bacteria release hydrogen sulfide as well as methane gas, both of which can create hazardous conditions. The following reactions represent the anaerobic transformation by anaerobes common in wastewater treatment (Equations 2.3 and 2.4):




which utilizes bounded oxygen in nitrate, or



which utilizes bounded oxygen in sulphate. Anaerobic bacterial activities are primarily founded in the digestion of sludge and wastewater lagoons. Anaerobic processes are normally biochemically inefficient and generally slow and produce complex end products some of which emit an obnoxious smell. In food and agricultural wastewater treatment, proteins are often degraded anaerobically into amino acids and CO<sub>2</sub> (like aerobic degradation), H<sub>2</sub>, alcohols, organic acids, methane, hydrogen sulphide, phenol, and indol.

Most of the bacteria that absorb the organic matters in a wastewater treatment system are facultative in nature. The nature of individual facultative bacteria is dependent upon the environment in which they live. Usually, facultative bacteria such as *E. coli* will be anaerobic unless there is some type of mechanical or biochemical process used to add oxygen to the wastewater. When bacteria are in the process of being transferred from one environment to the other, the metamorphosis from anaerobic to aerobic state (and vice versa) takes place within a couple of hours. Common bacteria found in biological wastewater treatment processes are listed in Table 2.1.

Using glucose as the organic substance and formula C<sub>5</sub>H<sub>7</sub>O<sub>2</sub>N to represent the composition of microorganisms, the basic organic bioconversion brought about by aerobes in biological wastewater treatment plants may be represented by the following (Equation 2.5):



Many studies on cell compositions have revealed that bacteria are composed of 80% water and 20% dry matter; approximately 90% of the dry matter in bacteria is organic. An approximate formula of C<sub>5</sub>H<sub>7</sub>O<sub>2</sub>N is often used in expressing the biochemical reaction; however, the formulation C<sub>60</sub>H<sub>87</sub>O<sub>23</sub>N<sub>12</sub>P may also be used when phosphorus is considered. The inorganic compounds in cells are about 50% phosphorus, 15% sulphur, 11% sodium, 9% calcium, 8% magnesium, 6% potassium, and 1% iron. All these inorganic elements are required for microbial growth, and since all of them are derived from the environment, shortage of any of

**Table 2.1.** Common organisms encountered in biological wastewater treatment (excluding flies).

Species	Genre	Process Involved
Achromobacter	Bacteria	Biofilters and activated sludge
Acinetobacter	Bacteria	Biological phosphorous removal
Alcaligenes	Bacteria	Biofilters, activated sludge, and sludge digester
Bloodworm	Metazoa	Biofilters and treated sludge
Chironomus	Metazoa	Stabilization ponds and sludge
Crustacea	Metazoa	Stabilization ponds and activated sludge
Daphnia	Metazoa	Activated sludge and ponds
Desulfovibrio	Bacteria	Sludge digesters
Flavobacterium	Bacteria	Activated sludge, biofilters, sludge digester
GAO	Bacteria	Biological phosphorus removal
Geotrichum	Fungus	Activated sludge and biofilters
Gordonia	Bacteria	Activated sludge
Micrococcus	Bacteria	Activated sludge and biofilters
Microtrix	Bacteria	Activated sludge
Nitrobacter	Bacteria	Nitrification
Nitrosomonas	Bacteria	Nitrification
PAO	Bacteria	Biological phosphorus removal
Pseudomonas	Bacteria	Denitrification
Rotifera	Metazoa	Activated sludge
Sphaerotilus natans	Bacteria	Activated sludge
Tubifex	Metazoa	Biofilters
Vorticella	Protozoa	All aerobic processes and ponds
Zoogloea ramigera	Bacteria	Activated sludge and biofilters

these elements would result in stunted growth or altering growth path. The pH of the environment is also important in microbial activities. Most bacteria cannot tolerate pH levels above 9.5 or below 4.0. The optimum pH value range of optimal growth for bacteria lies between 6.5 and 7.5.

Fungi are a group of microscopic nonphotosynthetic plants including yeasts and molds. Yeasts are widely used in the food industry for brewing and baking, and molds are filamentous fungi that bear a resemblance to

higher plants in structure with branched, fractallike growths. Fungi tend to compete disadvantageously with bacteria for nutrients, so their numbers are low except when the pH is low because the acidic condition favors growth of fungi. Fungi such as molds are nuisances in many biological wastewater processes because of their filamentous nature, which interferes with floc settling in flocculation and sedimentation basins.

The majority of filamentous organisms are bacteria, although some of them are classified as algae, fungi, or other life forms. There are a number of types of filamentous bacteria that proliferate in the activated sludge process. Filamentous organisms perform several different roles in the process, some of which are beneficial and some of which are detrimental. When filamentous organisms are in low concentrations in the process, they serve to strengthen the floc particles. This effect reduces the amount of shearing in the mechanical action of the aeration tank and allows the floc particles to increase in size. Larger floc particles are more readily settled in a clarifier. Larger floc particles settling in the clarifier also tend to accumulate smaller particulates (surface adsorption) as they settle, producing an even higher-quality effluent. Conversely, if the filamentous organisms reach too high a concentration, they can extend dramatically from the floc particles and tie one floc particle to another (*interfloc bridging*) or even form a filamentous mat of extra large size. Due to the increased surface area without a corresponding increase in mass, the activated sludge will not settle well. This results in less solids separation and may cause a washout of solid material from the system. In addition, air bubbles can become trapped in the mat and cause it to float, resulting in a floating scum mat. Due to the high surface area of the filamentous bacteria, once they reach an excess concentration, they can absorb a higher percentage of the organic matters and inhibit the growth of more desirable organisms.

### *Algae*

Algae are photosynthetic eukaryotes that inhabit all water bodies. There are only two situations where algae are involved in wastewater: trickling filters and stabilization ponds. Only stabilization ponds utilize algae to treat wastewater. The distinct feature of algae is that they use photosynthesis to produce energy via chlorophyll (which causes green color in green plants). The major group of algae is green algae that are found in aquatic environments. Blue-green algae are prokaryotes.



***Protozoa and metazoa***

In a wastewater treatment system, the next higher life form above bacteria is protozoa. These single-celled animals perform three significant roles in the activated sludge process: floc formation, cropping of bacteria, and removal of suspended material. Protozoa are also indicators of biomass health and effluent quality. Because protozoa are much larger in size than individual bacteria, identification and characterization is readily performed. Four major groups of protozoa have been identified: Mastigophora, Sarcodina, Sporozoz, and Ciliata. Ciliatae are the largest and most important protozoa in biological wastewater treatment, where they feed on bacteria and aid in both bioflocculation and clarification. Metazoans are very similar to protozoa except that they are usually multicelled animals. Macro-invertebrates such as nematodes and rotifers are typically found only in a well-developed biomass. The presence of protozoa and metazoans and the relative abundance of certain species can be a predictor of operational changes within a wastewater treatment plant. In this way, a wastewater treatment plant operator is able to make adjustments based on observations of changes in the protozoan and metazoan population in order to minimize negative operational effects.

***Role of microorganisms in biological wastewater treatment***

The role of microorganisms in wastewater treatment varies with the specific biological process and the environment the microorganisms are in. In the activated sludge process, which is operated often as a BOD reducer, the flocs that characterize the essence of the activated sludge process comprise microorganisms, organic matters, inorganic colloidal materials, and larger particulates. The structures of flocs provide certain advantages because they serve as not only colonies for BOD removal agents such as bacteria but also traps for soluble and insoluble BOD where they are readily hydrolyzed by extracellular enzymes prior to being absorbed and metabolized by microorganisms. Another important function for activated sludge is its significant role in promoting good settlement in the secondary sedimentation tanks or basins.

In trickling filters, the role of microorganisms in wastewater treatment is played out in the slime layer (called the *biofilm*) that adheres to the surface of the supporting media also known as the *filter media*. A trickling filter is a biological wastewater treatment system that consists of a circu-

lar bed of coarse stones and plastics that are continuously subject to a trickling flow of wastewater from an overhead, rotating distributor. The bacteria in the wastewater attach themselves to the bedding materials where the organic matters break down. Slime-producing bacteria, such as *Z. ramigera*, often initiate the formation of and the thickening of the biofilm. However, many other organisms contribute to further colonization of the biofilm of a multiple-layered structure with an outer layer of, often, fungi and the removal of BOD from the passing wastewater. This is, at least in terms of composition of the biomass of the biofilm, in contrast to that of activated sludge, where the existence and role of algae and fungi are insignificant. The design of trickling filters also exposes the process to limitations of mass transfers of  $O_2$ , soluble organic matters, and metabolized substances. This is a more severe issue when the thickness of the biofilm is considerable enough to affect the biodegradation of organic matters.

Anaerobic digestion is a slower biodegradation process of organic matters by anaerobic and facultative bacteria and is usually carried out in a continuously stirred tank reactor (CSTR) in order to suspend the insoluble organic materials. The reactor usually has a residence time of several days and is fed with a slurry of solids. The end products from the reactor usually are solids (a less amount than the feed),  $CO_2$ , and  $CH_4$ . Two groups of bacteria are involved; one group comprised of nonmethanogenic bacteria converts organic matters to simpler compounds such as organic acids, carbon dioxide, and hydrogen, and the second group, named methanogenic bacteria, transforms the metabolized products into methane. The interdependence between these two groups of bacteria fosters a delicate relationship that could be easily out of sync with some changes in general environmental parameters such as pH. The fragile alliance of the bacteria in these systems contributes to the difficulty in operations of anaerobic digesters.

The role of a wastewater stabilization pond, a condensed ecosystem of nature, on the other hand, is more complex, despite its simplistic appearance and operational logistics. It has diverse species of biota and incorporates several complete nutrient cycles: carbon, nitrogen, and sulphur. Depending on the primary purposes of the ponds, they can be divided into three basic groups: anaerobic, facultative, and maturation. The microorganisms inhabited in these communities vary considerably in terms of dominant species in the ponds. In general, the higher the BOD is, the lower the diversity of species in these ponds would be.

## **Microbial Metabolism**

### ***Microbial energy generation***

Microorganisms consume energy for their growth, reproduction, and maintenance (tasks such as motility, transport of materials in and out of the cell, and synthesis of new cell materials). The energy is derived from either physical source (light) or chemical source (breakdown of substrates). It is converted into biologically utilizable energy by microbial metabolism and stored inside the microorganism in a chemical form as a compound called adenosine 5'-triphosphate (ATP). It consists of an adenosine molecule that is linked to three inorganic phosphate molecules by phosphoryl bonds. These bonds are the energy source for microbial activities since the formation of these bonds requires a large amount of energy and the hydrolysis of the bonds releases energy that can be utilized microbiologically. The production of ATP is through the reaction between adenosine 5'-diphosphate (ADP) and inorganic phosphate resulting in a new phosphoryl bond in the ATP. Once the ATP is formed, it can be stored in the cell and used as needed by hydrolyzing the phosphoryl bond. Two types of phosphorylation reactions form ATP: substrate-level and oxidative. The substrate-level phosphorylation is particularly important for a certain bacterial growth that is devoid of free oxygen. The anaerobic microbes synthesize ATP exclusively with one of six inorganic phosphate compounds (substrates) in an enzymatic reaction. The other source of the microbial energy generation can be viewed as a biological redox half-reaction of NAD(P)H and NADH with nicotinamide adenine dinucleotide (NAD<sup>+</sup>) and its phosphorylated product of NADP<sup>+</sup> as acceptors for electrons. The oxidation of NADH and NAD(P)H releases energy to synthesize ATP. For example, oxidation of one mole of NAD(P)H helps yield three mole of ATP.

### ***Uptake of substrates into microbial cell***

Microbial growth requires the substrates in the wastewater to be brought inside the cell for utilization. Not all organic particulates or soluble solids can penetrate through the rigid, hydrophobic cell wall of a bacterium. Only small hydrophobic molecules can permeate the cell membrane unassisted. Some species of microorganisms have the ability to secrete enzymes outside the cell, hydrolyzing the larger molecules into smaller sol-

uble molecules that can enter the cell. Any form of close contact between substrates and the cells enhances the enzymatic breakdown, as in the cases in the trickling filters and activated sludge processes.

If the concentration of the substrate molecules is higher than the concentration across the cell wall and inside the cell, the small hydrophobic substrate molecules can permeate the cell wall of a microorganism via molecular diffusion mechanism. The mechanism of this diffusional mass transfer is similar to the mass transfer of molecules across a synthetic membrane. The majority of substrate transport, however, relies on a more active form of mass transfer that requires energy. As described previously, ATP contains energy-rich phosphoryl bonds that can be broken by hydrolysis and a large amount of energy released. Hence, ATP hydrolysis is an exergonic reaction. However, the release of energy from hydrolysis is not in the form of heat. It is rather used to drive the coupled biological reactions that need energy to complete (these reactions are called *endergonic reactions*). A portion of ATP energy is used for the active transport of substrates. This type of active mass transport of substrates requires a group of carrier enzymes called *permeases* (a word combining *permeate* and the suffix *ases* for enzymes). Permeases are substrate-selective, and therefore the uptakes of substrates in wastewater often are restricted by the amount of permeases present. The permease-assisted substrate transport overcomes the limit associated with the requirement of concentration gradient across the cell wall of molecular diffusion. It is not unusual to have internal substrate concentration inside the bacterial cell up to a thousandfold higher than the level in the wastewater. This is also the reason why the microorganisms can live in low-BOD environments such as rivers and oceans.

### ***Oxidation of organic and inorganic substrates***



Organic matters in wastewater are not directly oxidized to  $\text{CO}_2$  and  $\text{H}_2\text{O}$  because there is no energy conservation mechanism accommodating the release of large amounts of energy resulting from oxidations with  $\text{CO}_2$  and  $\text{H}_2\text{O}$  as the end products. Rather, they are oxidized in small steps. This typically involves transfer of an electron from the substrate being oxidized to some acceptor molecule that will be reduced as a result. The major electron acceptors (sometimes also called *hydrogen acceptors* due to the fact that for every electron removal there is a simultaneous loss of proton and the net result is loss of a hydrogen atom) in microbial cells are two carrier

molecules known as *pyridine nucleotides*: NAD and NADP. When they undergo redox reactions, the energy released from oxidation of NAD and NADP helps synthesize ATP. Microorganisms that obtain their reducing equivalents necessary for energy generation from oxidation of organic matters are called *organotrophs* (including *photoorganotrophs*, which derive energy from sunlight for photosynthesis and *chemoorganotrophs*, which generate energy from oxidation of organic compounds).


Many microorganisms are also able to oxidize inorganic materials. These microbes are termed *lithotrophs*. Bacteria that obtain their energy from the oxidation of inorganic compounds coupled with the energy release to ATP synthesis by means of electron transport chain are called *chemolithotrophs*. Those lithotrophs that derive their energy directly from sunlight are also known as *photolithotrophs*. There are many potential inorganic energy sources that include  $H_2$ ,  $NH_3$ , metal ions (e.g.,  $Fe^{2+}$ ), and sulphur for biochemical reactions in the wastewater treatment.

## Nitrification

Nitrification is a microbial process that converts ammonia into nitrite and ultimately into nitrate. Ammonia in wastewater comes primarily from two sources: intense use of nitrogen-rich fertilizers such as urea and organic nitrogen from proteins. The deamination of organic nitrogen and hydrolysis of urea under urease results in ammonia (Equations 2.6 and 2.7):



for oxidative deamination and




for reductive deamination (Equation 2.8).

Wastewaters from the fishery, meat, and poultry industries contain substantial amounts of proteins. By the time these proteins reach the collection facilities of the wastewater treatment plants, most of them have been converted into peptides and amino acids by extracellular proteolytic enzymes and ultimately into ammonia.


In nitrogen-rich wastewater streams, only a small amount of the nitrogen is removed from wastewater through conventional heterotrophic activity by incorporating nitrogen into the microbial biomass. There is a parallel in phosphorus-rich wastewaters. If left untreated, the nitrogen or/and phosphorus in discharged effluents will cause eutrophication (a form of photo-autotrophic activity) of the receiving waters, which will gravely disrupt the aquatic ecosystem.

The nitrification process in biological wastewater treatment, i.e., the use of a limited group of autotrophic nitrifying bacteria to convert ammonia into nitrite and eventually nitrate, is often used in the so-called advanced phase of a wastewater treatment scheme if the concentration of ammonia in wastewater streams is high enough to warrant the treatment. Nitrification is a two-step process: (a) ammonia is first converted into nitrite by a group of bacteria called *Nitrosomonas* and (b) further conversion of nitrite leads to nitrate by another group of bacteria named *Nitrobacter*. Other genera may also be involved in the nitrification process; for example, *Nitrospira*, *Nitrococcus*, *Nitrosogloea*, and *Nitrosocystis* have been identified to participate in oxidizing ammonia in nitrification (Belsler, 1979). Most nitrifying bacteria are autotrophic and utilize carbon dioxide as the carbon source. For oxidation of ammonia, the biochemical reaction is expressed as the following (Equation 2.9);



Here again, we use  $\text{C}_5\text{H}_7\text{O}_2\text{N}$  to represent the composition of microorganisms.

For oxidation of nitrite, the reaction expression is written as the following (Equation 2.10):



These equations allow the amount of chemicals required for the processes to be calculated.

The growth of nitrifying bacteria is represented by Monod Kinetics (Equation 2.11):

$$\mu = \frac{\mu_m \cdot S}{k_s + S}$$

**Table 2.2.** Common values for various Monod kinetic constants applicable to the nitrification process (Hultman, 1973).

Monod Kinetic Constant	Value
$\mu_{mNS}$ , 20°C, (pH) optimum	0.3–0.5 day <sup>-1</sup>
$k_s$	0.5–2.0 mg/l
$Y_{NS}$	$\cong 0.05$ mg VSS/mg [NH <sub>4</sub> <sup>+</sup> – N]
(pH) optimum	8.0–8.4

where  $\mu$  is the specific growth rate of the nitrifying bacteria,  $\mu_m$  is the maximum specific growth rate,  $k_s$  is the saturation constant, and  $S$  is the residual concentration of the growth-limited nutrient.

In the two-step nitrification process, conversion of ammonia into nitrite is the limiting reaction; thus, it is more convenient to model nitrification on the ammonia-nitrite step, i.e., on the specific growth rate of *Nitrosomonas*,  $\mu_{NS}$  (Equation 2.12):

$$\mu_{NS} = \mu_{mNS} \frac{[NH_4 - N]}{k_s + [NH_4 - N]}$$


where  $[NH_4 - N]$  is the ammonia concentration expressed in terms of nitrogen in wastewater in the reactor. The data for  $k_s$  of NH<sub>4</sub>, the maximum specific growth rate,  $\mu_{mNS}$ , and yield in nitrification can be found in Table 2.2 (Hultman, 1973). Once the observed yield constants for NH<sub>4</sub><sup>-</sup> and NO<sub>2</sub><sup>-</sup> conversions are known, various calculations can be done with Equations 2.9 and 2.10.

## Denitrification

Denitrification can be viewed in some ways as a reversal of nitrification; however, although the denitrification does go through a two-step biochemical transformation, the end product of the denitrification is not ammonia or organic nitrogen; rather, it is inert gaseous nitrogen (Liu et al., 2003).

Denitrification can only be operated under anoxic conditions when the free oxygen level is very low, but not necessarily zero, and when a carbon source, such as methanol or settled sewer (which has low dissolved oxygen), is available. The biochemical reaction characterizing the denitrification process is brought about by a wide range of bacterial genera, mostly facultative anaerobes such as *Pseudomonas* (*P. fluorescens*, *P. aeruginosa*, *P. denitrificans*) and *Alcaligenes*, with *Achromobacterium*, *Denitrobacillus*, *Spirillum*, *Micrococcus*, and *Xanthomonas* often present in wastewater streams (Painter, 1970; Tiedje, 1988).

The overall stoichiometric equation for denitrification using methanol as the carbon source is the following (Equation 2.13) (McCarty et al., 1969):



The maximum specific growth rate of nitrifying bacteria or denitrifiers ( $\mu_m$ ) is affected by nitrate and methanol concentrations, temperature, and pH. The growth rate of denitrifiers,  $\mu_D$  is represented as a double Monod expression (Equation 2.14):

$$\mu_D = \mu_m \cdot \left( \frac{D}{k_D + D} \right) \left( \frac{M}{k_m + D} \right)$$

where  $D$  is the nitrate concentration (mg/l),  $k_D$  is the half-saturation constant for nitrate (mg/l),  $k_m$  is the half-saturation constant for methanol (mg/l), and  $M$  is the methanol concentration (mg/l). Denitrification rate is related to the growth rate of denitrifiers as the following (Equation 2.15):

$$q_D = \frac{\mu_D}{Y_D}$$

where  $q_D$  is the nitrate removal rate (mg  $\text{NO}_3\text{-N}$  mg  $\text{VSS}^{-1}\text{d}^{-1}$ ) and  $Y_D$  is the yield (mg  $\text{VSS}$  per mg  $\text{NO}_3\text{-N}$  removed). Table 2.3 lists some values of the constants in Equation 2.14.



**Table 2.3.** Common values for various Monod kinetic constants applicable to the denitrification process (adapted from Henze et al., 2001).

Monod Kinetic Constant	Value
$\mu_m$ , 20°C, organic matter	3–6 day <sup>-1</sup>
$\mu_m$ , 20°C, methanol	5–10 day <sup>-1</sup>
$k_s$ , MeOH	5–10 COD mg/l
$k_s$ , COD	10–20 COD mg/l
$k_s$ , NO <sub>3</sub>	0.1–0.5 O <sub>2</sub> mg/l
$Y_{MeOH}$	0.5–0.65 mg COD/mg COD
$Y_{COD}$	1.6–1.8 mg COD/mg NO <sub>3</sub> <sup>-</sup> -N

### Further Reading

- Grady, C.P.L. and H.C. Lim. 1980. *Biological Wastewater Treatment: Theory and Applications*. New York: Marcel Dekker.
- Barnes, D. and P.J. Bliss. 1983. *Biological Control of Nitrogen in Wastewater Treatment*. London: Spon.

### References

- Belser, L.W. 1979. "Population ecology of nitrifying bacteria." *Annual Reviews of Microbiology* 33: 309–333.
- Henze, M., Harremose, P., Jansen, J.L.C., and Arvin, E. 2001. *Wastewater Treatment: Biological and Chemical Processes*, 3rd edition. Berlin: Springer.
- Hultman, B. 1973. "Biological nitrogen reduction studies as a general microbiological engineering process." In *Environmental Engineering*, Linder, G. and Nuberg, K., eds. Holland: D. Reidel.
- Liu, S.X., Hermanowicz, S.W., and Peng, M. 2003. "Nitrate removal from drinking water through the use of encapsulated microorganisms in alginate beads." *Environmental Technology* 22:1129–1134.
- McCarty, P.L., Beck, L., and St. Amant, P. 1969. "Biological denitrification of wastewaters by addition of organic materials." In *Proceedings of the 24th Industrial Waste Conference*. Purdue University, PP1271–1285.
- Painter, H.A. 1970. "A review of the literature on inorganic nitrogen metabolism." *Water Research* 4: 393–450.
- Tiedje, J.M. 1988. "Ecology of denitrification and dissimilatory nitrate reduction to ammonium." p. 179–244. In *Environmental Microbiology of Anaerobes*, Zehnder, A.J.B., ed. New York: John Wiley & Sons.


3

## PHYSICOCHEMICAL WASTEWATER TREATMENT PROCESSES

---

### **Introduction**

Physicochemical processes of wastewater treatment are most evident in the primary treatment facilities of a wastewater treatment plant. The adjective, *primary* may have had its undisputed claim on preeminence in the majority of wastewater treatment plants; this is no longer the case, because the environmental regulations and discharge standards of wastewater effluents tighten in many developed nations. Nevertheless, primary treatments in many wastewater treatment facilities in the U.S. or elsewhere are the most common wastewater treatment processes and contain many forms of physicochemical processing that may be categorized into a small number of basic operations called unit operations. Physicochemical processes in the primary treatment of food and agricultural wastewater generally comprise a set of unit operations that are intended to remove particulates and other coarse materials from the wastewater stream prior to the secondary treatment processes (mostly biological processes). The removed solids are fed into either aerobic digesters or anaerobic digesters for further volume reduction (Fig. 3.1). In primary treatment, only physicochemical processes are used to separate suspended solids and greases from wastewater. Primary treatment of food and agricultural wastewater usually include screening, flotation, flocculation, sedimentation, and sometimes, granular sand filtration. In a typical wastewater treatment facility for a food processing plant, wastewater is normally held in a tank for several hours, allowing the particles to settle to the bottom and the greases to float to the top. The solids drawn off the bottom and skimmed off the top receive further treatment as sludge. The clarified wastewater flows on to the next stage of wastewater treatment. The exact lineup and sequence of unit op-



**Figure 3.1.** A flow chart of a typical wastewater treatment scheme.

erations largely depend on the characteristics of wastewater streams, objectives of treatment, and local environmental laws and regulations.

### **Equalization Basins**


Generally speaking, flow equalization is not a treatment process or treatment method; it's a method to improve wastewater treatment processes, whether they are physicochemical processes or biological processes. The purpose of flow equalization is to balance out the process parameters, such as flow rate, organic loading, strength of wastewater streams, pH, and temperature over a 24-hour period. This practice is often applied either at the very beginning of the wastewater treatment plant—aiming at minimizing or controlling fluctuations in wastewater characteristics in order to provide optimum conditions for the subsequent treatment processes in the plant—or at the point right before discharging of effluent. For the former, the target is often focused on toxicity of the influent; the latter is squared at maintaining a predetermined discharging volume.

Flow equalization usually involves construction of large basins to collect and hold wastewater streams, from which the wastewater is pumped to treatment facilities at a constant rate. These basins usually are located after pretreatment facilities such as screens, comminutors, and grit chambers. In the case of industrial wastewater discharging into a municipal wastewater treatment plant, the location of the basins should be placed in the industrial site before discharging to smooth flow rate and characteristics of the industrial wastewater stream. Mixing is usually provided to ensure adequate equalization in basins and prevent depositing of solids on

the bottom of the basins. Additionally, these basins also provide some treatment functions by oxidizing the reduced compounds in the wastewater and reducing BOD through air stripping. The mixing may be achieved by a number of ways: distribution of inlet flow or baffling, turbine mixing, diffused air aeration, and mechanical aeration.

The basic types of flow equalization systems may be categorized as follows:

- *Alternating flow diversion* (see Fig 3.2a). The system alternates filling and discharging one of two flow equalization basins for consecutive time periods. The advantages of this system are constant flow rate and constant pollutant level in the discharging effluent to the treatment facilities. The disadvantage of the system is the high cost of construction, because a large capacity of basins is needed to hold incoming wastewater streams one basin at a time.
- *Intermittent flow diversion* (see Fig 3.2b). The basin is used to divert significant variance in wastewater flow when needed; the diverted stream can be added back to the wastewater stream before it enters the treatment facilities. The diversion tends to run on short time periods.
- *Completely mixed, combined flow* (see Fig 3.2c). This system completely mixes several incoming wastewater streams at the front end of the treatment facilities in a mixing basin in order to level out the variances among the streams. This system works well if the flows are rela-



**Figure 3.2.** (a) Alternating flow diversion equalization system; (b) intermittent flow diversion system; (c) completely mixed, combined flow system; (d) completely mixed, fixed flow system.

tively compatible, because any large variance in parameters will create a shock load to the treatment facilities.

- *Completely mixed, fixed flow* (see Fig. 3.2d). The difference between this system and the completely mixed, combined flow system is that there is a large holding basin that not only completely mixes the incoming wastewater streams but also equalizes the flow parameters in the basin before the effluent of the basin goes into the treatment facilities, thus providing a constant wastewater effluent with relatively constant flow parameters.

Design of the equalization facility should begin with the investigation of characteristics of the wastewater and its variability. A detailed analysis of the pollutants in the stream and flow data collection are a must in order to gain an appreciation of the effect of the nature of the wastewater on downstream wastewater treatment. Several flow parameters are the most important to be included in a detailed study of the nature and variability of the wastewater stream: mass flow rate, BOD<sub>5</sub>, TSS, TOC, etc. The data gathered from the study of the wastewater stream tends to be time-series, and a statistical analysis is needed to determine the effect of variability on the data of the parameters.

Equalization basins may be designed to achieve flow equalization, concentration of pollutants, or both. For flow equalization, a plot of the cumulative flow volume versus time over 24 hours is compared to the straight line of the average daily flow rate on the same diagram. The equalization volume required is the vertical distance from the point of tangency to the straight line representing the average flow rate multiplying by a safety factor (e.g., 110%). If the cumulative inflow rate curve goes beyond the line of the average daily flow rate, draw two straight lines that bound the cumulative inflow rate curve and are parallel to the average daily rate line. The equalization volume is the distance between the two straight lines that are tangent to the extremities of the curve.

## Screening

Wastewater from food processing or postharvest processing may contain debris, either suspended or floating on the surface. These coarse solids have to be removed at the very beginning of the wastewater treatment regimen. Screening of debris is sometimes considered as a “preliminary” treatment,



**Figure 3.3.** A photo of an inclined screen.

not part of primary treatment of wastewater; however, the distinction is more semantics than anything else. Screening can be effective in the food industry to quickly and cheaply reduce the amount of relatively large solids (0.7 mm or larger) in the wastewater. The simplest type of screen is an inclined flow-through type of static screen with openings of about 1.5 mm to 6 mm for fine screens and 6 mm or larger for coarse screens (Fig.3.3). (There are also very fine screens with openings of 0.2 to 1.5 mm placed after the coarse or fine screens, which can reduce suspended solids to levels near those achieved by primary clarification/sedimentation.) In some




Figure 3.4. A schematic diagram of a vacuum drum screen.

cases, some sort of scrapping mechanism has to be implemented to avoid clogging of the screens.

Rotary drum screens may also be used in removing coarse solids from food and agricultural wastewater. They are composed of a drum that rotates along its axis, and the effluent enters through an opening at one end. Screened wastewater exits from the other end. The retained solids are washed out from the screen into a collector in the upper section of the drum by a spray of the wastewater (Fig. 3.4).

The screening media used in screens are generally of stainless steel with opening ranging from 0.7 mm to 1.5 mm. Some of the screening elements may consist of parallel bars or rods (this type of screen is called a *bar rack*), wires, grating, wire mesh, or perforated plates. Bar racks are used to protect pumps, valves, pipes, and other devices from damages and clogging by large objects in the wastewater stream. Some bar racks are equipped with a mechanical scrapping accessory to clean the screen.

## Flotation

Flotation is a physical process of removing not only oil and grease, but also fine and light suspended particulates from wastewater. Flotation has particular appeal to food wastewater treatment because this source of wastewater contains a substantial amount of oil/grease floating on the surface. The particulates in wastewater that do not settle well and take too much time for settling are also good candidates for flotation treatment. Flotation is achieved by introducing gas (usually air) in the wastewater stream through either pressure-dissolved air in the feed or direct air diffusers or vacuum. The air bubbles attach themselves to the particulates causing the particulates and oil/grease to aggregate and rise to the surface where the particulates are removed by mechanical skimmers. For oil and grease removal, the emulsified oil and grease in wastewater present a problem for utilization of flotation technology. It is critical to break up the emulsion before applying flotation to the wastewater. Adjustment of pH value, heat, and additions of chemicals are used to destabilize the emulsion. Dissolved air flotation (DAF) is commonly used in food wastewater treatment. The wastewater feedstock is first pressured with air in a closed tank, and after the wastewater is discharged into a tube in the center of the DAF tank, the air bubbles carry the solids in the wastewater to the surface where they are skimmed by skimmers and moved to a discharge trough where they are collected. Treated water exits from the lower sections of the DAF through the riser tubes. Heavy solids that do not float settle to the bottom where a bottom skimmer moves them to a discharge point for removal. Flotation is also used to concentrate sludge from biological processes. Flocculants (see the section “Coagulation and Flocculation” below) of inorganic ( $\text{FeCl}_2$ ,  $\text{FeSO}_4$ , or  $\text{AlSO}_4$ ) and organic (carrageenan, chitosan, and lignosulfonic acid, or their derivatives) as well as polymeric (polyacrylamides) nature sometimes are added to aid flotation operations. As a food wastewater treatment strategy, flotation (DAF in particular) has its own advantages and disadvantages. The following are the advantages:

- Reduces oil, grease, and suspended particulates
- Reduces suspended solids and settling solids if equipped with a bottom sweep
- Does not require excessive maintenance or management



Disadvantages include the following:

- Does not remove the BODs associated with soluble materials
- Disposes and/or treats floats
- Capital and operating costs could be high

In a DAF system, wastewater is first mixed with flocculants and pressurized to a pressure of several atmospheres, followed by the release of pressure to the atmosphere level by a valve. As the minute bubbles in the order of  $50 \times 100$  microns resulting from depressurization rise to the surface, the particles, oil, or grease adhere to the air bubbles to be carried upward. A mechanical skimmer on the top then removes the float. A bottom sweep is sometimes employed to stir up settleable particulates to aid flotation operation (see Fig. 3.5). For larger flotation systems, a portion of the effluent from the DAF system is recycled (at least 10%) and mixed with the fresh feed of the DAF system.

The oil, grease, and suspended particulates removed by the DAF system are concentrated in the float and must be used or disposed of properly to avoid pollution. DAF float can be disposed of by

- Applying it to land (A permit is required.) See also Chapter 7 regarding land applications.
- Depositing it in a landfill. (This practice is banned in some states.) Regulations usually require that the material be easily handled by the machinery in the landfill.
- Using as ingredients for animal feeds. But, the flocculants used must be approved by the FDA, and the float often contains too much liquid for most direct feeding applications or for uses as ingredients for animal feed manufacturing (high energy cost for drying).
- Mixing with sludge for further treatment.

## **Sedimentation**

Sedimentation is the most common physical unit operation in wastewater treatment, more so in primary treatment where sedimentation is the workhorse of the treatment. The term *sedimentation* is also called settling in some literature. Sedimentation is, in a nutshell, a process by which the suspended solids, which have higher densities than that of water, are re-



**Figure 3.5.** A photo of a dissolved air flotation system.

moved from wastewater by the action of gravity in the bottom of the settling tank or basin (also called a *clarifier*) within a reasonable period of time. Sedimentation basins are usually rectangular or circular with a radial or upward water flow pattern. Sedimentation is not limited to primary treatment; there is also secondary sedimentation by which settleable solids in the biological secondary treatment processes are removed. For example, recovery of activated sludge for recycling is achieved with secondary sedimentation.

In a typical wastewater treatment plant, the wastewater stream exiting from screening devices (and after flotation basins) then enters the second section of the primary treatment of wastewater treatment or sedimentation tanks/basins. Here, the sludge (the organic portion of the sewage) settles out of the wastewater and is pumped out of the tanks. Some of the water is removed in a step called *thickening* and then the sludge is processed in large tanks called *digesters*.

Sedimentation uses gravitational force to separate unstable and destabilized suspended solids from wastewater. It is based on the density differ-

ence between the bulk of the liquid and the solids. Stabilized solids such as colloids can be destabilized with flocculants (see the section “Coagulation and Flocculation” below). Sedimentation is a very important primary treatment process; it is, however, also used in the biological treatment, such as activated sludge and trickling filters for solid removal. The settling characteristics of the solids are determined by the types of the settling solids and their concentrations. Sedimentation has four distinct types of settling:


- Discrete settling (Type I), which is settling of a dilute suspension of solids that do not aggregate.
- Flocculent settling (Type II), which is settling of the particulates that aggregate among themselves and/or with added flocculants to form larger particulates and therefore results in faster settling. The sedimentation operation in a typical primary treatment of wastewater operates in this mode.
- Zone settling (Type III, also called *hindered settling*), which occurs when particulates adhere together, forming a mass that settles as a blanket with a distinguishable interface with the liquid above it.
- Compression zone (Type IV), which occurs when sinking particulates accumulate at the bottom of the sedimentation tank/basin, forming a compressed structure that supports the weight of the particulates that settled in the bottom of the tank/basin.

Although sedimentation basins in primary treatment are characterized by Type II flocculant settling, each of these zones have different characteristics that warrant further analysis.

### ***Discrete settling (Type I)***

The settling of nonaggregated solids in a dilute suspension can be described by its settling velocity of individual particulates. In a settling tank/basin, the settling of a discrete particle is not affected by the other particles and is only a function of the fluid property and the characteristics of the particle; this may be further depicted in Fig. 3.6 when the movement of the particle of interest is subject to the combined effect of the gravitational force downward and the bulk flow toward the outlet (Equation 3.1):

$$v_t = (\text{tank depth})/(\text{residence time})$$



**Figure 3.6.** A schematic diagram of discrete settling.

or mathematically (Equation 3.2):

$$v_t = H/t$$

$H$  is the depth of the sedimentation tank and  $t$  is the residence time of the particle in the liquid in the tank. If we assume the residence time of the liquid is the residence time of the liquid in the tank, then it is the following (Equation 3.3):

$$t = HA/Q$$

$A$  is the cross-sectional area of the tank and  $Q$  is the overall volumetric flow rate through the tank. Here,  $Q/A$  is the overflow rate of the liquid passing through the tank. So, we have the following (Equation 3.4):

$$v_t = Q/A$$

The terminal velocity of the particle is equal to the overflow rate of the tank.

For readers who have some exposure to fluid mechanics, the above derivation might strike them as being suspicious, since the terminal velocity of a discrete particle in the liquid follows Stoke's law (Equation 3.5):

$$v_t = [g(\rho_s - \rho_l)d^2]/18\mu$$

where  $d$  is the size (equivalent diameter of the particle),  $g$  is the gravitational acceleration,  $\mu$  is the viscosity of the liquid, and  $(\rho_s - \rho_l)$  is the density difference between the particle and the liquid.

This suggests that the terminal velocity is a function of size and the density of the particle, which is nowhere to be inferred from Equations 3.2–3.4. Note that we have assumed that the residence time of the particle in the tank is the same as that of the bulk liquid or the equivalent depth for the particle settling in the tank is the same as the depth of the tank. The overflow rate of the tank as the terminal velocity of a particle in the tank represents the critical velocity of an ideal particle in an ideal settling tank assuming


- The number of ideal discrete particles and the velocity vectors of the liquid are uniformly distributed.
- The liquid flows in the tank as an ideal slug.
- Any particle reaching the bottom of the tank is effectively removed (no resuspension) (Canale and Borchardt, 1972)

Any ideal particles having terminal velocity  $v$  (average velocity among all particles present) greater than  $v_t$  is 100% removed from the settling tank/basin. For those particles with less than  $v_t$  average terminal velocity, the portion of the particles removed in the tank is equal to  $v/v_t$ .

In reality, the discrete settling is more likely associated with settling of hard particulates with high density and size such as grit and sand. This is a rare type of particulate in a typical food wastewater stream, but it may occur in some sources of agricultural wastewater that is subject to intrusion of soil and dirt.

### ***Flocculent settling (Type II)***

Flocculent settling is used in primary clarifiers and the upper zones of secondary clarifiers. In the case of flocculent settling, the particles in the relatively dilute suspension coalesce or flocculate to form larger particles or aggregates during settling, thus increasing the mass of settling solids as well as the settling velocity (and removal rate). In many food wastewater treatment situations, except very dilute ones, suspended solids cannot be described as discrete particles of known specific gravity (a quantity that is the ratio of density of particle to density of water). In general, larger particles settle faster and have a greater tendency to collide with other slower-settling particles, resulting in formation of larger particles in a quiescent body of water. However, the wind, hydrodynamic shear, and hydraulic disturbance all contribute to further contacts among particles in the tank.



**Figure 3.7.** A diagram of settling column and zoning settling process.

Furthermore, the greater the depth of the tank, the higher the frequency of collisions among particles will be during settling. Therefore, the flocculent settling is dependent on the properties of particles and the liquid as well as depth of the settling tank/basin. The settled solids in the bottom of the tank are usually promptly removed, so the greater rate of settling as a result of aggregation of individual particles translates into a greater rate of solid removal from the wastewater. Evaluation of a wastewater stream slated for a sedimentation tank or basin is carried out using a settling column, as depicted in Fig. 3.7. The laboratory of the settling column is about 15 cm (6 in) in diameter and 305 cm (10 ft) tall, and it has several sampling ports 61 cm (2 ft) apart. The settling evaluation is conducted by first placing a known quantity of wastewater sample in the column. The uniformity of particle size from top to bottom of the column in the beginning of the evaluation and the temperature of the liquid throughout the evaluation should be accomplished. The wastewater containing suspended solids is allowed to settle under quiescent conditions; small samples of suspension at different ports with preset depths are drawn and concentrations of particles in the samples are determined over preset time intervals. The frac-




Figure 3.8. A fraction of removal of flocculating particles at each depth.

tion removal of the particles is calculated for each sample analyzed and is plotted against time and depth. The fraction of the particles removed at each depth is constructed as curve lines called *isoconcentration lines*, as those illustrated in Fig. 3.8. These lines represent the most efficient particle removal loci for a given removal rate. The ratio of the depth to time is the average settling (terminal) velocity of the particles under a given percent removal.

**Zone settling (Type III)**

Zone settling, also called *hindered settling*, acquires its name from the fact that aggregated particulates of a concentrated suspension (activated sludge or flocculated colloids) in the sedimentation basin tend to form a massive blanketlike suspension with a distinct interface. Zone settling is mainly used in secondary clarifiers. Many wastewater treatment process designers use a batch settling test to determine the interface.

### Compression zone (Type IV)

Compression settling involves the highest concentration of suspended solids and occurs in the lower reaches of clarifiers. The particles settle by compressing the mass of the particles below. Compression occurs not only in the lower zones of secondary clarifiers but also in sludge thickening tanks.

### Coagulation and Flocculation

Many substances in wastewater vary greatly in size, from a few angstroms for soluble solids to a few hundred microns of suspended materials. Consider a force balance upon a clay particle with diameter of 1 micron; in the absence of electrostatic forces, the terminal settling velocity of this particle in water is approximately  $10^{-4}$  cm/s based on the following expression (Equation 3.6):

$$v = \frac{d^2 g (\rho_s - \rho_f)}{18\mu}$$

where  $(\rho_s - \rho_f)$  is the density difference between the particle and fluid (water), and  $\mu$  is the viscosity of the fluid (water). This is obviously too low for any practical sedimentation process. To remove a large portion of these substances from wastewater by sedimentation or filtration, smaller particulates need to be aggregated into large and more readily settleable or filterable particles. This process of forming aggregates from smaller particulates is called *coagulation*. Many unsettleable small particulates are colloids that can exist stably in water under favorable conditions. The objective of coagulation is to destabilize the colloidal dispersion in wastewater by using either chemical/polymer agents or hydrodynamic forces. The aggregation of colloidal particulates can be visualized as a two-step process: particle contacts/collisions brought up by hydrodynamic forces and particle destabilization to allow attachment of particles when collided.

There are two terms describing aggregations of colloidal particles: *coagulation* and *flocculation*. Depending on the industry that employs the unit operation, they may mean different things or they are synonymous. In environmental engineering, particularly a wastewater treatment field, flocculation refers specifically to destabilization of colloidal particles by



forming aggregates of colloids with added water-soluble polymers (polymer bridges); coagulation is caused by destabilization of colloids through compression of electrical double layers of the particles. However, this review is not universally shared. Some experts refer to the initial step of adding chemicals (coagulants or flocculants) to the wastewater in an intensely stirred tank as *coagulation* and subsequent slow stirring of the destabilized colloidal suspension in another tank to promote floc growth as *flocculation*.

The conventional practice of initial rapid mixing followed by slow stirring of coagulation-flocculation intends to maximize the extent of the formation of aggregates of colloids; this does not always have desirable outcomes. The slow stirring of the later stage of flocculation produces many large, fluffy flocs with high interstitial water; although these large flocs are settleable, they could severely strain the operation of dewatering of sludge and ultimately result in large amounts of sludge destined for landfill (Liu, 1995). Glasgow and Liu (1995) proposed a scheme of coagulation-flocculation that involves slow stirring interspersed with short bursts of highly intensive mixing in a flocculator in order to produce flocs with more compact structures.

Many food wastewaters contain large amounts of organic materials, such as proteins that are of colloids in nature; they tend to be charged, a result of ionization of carboxyl and amino groups or their constituent amino acids and therefore stabilizing in the streams. Other organic substances, also common in some wastewaters, may contain grease and oil and become charged due to adsorption of anions such as hydroxyl ions. Destabilization of the colloidal suspension containing these charged colloids requires overcoming the zeta ( $\zeta$ ) potential of the colloid dispersion in order to form aggregates. Zeta potential refers to the electrostatic potential generated by the accumulation of ions at the surface of the colloidal particle that is organized into an electrical double-layer consisting of the immovable Stern layer and the diffuse layer. The usefulness of the vaunted zeta potential as a process parameter is questionable in real-world situations because it varies with the composition of the suspension and is hardly repeatable.

Destabilization of colloids can be achieved through addition of chemical agents, including charged or nonionic water-soluble polymers. Depending on the conditions under which the agents are used and the characteristics of the agents, destabilization of colloids in water may be achieved through one or more of four distinct methods: (1) compression

of the diffuse layer of the electric double layer, (2) adsorption of agents to produce charge neutralization, (3) enmeshment of colloids in a precipitate, and (4) adsorption of polymeric agents to allow interparticle bridging. The electric double layer is the result of dynamic charge equilibrium between the particle and water, resulting in a zero net electrical charge in the colloidal dispersion (particles plus water). The double layer consists of the charged particles and counterions in water that are attracted to the charges on the particles. The concentrations of counterions near the particles are determined by not only the charges on the particles but also the diffusional force due to the concentration gradient in water. The result is a concentration distribution of counterions near the charged particle with the highest concentration of counterions near the particle surface, decreasing gradually with increasing distance from the particle surface. When concentration of counterions is low, the electric double layer is extended (because large volume of the diffuse layer is needed in order to maintain the electrical neutrality of colloidal dispersion). Destabilization of colloidal dispersion by adding counterions in the form of chemical agents is achieved by reducing the volume of the diffuse layer needed in order to maintain electrical neutrality of the colloidal dispersion. The compression of the double layer enhances the likelihood of aggregation among colliding particles because the attractive forces (van der Waals forces) between particles are short-distance forces and operate only during collisions or near misses.

Adsorption of counterions on particles to neutralize the charges on the surface eliminates electrostatic repulsions among colloids making aggregation possible.

Enmeshment of colloids in wastewater is mainly attributed to precipitation of the insoluble  $\text{Fe}(\text{OH})_3$  or  $\text{Al}(\text{OH})_3$  when common coagulants,  $\text{FeCl}_3$  or  $\text{AlCl}_3$ , are added into wastewater under alkaline conditions.

When water-soluble polymers are used for destabilizing colloidal dispersion, the mechanism of destabilization is not of charge neutralization because the most effective polymeric coagulants are the anionic polymers—even the majority of colloids are negatively charged. The bridging theory stipulates that the chemical groups of the polymer chains bond to the sites of colloidal particulates forming particle-polymer-particle aggregates (hence the name *bridging* in reference to the mechanism). Many common polymers used for wastewater treatment are classified as polyelectrolytes because they contain ionizable groups such as carboxyl, amino, and sulfonic groups; polyelectrolytes can be positive, negative, or


ampholytic (with both positive and negative groups), which can be prepared from acidic and basic vinyl monomers, from sulfobetaine monomers, from ion-pair co-monomers, or from charged anionic and cationic monomers mixed in varying proportions.

Flocculation is not limited to colloids destabilized by coagulant chemicals and polymers. Aggregation of microorganisms is common in biological wastewater treatment plants. It is evident that natural polymers either excreted by microorganisms or exposed at the surface of the microbial cells are responsible for enabling the bioflocculation. These natural polymers are also responsible for destabilizing organic colloids in wastewater. It has been demonstrated that synthetic polymers can also destabilize the microorganism suspension causing it to aggregate.

The selection of the optimum type and dosage of coagulant can be made only after judicious experiments with wastewater samples. Many substances can be used as coagulants. For food wastewater containing high proteinaceous substances, it is sometimes required to adjust pH by adding acids or alkali. For protein-rich wastewater, coagulation of the proteins can be started with denaturing. Denaturing is a process of changing structural conformation of proteins under heat or shear or chemical addition. The downside with denaturing as a way of coagulation of proteins is high cost associated with energy requirement; it is cheaper to use chemical agents as coagulants. If the recovered sludge from coagulation-flocculation treatment is to be used for animal feeds, the toxicity of chemical agents as coagulants is a very important issue.

Because of the complexity in wastewater compositions and operational policy, no single set of operating conditions will meet the treatment criteria of food and agricultural wastewater. It is therefore necessary to evaluate coagulants, pH, coagulant dosage, and operational procedures using a laboratory test that simulates the operation of a full-scale coagulation-flocculation called a *jar test*. A jar test is a scripted lab testing conducted in a series of beakers and stirrers in a jar test apparatus (Fig. 3.9). Jar tests have been used to evaluate the effectiveness of various coagulants and flocculants under a variety of operating conditions for water treatment. The procedures and evaluation process have been adapted to dredged material. However, conducting jar tests and interpreting the results to determine design parameters are not simple tasks because there are many variables that can affect the tests. Only experience can assist in applying the following jar test procedures to a specific project.

Jar tests are used in these procedures to provide information on the



**Figure 3.9.** A schematic diagram of jar test apparatus.

most effective coagulant, optimum dosage, optimum feed concentration, effects of dosage on removal efficiencies, effects of concentration of the suspension on removal efficiencies, effects of mixing conditions, and effects of settling time:

1. Fill the jar testing apparatus containers with sample wastewater from a stock suspension (either real sample or synthetic one with composition similar to the wastewater) of known turbidity, color, alkalinity, and pH. Calculate the amount of alkalinity required to react with the maximum dosage of aluminum or ferric sulfate. If necessary, augment the natural alkalinity by the addition of 0.1 N  $\text{Na}_2\text{CO}_3$  so that the alkalinity will be at least 0.5 meq/l (25 mg/l as  $\text{CaCO}_3$ ). One container will be used as a control while the other containers can be adjusted depending on what conditions are being tested. For example, the dosage of coagulants, pH, and settling time in the containers can be adjusted to determine the optimum conditions.
2. If it is a test for an existing coagulation-flocculation process, the procedure should reflect the actual conditions of the specific plant in terms of rapid mixing RPM and time, slow mixing RPM and time, and finally settling time. If not, choose a set of appropriate stirring speeds for rapid

and slow mixing, mixing times, and settling time for flocs to settle completely; add chemicals (aluminum or ferric sulfate) to each beaker near the vortex at high RPM for a minute and follow the actual or proposed operating conditions. Next, look at the beakers and determine which one has the best results (if any). An underdosed suspension will cause the sample to look cloudy with little or no floc. An overfeed suspension will cause fluffy flocs to occur and will not settle well. The beaker with an appropriate dosage of coagulant will have floc that has settled to the bottom, and the water above it will be clear determined either by vision or a nephelometer. If none of the beakers appear to have good results, the procedure should be rerun using different dosages until the correct dosage is determined.

The jar test procedure described follows a conventional empirical experiment design where variables are explored one factor at a time, keeping the other factors constant. This is not always effective or practical because the optimum conditions identified by the conventional approach may not be the true optimum if interactions between factors are present. Variables such as pH, mixing, and stirring speed may be important factors and should be included in the experiment design; a factorial design method may yield a better test result.

## **Filtration Processes**

Filtration is often employed in wastewater treatment, with or without prior treatments by coagulation-flocculation and sedimentation, for removal of flocs (or bioflocs) from primary and secondary wastewater treatment processes, solids remaining in effluents from primary and secondary wastewater treatment processes, and precipitates from physicochemical treatment of phosphate from the advanced wastewater treatment stage. Earlier applications of filtration for wastewater treatment borrowed heavily from design and operational experience with potable water treatment; the wastewater treatment adaptation has been perfected ever since. Filtration of sludge on rotary vacuum filters for dewatering is a common application of filtration in wastewater. Other applications of filtration are dewatering of digested sludge on sand beds and wastewater treatment through deep granular filters (sand, dual-medium, and multimedia) after most of the solids are removed.

Wastewater treatment using filtration usually is designed to get rid of microorganisms, reduce turbidity and color, remove odors, reduce the amount of iron, and remove most other solid particles that remain in the water. Water is sometimes filtered through activated carbon particles (see also the section “Adsorption,” below), which removes refractory organic particles.

Filtration in wastewater treatment is a unit operation that mirrors the natural system that treats impaired waters; groundwater is filtered through layers of sand and/or soil (underground strata) and potable quality of water may be obtained in wells deep beneath the surface. It is no surprise that filtration media used in wastewater treatment are sand, crushed anthracite coal, diatomaceous earth, perlite, and powdered or granular activated carbon. Combinations of different media are commonly used; a dual media may consist of coal over sand and a multimedia filter may be layered with garnet sand, silica sand, and coal.

Filtration involves complex mechanisms because these mechanisms depend on the physicochemical characteristics of the suspension and the filter medium, the rate of filtration, and the composition of wastewater. Deep granular filters consisting of 46 to 76 cm (18 to 30 in) of filter medium are supported on an underdrainage system; the filter may or may not be open to the atmosphere. A closed filter usually involves pressure and is called a *pressure filter*; open filters are termed *gravity filters*. Precoat filters comprise a number of porous septa in a filter housing connected to a collection manifold. The septa hold a thin layer of filter medium that is deposited hydraulically on the outside of the septa at the beginning of the filtering cycle. The filter septa are either open to the atmosphere while they are submerged in a tank or totally enclosed in a pressure tank. They are sometimes called *vacuum filters*. The characteristic designs of different types of filters contribute to the mechanisms of filtration in the systems. For example, precoats remove impurities at the surface through a formation of a filter cake made of the impurities; therefore, it is a mechanism of straining water. With deep granular filters with coarse materials, on the other hand, removal of particulate materials from wastewater is primarily within the filter bed as wastewater wiggles through the spaces formed by the filter medium. This type of filtration, as seen in some deep granular filters, is called *depth filtration*. However, actual removal of impurities involves several mechanisms: interstitial straining, gravitational settling, diffusion, interception, hydrodynamic interactions, and attachment/adsorption due to electrostatic interactions, chemical bonding, or specific adsorption, which may be affected by the type and dosage of the coagu-

lant used prior to filtration. Removal results in many deep granular filters may be dominated by a combination of surface cake removal and depth removal mechanisms.

The flow of wastewater through a filter at the rates commonly used in wastewater treatment is hydraulically the same as flow through underground strata in a natural system of groundwater treatment. The rate of flow through a filter may be expressed as follows (Equation 3.7):

$$\text{Rate of Flow} = \frac{\text{Driving Force}}{\text{Filter Resistance}}$$

where the driving force represents the pressure drop (head loss) across the filter.

Historically, single-phase wastewater flow through porous media has been modeled using either the linear Darcy's law or some empirical non-linear relationship between the pressure gradient and the Darcy velocity as an approximation to momentum conservation. For example, head loss through granular materials in the laminar range may be described by Darcy's law (Equation 3.8):

$$v = K_p \frac{h_f}{L}$$

where  $K_p$  is coefficient of permeability,  $h_f$  is head loss, and  $L$  is depth (or length) of filter. The coefficient of permeability can be determined experimentally. Theoretical relationships have been developed to calculate coefficient of permeability from measured physical characteristics. Non-linear relationships between the head loss and the Darcy velocity  $v$  have been used to illustrate important variables attributing to the head loss such as the following (Equation 3.9):

$$\frac{h_f}{L} = J \frac{v(1-\epsilon)^2}{g\epsilon^3} v \left( \frac{\sigma_s}{d_p} \right)^2$$

where  $J$  is a constant of approximately 6 in a laminar flow,  $\epsilon$  is the porosity ratio of the filter bed,  $d_p$  is the diameter of the particles, and  $\sigma_s$  is the shape factor. Values of shape factor range from 6.0 for spherical particles to 8.5 for granular materials such as anthracite coal.

Filter effluent quality patterns vary with the characteristics of the filter medium, the solids, the water chemistry, and operating conditions of the filter. For precoat filters, the effluent quality is usually excellent, particularly after the filter cake is formed, which acts as an additional filtering medium. Removal of impurities by granular filter usually occurs within the cavities and interstices of the filter medium. Formation of cakes in these filters may contribute to the filtering of solids. Because the filtering occurs within the granular bed, the burden of removal shifts gradually from the upper layers to the lower layers; it is observed that a granular filter usually starts with high removal efficiency but degrades steadily over time as layers of the filter medium progressively are saturated with pollutants.

Filtration in wastewater treatment is a unit operation that frustrates theoreticians of wastewater engineering design because of the inherited variability in the characteristics of the feed stream to be filtered. This is not only a testament to the diversity of wastewater sources but also the fact that the filtration process is often employed as a supplemental process to the primary or secondary wastewater treatment processes. Thus, the filtration process is subject to changes in the degree of coagulation-flocculation of colloidal dispersion in the settling basins or tanks because these changes lead to variability in particle size and distribution. It is often necessary to conduct pilot plant studies to ensure that the filter configuration selected for a given task will perform adequately for the treatment objective.

## Adsorption

Adsorption is a physicochemical process that generally occurs at the interface of fluid-solid phases and is sometimes used to remove certain species that cannot effectively be removed from the wastewater stream by other conventional technologies. Although it is quite possible that liquid-liquid or gas-liquid interaction results in adsorption, it is more common in wastewater treatment to observe interactions of two fluid phases as absorption. Adsorption and absorption, which belong to the same category of physicochemical processes called *sorption*, are two different phenomena. The main difference of these two lies in the equilibrium phase they eventually form: If it is homogeneous, it is absorption; otherwise, it is adsorption. Adsorption can be either physical (such as binding caused by van der



Waals forces) or chemical/activated (such as covalent bonds). It is quite possible that both styles of adsorption exist in wastewater treatment employing adsorption because a variety of substances could be in the stream.

In general, the materials being adsorbed are called *adsorbates*; the materials adsorbing adsorbates are termed *adsorbents*. The majority of the adsorbents in wastewater treatment are solids. These solids can be roughly divided into three categories: carbons, inorganic materials, and synthetic polymers. Carbon-based adsorbents such as activated carbons are the most common adsorbents in use in wastewater treatment plants. They are effective and relatively inexpensive; they even can be made from agricultural wastes. For example, peanut shells from the deep south of the U.S. are currently tested for use as adsorbents for heavy metal and other toxic material removals. Other sources of raw materials for carbon-based adsorbent manufacturing include petroleum coke, wood, and coconut shells.

Inorganic materials used for adsorption are classes of activated alumina and zeolites. These materials are expensive and more size- or/and species-specific. They are more likely to be found in fine chemical manufacturing, pharmaceutical, and other high-profit margin industries.

Synthetic polymers can be used as adsorbents because they are easily functionalized on the surfaces. Ion exchange polymers target ions in the solution, so they are good candidates for removing ions in water purification or wastewater treatment to remove certain heavy metal or other toxic ions from wastewater. Polymers that do not rely on an ion exchange mechanism utilize the hydrophobic or hydrophilic interactions (a stronger form of molecular force than van der Waals forces) to adsorb the adsorbates.

In order to describe the capability of an adsorbent to adsorb certain adsorbate species, we often examine an isotherm of the adsorbent—an adsorption data plot of amount of adsorbed per unit mass of the adsorbent versus concentration of adsorbates in the solution. There are four common isotherms (curves) typical of all adsorptions: linear, Freundlich, Langmuir, and “unfavorable,” as shown in Fig. 3.10. The last one has an upward curvature on adsorption versus concentration plot and receives no favor, as its name suggests; therefore, it is so termed but never tended. The isotherms reveal not only the capacity of the adsorbent but also the adsorption patterns and its equilibrium state. The linear isotherm is a simplistic mathematical gimmick, straightforward but unrealistic (Equation 3.10):

$$q = Ky$$




Figure 3.10. A schematic of isotherms of adsorption.

where  $K$  is a proportionality constant associated with equilibrium adsorption. The reason that the linear isotherm is included in discussions is because it is simple and provides a rather reassuring reference to both Langmuir and Freundlich isotherms.

The Langmuir isotherm is more widespread and easily explained away with a theoretical basis that accounts for irreversible adsorption as a result of an equilibrium between adsorption and desorption. Its expression is not neat but insightful (Equation 3.11):

$$q = \frac{q_0 y}{K + y}$$

$q_0$  in this equation is the total concentration of the adsorption sites on the adsorbents;  $K$  is the reciprocal of the equilibrium constant of irreversible adsorption on the sites. For data processing of the Langmuir type of equa-

tions, a linearization step is often the only thing needed. For example, rearrangement of Equation 3.11 reveals the linear relationship of  $1/q$  vs.  $1/y$  (Equation 3.12):

$$\frac{1}{q} = \frac{1}{q_0} + \frac{K}{q_0 y}$$

Here,  $q_0$  is considered as a constant.

The Freundlich isotherm is defined as the following (Equation 3.13):

$$q = Ky^n$$

where  $n$  and  $K$  are experimentally determined constants; in many cases,  $n$  is less than 1 (but never equal to or larger than 1). Occasionally, for some adsorption curves of Freundlich isotherm type that has an  $n$  value close to 1, the linear isotherm is used for approximation purposes. To use the Freundlich isotherm to fit the experimental data, one has to transform the equation into a linear form by taking logs on both sides of Equation 3.13, resulting in the following (Equation 3.14):

$$\log q = \log K + n \log y$$

It is obvious that plotting of  $\log q$  versus  $\log y$  yields a linear line.


The common way of determining the best fit of the isotherms in an adsorption experimental data is to plot data according to three common isotherms until a best-fit model (isotherm) is found. It is possible that none of the isotherms fits precisely to the data; in that case, a best fit (least deviated from the majority of data points—a statistical analysis of data fitting of the linearized isotherm) may be needed.

In adsorption operations, adsorbents often reside in a packed bed. This arrangement, which is akin to a plug flow reactor, has the best mass transfer driving force of adsorption of adsorbates onto the adsorbents in the packed bed. As adsorbates pass through the bed over time, the adsorbents in the bed extract the adsorbates from the solution and, eventually, the adsorbents in the bed become saturated and the concentrations of the adsorbates from the effluent (called *eluent*) start to rise as illustrated in Fig. 3.11. The s-shaped curve of adsorbates' concentrations versus eluent volume (expressed often as time) that depicts the starting points of sharp rising and leveling off corresponding to exhaustion of the adsorbents of ad-

sorbates' concentrations leaving the packed bed is called the *breakthrough curve*. The breakthrough curve is used to compare different adsorbents in a packed bed. In addition to the breakthrough curve obtained from evaluation of adsorbents in a laboratory or provided by the vendor, another issue, called *bed efficiency*, is also important to practical application of adsorption technology and is related to the breakthrough curve. The packed bed efficiency over time is a measurement of the effect of the bed (the shell/container holding the adsorbents and the packing factor) on adsorption capacity (Equation 3.15):

$$\theta = 1 - \frac{t_E - t_B}{2t_B}$$

where  $\theta$  is the fraction of the packed bed that is loaded with adsorbates,  $t_E$  is eluent time (corresponding to the starting point of leveling off of the breakthrough curve in Fig. 3.11) and  $t_B$  is the starting point of the breakthrough curve. This equation, through  $\theta$ , indicates the actual saturation of the adsorbents in the bed when the breakthrough curve is observed, which



**Figure 3.11.** A schematic diagram of a breakthrough curve of adsorption.

is always lower than 100%, hence the bed efficiency. It should be emphasized that Equation 3.15 is an approximation because its derivation involves the assumption of the breakthrough curve as a step function, a sharp, vertical rise of the eluent concentration in contrast to the more rounded curve shown in Fig. 3.11; however, it is a relatively adequate approximation because of the concentration profile developing quickly in the bed and “sharpening” of the curve. The attempt to make a numerical integration over the breakthrough curve does not lead to more accurate results since the gain from elaborate mathematical treatment of the breakthrough curve will be negated by the errors associated with the numerical methods used as well as the curve itself. The approximation method shown in Equation 3.15 is often recommended by adsorbent manufacturers.

Once  $\theta$  is known, the unused bed length  $l'$  can be calculated as follows (Equation 3.16):

$$l' = l(1 - \theta)$$

where  $l$  is the bed length. So the used bed length  $l-l'$  is therefore saturated as follows (Equation 3.17):

$$l_{sat} = \left[ \frac{y_0 v}{q_0(1 - \varepsilon)} \right] (t_E - t_B)$$

where  $v$  is the superficial velocity of the eluent;  $\varepsilon$  is the void fraction of the bed; and  $y_0$  and  $q_0$  are the initial concentration of the adsorbate and saturated concentration of the adsorbate on the adsorbent, respectively. For a batch-packed bed, if we know the initial and final concentrations of the adsorbate and the amount of the feed that goes through the bed, we can easily calculate the amount of the adsorbent used based on mass balance on the adsorbate (Equation 3.18):

$$(y_0 - y)V = qW$$

where  $V$  is the amount of the feed in volume and  $W$  is the weight of the adsorbent. The adsorption  $q$  is in equilibrium with the concentration of the depleted solution,  $y$ , and can be expressed by one of three isotherms. However, for a packed bed, Equation 3.18 is valid but  $q$  is in equilibrium with the feed concentration,  $y_0$ , thus enabling much efficient mass transfer and requiring less adsorbent. This is the reason that packed bed adsorp-

tion units, which are close to idealized reactors with plug flow in terms of fluid dynamics and mass transfer, are commonly used.

## Chemical Oxidation

Chemical oxidation in wastewater treatment is a process in which undesirable chemical species are converted through oxidation (such as redox reactions) to chemical species that are neither harmful nor objectionable. It modifies the structure of pollutants in wastewater through the addition of an oxidizing agent. During chemical oxidation, one or more electrons transfer from the oxidant to the targeted pollutant, causing its destruction. Both organic matters, including microorganisms and inorganic substances, can be subject to oxidation. Examples of organic matters for chemical oxidation include humic acids, phenols, amines, and bacteria; common inorganic substances that are toxic and/or objectionable may include ions such as  $\text{Fe}^{2+}$ ,  $\text{Mn}^{2+}$ ,  $\text{S}^{2-}$ ,  $\text{CN}^-$ , and  $\text{SO}_3^{2-}$ . A handful of oxidizing agents are capable of oxidizing the undesirable substances adequately: oxygen, ozone,  $\text{UV}/\text{H}_2\text{O}_2$ ,  $\text{Fe}^{2+}/\text{H}_2\text{O}_2$  (Fenton's reaction), potassium permanganate, chlorine, chlorine dioxide, and zero-valent iron nanoparticles.

Chemical oxidation applications in wastewater are used throughout entire wastewater management operations—from collection of wastewater streams, to treatment, to disposal. In collection facilities, chemicals such as  $\text{Cl}_2$ ,  $\text{FeCl}_3$ , and  $\text{O}_3$  or  $\text{H}_2\text{O}_2$  are employed in controlling slime growth and corrosion; in treatment operations of wastewater, chemicals are used in a number of places often as supplemental procedures for a major wastewater treatment unit operation. For example,  $\text{Cl}_2$  and  $\text{O}_3$  are applied to reduce BOD and ammonia; but by and large, chemical oxidation procedures are often used to counter the problems of a biological, microbial, or noxious (odorous) nature. When the wastewater effluent from a treatment plant is ready for disposal, the effluent is often treated with  $\text{Cl}_2$ ,  $\text{H}_2\text{O}_2$ , or  $\text{O}_3$  to ward off bacteria and odor. In potable water treatment (including membrane-based processes but with the addition of ammonia to neutralize the residual  $\text{Cl}_2$  or  $\text{H}_2\text{O}_2$  in order to protect membranes), chemical oxidation is used for disinfection with  $\text{Cl}_2$  (mainly in the U.S. and a number of other nations) or  $\text{O}_3/\text{H}_2\text{O}_2$  (mainly in west Europe). Chlorine has a better residual antimicrobial potency than  $\text{O}_3$  or  $\text{H}_2\text{O}_2$ , but it could produce harmful substances, as described below.

One common (and inexpensive) method of chemical oxidation, referred

to as *alkaline chlorination*, uses chlorine (usually in the form of sodium hypochlorite) under alkaline conditions to destroy undesirables such as cyanide and some pesticides. However, using alkaline chlorination for chemical oxidation of pollutants may generate toxic chlorinated organic compounds, including chloroform, bromodichloromethane, and dibromochloromethane, as by-products. Adjustments to the design and operating parameters may alleviate this problem, or an additional treatment step (e.g., steam stripping, air stripping, or activated carbon adsorption) may be required to remove these by-products.

Oxidation by hydrogen peroxide alone is not effective for converting high concentrations of certain refractory contaminants, such as highly chlorinated aromatic compounds and inorganic compounds (e.g., cyanides), because of low rates of reaction at reasonable  $\text{H}_2\text{O}_2$  concentrations. Transition metal salts (e.g., iron salts), ozone, and UV-light can activate  $\text{H}_2\text{O}_2$  to form hydroxyl radicals that are strong oxidants:

- ozone and hydrogen peroxide  

$$\text{O}_3 + \text{H}_2\text{O}_2 \rightarrow \text{OH}\cdot + \text{O}_2 + \text{HO}_2\cdot$$
- iron salts and hydrogen peroxide  

$$\text{Fe}^{2+} + \text{H}_2\text{O}_2 \rightarrow \text{Fe}^{3+} + \text{OH}\cdot + \text{OH}^-$$
- UV-light and hydrogen peroxide  

$$\text{H}_2\text{O}_2[\text{+UV}] \rightarrow 2\text{OH}\cdot$$

The oxidation processes utilizing activation of  $\text{H}_2\text{O}_2$  by iron salts are referred to as *Fenton's reagent*.

In general, oxidation processes that are based on the generation of radical intermediates are termed *advanced oxidation techniques*. Hydroxyl radicals (oxidation potential: 2.8 V) are stronger oxidants than ozone and  $\text{H}_2\text{O}_2$ . Hydroxyl radicals nonspecifically oxidize target compounds at high reaction rates of the order of  $10^9 \text{ M}^{-1} \text{ s}^{-1}$ .

## Membrane Separations


Membrane separations have been playing an increasing role in wastewater treatment; this is the most evident in processing whey wastewater with ultrafiltration in the dairy industry, one of many types of membrane separation technologies, and in membrane pervaporation of volatile organic compounds (VOCs) from wastewater. Currently, a new field of membrane

separations called *nanomembrane technology* is said to be the future nanotechnology for achieving clean water with this purported type of “smart membranes.” It is predicted that nanomembranes are able to separate molecules by differences between molecular weights of a mixture of compounds—a feat that current membranes (polymeric or inorganic membranes) are unable to achieve. Whether this prediction of smart membranes can really hold water in the future is anyone’s guess; however, the use of membrane-based technologies will undoubtedly increase among the evolving water and wastewater treatment landscapes.

A membrane can be viewed as a discreet (or discriminating) barrier that allows some components of the wastewater feed to pass through the membrane faster than the other components. A membrane provides a third phase, mostly a solid phase that straddles between two fluid phases serving as the origin and the destination of the separation process. The membrane is most likely polymeric, though new inorganic membranes are now emerging at a rapid pace. The principal mechanisms of membrane separations are molecular diffusion in solid and tortuous viscous flows in microporous solids.

Membrane technology is an evolving separation technology, and because of its multidisciplinary characters it can be used to perform a large number of separations in food and agricultural wastewater treatment. The membrane processes that are commonly found in processing plants or research laboratories include microfiltration (MF), reverse osmosis (RO), ultrafiltration (UF), nanofiltration (NF), electrodialysis (ED), membrane distillation (MD), and pervaporation (PV). Membrane processes are based upon different separation principles or mechanisms and their applications in food processing range from concentration of food fluids to aromatic flavor recovery. The membrane is at the center of every membrane process. However, membrane separations can be achieved only when a driving force is applied to the underlying membrane process. A schematic diagram of a two-phase conceptual system is shown in Fig. 3.12. No perfect man-made membrane ever existed. This situation will be with us in the foreseeable future until perhaps we fully understand the mechanisms that regulate the mass transfer in the membrane, and we are able to tailor the membrane structures to the need of separation of molecules of interest by using the latest advancement in nanotechnology. In assessing membrane systems, two experimental parameters that determine the overall performance of membrane processes should be the main focus of designers’ attention. The first one is selectivity, the other, permeation flux.





**Figure 3.12.** A schematic diagram of a conceptual two-phase membrane system.

The selectivity of a membrane toward a mixture, which characterizes the extent of separation, is customarily expressed by one of two quantities: the retention,  $R$ , and the separation factor,  $\alpha$ . The  $R$  is more suitable for the membrane separation of a dilute binary system and given by Equation 3.19:

$$R = \frac{C_f - C_p}{C_f}$$

where  $C_f$  is the solute concentration in the feed stream and  $C_p$  the solute in the permeate. The value of  $R$  varies between 100% (complete rejection or retention) and 0% (complete permeation). For most mixtures, however, the selectivity factor is more adequate (Equation 3.20):

$$\alpha_{ij} = \frac{(C_i / C_j)^p}{(C_i / C_j)^f}$$

where  $C_i$  and  $C_j$  are the concentrations of components  $i$  and  $j$  in the permeate and in the feed. The value of  $\alpha_{ij}$  is greater than 1 if the component  $i$  is more readily permeable than component  $j$  and if the separation occurs.

The other parameter, permeation flux, takes many forms depending upon the underlying membrane processes. It is normally expressed as the following (Equation 3.21):

$$J_i = -K \frac{dg}{dz}$$

where  $K$  is the phenomenological coefficient and  $dg/dz$  is the driving force expressed as the gradient of  $g$  (concentration, temperature, pressure) in the  $z$  direction toward the membrane. The phenomenological coefficient  $K$  is strongly related to the driving force, module configuration, and operating conditions.

Membrane processes can be classified according to the nature of their driving forces and pore size of the membrane. Although all membrane processes are driven by the electrochemical potential gradient, one particular driving force is usually dominated in a membrane process. Three types of membrane separation processes relevant to the food industry can be considered: those driven by hydrostatic pressure difference, those driven by the partial vapor pressure gradient, and those driven by electrical potential differences. The next sections present brief general descriptions of the membrane processes used or potentially usable in various operations of the food industry.

### *Membrane separation by hydrostatic pressure difference*

Membrane performance of a pressure-driven system is usually described by the flow rates of water (solvent) and solute (permeate). The flow of water (volume flux) through a membrane without considering concentration polarization and fouling (or/and gel layer) is expressed by the following (Equation 3.22)

$$J_w = K_w (\Delta P - \sigma \Delta \Pi)$$

where  $K_w$  is water permeability;  $\Delta P$  is the applied pressure;  $\Delta \Pi$  is the osmotic pressure difference; and  $\sigma$  is the reflection coefficient of the membrane toward the solute, which is a measure of degree of solute rejection. The driving force is  $(\Delta P - \Delta \Pi)$  as  $dg/dz$  in Equation 3.21. Because there is no perfect membrane, we may suspect (it can be verified) that some solutes, including those undesirable, also transport across the membrane, though less freely than water (solvent) (Equation 3.23):


$$J_s = K_s (C_m - C_p)$$

where  $K_s$  is the solute permeability and  $C_m$  and  $C_p$  are concentrations on the upstream side of the membrane and on the permeate side, respectively. Note that  $K_s$  has a different unit from that of  $K_w$  because the driving force in Equation 3.23 is expressed as the solute concentration difference.

Although Equations 3.22 and 3.23 are generally considered as valid phenomenological expressions, the true meanings of  $C_m$  and  $C_p$  are not what they seem to be. This is because in a pressure-driven membrane process, the retained solutes transported by convective transmembrane flux can accumulate at the membrane surface leading to high concentration of solutes near the membrane, a phenomenon called *concentration polarization*. This concentration gradient is encompassed in a region designated as the boundary layer (velocity has its own gradient due to the viscous effect at the water-membrane interface and the no-slip condition for a common cross-flow membrane configuration, thus a velocity boundary layer). In a steady state situation, the concentration polarization is the result of solute buildup counterbalanced by the solute flux through the membrane plus the diffusive flux of solute at the membrane surface toward the bulk flow on the upstream side of the membrane. The magnitude of the concentration polarization is expressed by the Equation 3.24 as a result of the solute mass balance based upon the concentration profile of the film model illustrated in Fig. 3.13:

$$\frac{C_m - C_p}{C_b - C_p} = \exp\left(\frac{J_s}{k}\right)$$

where  $C_b$  is the concentration of the solute in the bulk flow and  $k$  is the mass transfer coefficient that is the ratio of diffusivity of the solute in the solvent to the thickness of the concentration boundary layer, which can be interpreted as the mass transfer coefficient when the permeation flux approaches zero. The cause of the concentration polarization phenomenon is different in reverse osmosis, as in microfiltration or ultrafiltration. In reverse osmosis, as the low molecular weight material is retained on the membrane surface (see the following section about the characteristics of all pressure-driven membrane processes), the increase in the solute concentration causes the osmotic pressure to rise, which decreases the water flux, as illustrated in Equation 3.22. In ultrafiltration, the high concentration of larger molecules accumulated on the membrane surface does not result in significant osmotic pressure increase. However, these retained molecules may lead to precipitation and possibly formation of a gel layer on the mem-



**Figure 3.13.** A schematic diagram of a film model.

brane surface. The mass transfer coefficient,  $k$ , in Equation 3.24 has to be determined experimentally because the thickness of the concentration boundary layer is usually an unknown quantity that is strongly influenced by hydrodynamics of the system. The mass transfer coefficient,  $k$ , however, can often be related to the semiempirical Sherwood number correlations with the following form of expression (Equation 3.25):

$$Sh = \frac{Kd_h}{D} = a Re^b Sc^c = a \left( \frac{\rho u d_h}{\mu} \right)^b \left( \frac{\nu}{D} \right)^c$$

where  $Re$  is the Reynolds number,  $Sc$  the Schmidt number, and  $Sh$  is Sherwood number; and  $a$ ,  $b$ , and  $c$  are all constants. In Equation 3.25,  $\mu$  and  $\nu$  are dynamic viscosity and kinematic viscosity, respectively while  $\rho$  is the density,  $D$  the diffusivity, and  $d_h$  the hydrodynamic diameter. It is clear that the mass transfer coefficient  $k$  is mainly a function of the feed flow velocity, the density, the viscosity, the diffusivity of the solute, and the membrane module type. Many Sherwood relationships for different flow regimes and membrane module shape and dimensions are available in the literature (Cheryan, 1986; Rautenbach and Albrecht, 1989; Mulder, 1991).

*Microfiltration (MF)*

Microfiltration (MF) is a form of filtration that has two common forms. One form is cross-flow separation. In cross-flow separation, a fluid stream runs parallel to a membrane. There is a pressure differential across the membrane. This causes some of the fluid to pass through the membrane, while the remainder continues across the membrane, cleaning it. The other form of filtration is called *dead-end filtration* or *perpendicular filtration*. In dead-end filtration, all of the fluid passes through the membrane, and all of the particles that cannot fit through the pores of the membrane are stopped. Cross-flow microfiltration is used in a number of applications, as either a prefiltration step or as a process to separate a fluid from a process stream. Dead-end microfiltration is used commonly in stopping particles in either prefiltration or final filtration before a fluid is to be used. Cartridge filters are typically composed of microfiltration media. MF is a pressure-driven membrane filtration process that has a membrane with a pore size typically of 0.2–2  $\mu\text{m}$  and able to retain particles with molecular weights equal or larger than 200 kDa. MF membranes are symmetric with a characteristic spongelike network of interconnecting pores. It has been successfully used in the beer brewing industry to remove bacteria in the production of long shelf-life draft beers. The dairy industry has also found MF useful in removing bacteria or particulate substances and fractionation of milk proteins. MF is the membrane process that most closely resembles a conventional filtration unit. The transport mechanism of MF is undoubtedly sieving action. Thus, the volume flux through the MF membranes is expressed with a Hagen-Poiseuille relationship (Equation 3.26):

$$J = \frac{\varepsilon r^2 \Delta P}{8 \mu \tau \Delta z}$$

if the membrane is perceived as a bunch of straight capillaries. When a nodular structure (the space between spheres) exists, a Kozeny-Carman equation is usually applied to the following (Equation 3.27):

$$J = \frac{\varepsilon^3}{K \mu S^2 (1 - \varepsilon)^2} \frac{\Delta P}{\Delta z}$$

where  $S$  is the internal surface area,  $\varepsilon$  the volume fraction of the pores,  $\tau$  the pore tortuosity,  $\mu$  the viscosity, and  $K$  the Kozeny-Carman constant.

### *Ultrafiltration (UF)*

Ultrafiltration (UF) is the most common membrane process used in the food industry and it involves the use of a membrane with a pore size ranging between 0.01–0.2  $\mu\text{m}$ . Ultrafiltration is not as fine a filtration process as nanofiltration, but it also does not require the same energy to perform the separation. Applications of ultrafiltration in food processing can most likely be found in situations that call for separating one or more desirable components from a liquid mixture. Ultrafiltration is capable of concentrating bacteria, some proteins, some fats, some colloidal minerals and constituents that have a larger molecular weight of greater than 10 kDa, but it is typically not effective at separating organic streams (Rosenberg, 1995). In UF, the chemical nature of membrane materials has only little effect upon the separation because ultrafiltration separation, like microfiltration, is based upon sieving mechanisms; thus, ultrafiltration is only somewhat dependent upon the charge of the particle and is much more concerned with the size of the particle. The mass transfer equations for UF are similar to those for MF.

### *Reverse Osmosis (RO)*

Reverse osmosis (RO), also known as hyperfiltration, is the finest filtration known. This process will allow the removal of particles as small as ions from a solution. Reverse osmosis is used to purify water and remove salts and other impurities in order to improve the color, taste, or properties of the fluid. It can be used to purify wastewater streams that need additional treatment to remove water, which will pass through the reverse osmosis membrane, while rejecting other ions and colloids from passing. The most common use for reverse osmosis is in purifying water. It is used to produce water that meets the most demanding specifications that are currently in place. Reverse osmosis uses a membrane that is semipermeable, allowing the fluid that is being purified to pass through it, while rejecting the contaminants that remain. Most reverse osmosis technology uses a process known as *cross-flow* to allow the membrane to continually clean itself. As some of the fluid passes through the membrane, the rest continues downstream, sweeping the rejected species away from the membrane. The process of reverse osmosis requires a driving force to push the fluid through the membrane, and the most common force is pressure from a pump. A reverse osmosis process involves pressures 5–10 times higher than those used in ultrafiltration. As the concentration of the fluid being rejected increases, the driving force required to continue concentrating the

fluid increases. Reverse osmosis is capable of rejecting bacteria, salts, sugars, proteins, particles, fats, and other constituents that have a molecular weight of greater than 0.15–0.25 kDa. The separation of ions with reverse osmosis is aided by charged particles. This means that dissolved ions that carry a charge, such as salts, are more likely to be rejected by the membrane than those that are not charged, such as organics. The larger the charge and the larger the particle, the more likely it will be rejected. The transport mechanism of RO as well as of nanofiltration is now believed to be the solution diffusion mechanism. The evaluation of RO performance can be conducted with Equations 3.21–3.24.

#### *Nanofiltration (NF)*

Nanofiltration (NF) is a form of filtration that uses membranes to preferentially separate different fluids or ions. Nanofiltration is not as fine a filtration process as reverse osmosis, but it also does not require the same energy to perform the separation. Nanofiltration also uses a membrane that is partially permeable to perform the separation, but the pores of the membrane are typically much larger than the membrane pores that are used in reverse osmosis. Nanofiltration is most commonly used to separate a solution that has a mixture of some desirable components and some that are not desirable. An example of this is the concentration of corn syrup. The nanofiltration membrane will allow the water to pass through the membrane while holding the sugar back, concentrating the solution. As the concentration of the fluid being rejected increases, the driving force required to continue concentrating the fluid increases. Nanofiltration is capable of concentrating sugars, divalent salts, bacteria, proteins, particles, fats, and other constituents that have a molecular weight greater than 1 kDa. Nanofiltration, like reverse osmosis, is affected by the charge of the particles being rejected. Thus, particles with larger charges are more likely to be rejected than others. The mass transport mechanism of NF and the membrane material used are quite comparable to those of RO. In some cases, NF is grouped into reverse osmosis processes.

#### ***Membrane separations by electrical potential difference:***

##### ***Electrodialysis (ED)***

Electrodialysis (ED) is an electrically driven membrane separation process that is capable of separating, concentrating, and purifying selected

ions from aqueous solutions (as well as some organic solvents). The process is based on the property of ion exchange membranes to selectively reject anions or cations. If membranes are more permeable to cations than to anions or vice versa, the concentration of ionic solutions increases or decreases, so that concentration or depletion of electrolyte solutions is possible. Because in electrodialysis only ionic species are transferred directly, removal of ionic species from nonionic products can be accomplished so that purification is possible. Electrodialysis reversal (EDR) is an electrodialysis process in which the polarity of the electrodes is reversed on a prescribed time cycle, thus reversing the direction of ion movement in a membrane stack. The advantage of EDR is that it mitigates some of the concentration polarization and membrane fouling problems (Davis, 1990). The largest application of ED is the production of potable water from brackish water. Electrodialysis can remove salts from food, dairy, and other products, as well as concentrate salts, acids, or bases. It also finds applications in wine and juice stabilization and in removing unwanted total dissolved solids that can build up in product streams (López-Leiva, 1988; Davis, 1990).

Faraday's law supplies the basis to model ion transport and affirms that the total current in an electrolytic cell is equal to the sum of the electricity conveyed by each ion species (Equation 3.28):

$$I = f \sum (J_i Z_i) = fQ \sum \left( Z_i \frac{\Delta C_i}{e_i} \right)$$

where  $I$  is the current density,  $f$  the Faraday's constant,  $Q$  the flow rate,  $\Delta C_i$  the concentration difference,  $J_i$  the molar flux,  $e_i$  the current efficiency, and  $Z_i$  the valence of ion  $i$ . Concentration polarization also severely affects the current density and the diffusive flux (the current density) through the concentration gradient over the boundary layer for a univalent ionic solution ( $Z = 1$ ) (Equation 3.29):

$$I = \frac{Df(C_b - C_m)}{\delta_c(t_m - t_{bl})}$$

where  $D$  is the diffusivity;  $C_m$  and  $C_b$  are concentrations at the membrane surface and in the bulk, respectively;  $\delta_c$  is the thickness of the concentration boundary layer; and  $t_m$  and  $t_{bl}$  are the transport numbers of the ion in



the membrane and in the solution, respectively. The transport number of the ion is defined as the following (Equation 3.30):

$$t_i = \frac{(J_i Z_i)}{\sum (J_i Z_i)}$$

### ***Membrane separations by partial vapor pressure gradient***

#### *Pervaporation (PV)*

Pervaporation (PV) is the separation of liquid mixtures by partial vaporization through a dense permselective membrane. Unlike the other membrane processes, a phase change occurs when the permeate changes from liquid to vapor during its transport through the membrane. PV is an enrichment technique similar to distillation; however, unlike distillation, PV is not limited by the vapor-liquid equilibrium. As a matter of fact, PV has been commercially applied to the separation of azeotropic mixtures (dehydration of alcohol). The heart of the PV is a nonporous membrane, which either exhibits a high permeation rate for water but does not permeate organics, or vice versa. A gradient in the chemical potential of the substances on the feed side, and the permeate side is the driving force for the process, which can be represented by partial vapor pressures on both sides of the membrane. The driving force is kept at a maximum by applying low pressure (vacuum or sweep gas) to the permeate side of the membrane, combined with immediate condensation of permeated vapors.

Pervaporation processes have found use in the chemical industry to break azeotropic water/alcohol mixtures and to perform separations that are highly energy-intensive when distillation is used. Over the decades, a growing amount of attention has been paid to the application of pervaporation to environmental problem.

The performance of pervaporation is commonly evaluated by two experimental parameters: the permeation flux and the selectivity. The performance of a pervaporation process is assessed by the flux of the permeating species and the selectivity of the species (Equation 3.31):

$$J_i = k_i^{ov} \rho' [C_i^L - C_i^v]$$

where  $k_i^{ov}$ ,  $\rho'$ ,  $C_i^L$ ,  $C_i^v$  are the overall mass transfer rate constant, molar density of feed, bulk liquid phase concentration (mole fraction), and bulk

vapor phase concentration, respectively, for component  $i$ . The most commonly used selectivity parameter is the separation factor shown in Equation 3.20. Sometimes, however, the enrichment factor,  $\beta_i$ , is used as an indication of the separation selectivity for component  $i$  (Equation 3.32):

$$\beta_i = \frac{(C_i)^v}{(C_i)^L}$$

As the concentration of component  $i$  is reduced, the concentration of component  $j$  will approach 1. The separation factor will therefore be close to the value of the enrichment factor,  $\beta_i$ , for dilute solutions (Equation 3.33):

$$\alpha_{ij} \approx \beta_i$$

Pervaporative transport process follows the solution-diffusion model that is also the transport mechanism of RO and NF, which consists of the following steps:

1. Diffusion through the liquid boundary layer next to the feed side of the membrane
2. Selective partitioning of molecules of components into the membrane
3. Selective transport (diffusion) through the membrane matrix
4. Desorption into vapor phase on the permeate side
5. Diffusion away from the membrane and into the vapor boundary layer on the permeate side of the membrane

Often, each step can be modeled with different approaches and fundamental assumptions; however, as with all mass transfer operations, the slowest step in this sequence will limit the overall rate of mass transfer and will be the center of research focus. Naturally, these steps are conveniently expressed in the form of the resistance-in-series model, which is expressed with mathematical symbols as the following (Equation 3.34):

$$\frac{1}{k^{ov}} = \frac{1}{k^{bl}} + \frac{1}{k^m} + \frac{1}{k^v}$$

The  $k$ 's appearing in the equation are mass transfer coefficients, and their reciprocals represent the mass transfer resistance at each step. For many pervaporation processes, the mass transfer resistance in the vapor

boundary layer tends to be small enough to be ignored. This leaves only the liquid boundary layer ( $1/k^{bl}$ ) and membrane ( $1/k^m$ ) resistances to deal with.  $k^m$  is strongly determined by polymer properties, the thickness of the membrane, and chemical structures of the components in the liquid. In situations where hydrophobic volatile compounds are being removed from the liquid by pervaporation, the mass transfer rate is often limited by diffusion of the compound in the liquid boundary layer, i.e.,  $k^{ov} \cong k^{bl}$ . This situation arises because nowadays membrane can be made in such a way that the membrane provides minimal mass transfer resistance to the volatile compounds, almost to the point of being absent. This situation manifests itself as a phenomenon called *concentration polarization*, i.e., the steep discrepancy in volatile compound concentrations between the bulk and the membrane surface. When concentration polarization is severe, the function of membrane is to minimize the solvent flux, thereby maximizing the selectivity of the intended separation. The analysis of the liquid boundary-layer mass transfer resistance is very important to the process designers and operators alike. One common approach to the analysis is to find out the correlation between the mass transfer coefficient and process parameters. It is recommended that the boundary-layer theory would have to be adopted to provide more robust analysis that has broader application and scalability. However, in reality, it is exceedingly difficult to do it. Instead the semiempirical correlations that have the form of Sherwood number correlations shown in Equation 3.25 are commonly employed. Among these correlations is the frequently cited L ev eque's correlation (Equation 3.35):

$$k^{bl} = 1.6 \frac{D}{d_h} \text{Re}^{1/3} \text{Sc}^{1/3} \left( \frac{d^h}{L} \right)^{1/3}$$

The only new parameter in this correlation is  $L$ , the length of the membrane channel. This correlation indicates that the mass transfer coefficient is mainly dependent upon flow conditions on the feed side and the shape and dimensions of the module. Temperature has a substantial impact upon the mass transfer coefficient through the diffusivity of the solute and viscosity. Nevertheless, temperature is not a commonly manipulated parameter due to the issues of membrane stability and the vapor pressure of the volatile solute because the feed has to be kept in the liquid phase. Flow velocity (flow rate) is the parameter that can be adjusted to minimize the liquid boundary layer resistance for a fixed membrane module (configuration).

*Membrane distillation (MD)*

Membrane distillation (MD) is a type of low-temperature, reduced pressure distillation using porous hydrophobic (water-hating) polymer materials. It is a process that separates two aqueous solutions at different temperatures and has been developed for the production of high-purity water, and for the separation of volatile solvents such as acetone and ethanol. MD can achieve higher concentration than RO. In MD, the membrane must be hydrophobic and microporous. The hydrophobic nature of the material prevents the membrane from being wetted by the liquid feed; hence, liquid penetration and transport across the membrane is avoided, provided the feed side pressure does not exceed the minimum entry pressure for the pore size distribution of the membrane. The driving force of MD is the temperature gradient, and the two different temperatures produce two different partial vapor pressures at the solution-membrane interface, which propels consequent penetration of the vapor through the pores of the membrane. The vapor is condensed on the chilled wall by cooling water, producing a distillate. This process usually takes place at an atmospheric pressure and temperature that may be much lower than the boiling point of the liquids (e.g., solvents). It is commonly observed that the effect of the osmotic pressure from the permeate to the feed solution will be prominent when the high solute concentrations of feed liquids are processed. A variation of MD is sometimes called *low pressure membrane distillation* or *osmotic distillation*, which uses an auxiliary device to condense the vapor coming out of the membrane. The driving force for vapor transport in this case is the pressure differential. Alternatively, the auxiliary cooling device can be replaced by using an inert sweep gas or absorbing strip liquid to remove the vapor permeate and maintain the pressure differential. The membrane distillation is very similar to a single-stage distillation and is thus unable to achieve a high separation factor. The primary advantage of MD is the high surface-area:volume ratio available and thus high permeation rates. Most food applications of MD are concentrated upon dehydration of liquid foods.

The performance of an MD can be evaluated by a phenomenological equation (Equation 3.36):

$$J = F\Delta P$$

where the flux is related to two parameters; one is pressure difference and the other proportionality factor (“membrane permeability”)  $F$ .  $\Delta P$  is

mainly determined by the temperature difference  $T$ , which can be related to the Clausius-Claperyron relationship (Equation 3.37):

$$\ln P = \frac{\Delta H_{vap}}{RT} + c$$

$H_{vap}$  is the enthalpy of the vapor of permeating species,  $T$  the temperature, and  $c$  the constant. MD sometimes experiences a temperature polarization phenomenon due to the difference in the heat transfer rate between the heat conduction in the membrane and the heat transfer in the bulk fluid.

### ***Membrane contactor (MC)***

Membrane contactors (MCs) are a motley group of several membrane processes that primarily use the membranes as mass transfer barriers for certain matters and interfaces between two phases. The driving force in the process is typically the difference in either vapor pressures or the osmotic pressures across the membrane barrier. The relevant membrane contactors for fruit juice processing are direct osmosis, MD, and osmotic distillation (OD). Direct osmosis (DO) originates from an old practice for juice concentration and is caused by the difference of osmotic pressures between the dilute juice on the upstream side and the brine on the other side. The disadvantages of DO are the high costs and low permeation rates, even though DO can reach concentrations greater than those achieved by RO. MD utilizes the vapor pressure difference across the membrane resulting from temperature difference to drive the solvent molecules across the microporous hydrophobic membrane and condense at the cold side of the membrane. Because temperature difference (subsequently vapor pressure difference) drives MD, an increase in temperature on one side of the membrane would increase permeation rate. However, temperature polarization becomes prominent at high temperatures and exerts negative effect on permeation of MD. The other problem with MD operations is that the process is limited in terms of operating temperature due to concerns about thermal damage to the flavor compounds in fruit juices. This limitation with MD makes OD (also known as *osmotic evaporation*) or isothermal membrane distillation a better choice. In OD, a liquid mixture containing a volatile component is contacted with a microporous, nonwetable membrane whose opposite surface is exposed to another liquid phase where the mass transfer takes place across the membrane. This technology can remove se-

lectively the water from liquid wastes under atmospheric pressure and at room temperature. Like other membrane contactors, OD suffers from high costs and low permeation rate.

### ***Design considerations***

In many cases, it is still true to say that the design of a membrane process and/or the selection of a membrane module/material for desired separations remains a mixture of art and science, in which knowledge, experience, and science all play important roles. More often than not, there is no “right answer” in the absolute sense, because more than one solution is both technically and economically viable. However, a careful evaluation at the outset of as many as possible of the factors influencing the choices will help narrow down the items on the list.

When contemplating the use of any particular membrane process for the separation of components in a liquid food stream after the initial assessment, several process issues must be evaluated. The first step in doing so is to draw up the detailed requirements for the process. Accurate qualitative and, where possible, quantitative information on the following aspects should therefore be specified:

- The components and range of concentrations in the feed
- The intended use or fate of the treated feed liquids (i.e., final products, further processing, etc.)
- The intended use of or fate of the permeate (i.e., disposal, reuse, further processing, etc.)
- Permeation flux
- The minimum properties of the treated food fluids and permeate that will make the intended use or fate possible
- The membrane transport mechanism
- A cost-effective and environmentally friendly alternative solution

Any one or more of the above factors may, depending upon circumstances, influence the design of a membrane process. In the case of food-related wastes and by-products, it is normal for economical considerations to override operational simplicity. This is particularly true for aroma compound recovery in orange juice production effluents using pervaporation, in which the preservation of the permeate is the key to exerting a major influence on the ultimate cost of treating the wastewater stream. In other

processing applications, a membrane process can be an important intermediate operation that is vital to subsequent processing operations.

The next issue to be addressed is whether the membrane processes are actually capable of separating the components from liquid foods. The answer to this question for the pressure-driven membrane processes such as MC, UF, NF, and RO is generally affirmative, provided that appropriate membranes (pore size and, for NF and RO, membrane properties such as charge, hydrophilic tendency) are used. For pervaporation, the answer is more complicated and conditional. It is well documented that PV works well when the compound to be removed has a high vapor pressure relative to the background material and a low solubility in the background material. In dilute aqueous solutions such as aromas in orange juice, it is generally the Henry's constant that determines whether an aroma compound can be effectively separated by pervaporation. The Henry's constant represents the vapor-liquid partitioning of organic compounds in an aqueous system. The general rule of thumb is: the more dissimilar the components, the easier it will be to separate them.

Once the process designer has determined that a particular membrane process will, theoretically, work. The subsequent questions to be answered are

- Does a membrane material exist which will do the job?
- Is this membrane material available in a membrane module?

The answer to the first question is usually positive. A great deal of membrane research has been performed on many membrane materials and feed mixtures. In addition, a wide array of membrane materials is available; these are materials that may achieve the desired separation, but they have not been tested in a membrane mode of interest.

Another variable in the selection of membrane materials is whether a single-layer membrane or a multilayer membrane is to be used. Membranes used in an MF are normally single-layer, isotropic; membranes in other pressure-driven membrane filtrations and pervaporation are composed of composite or multiplayer, nonhomogenous materials. This is because a membrane with desired selectivity may require a significant thickness to deliver the desired physical properties, such as burst pressure; however, improving membrane mechanical stability by increasing membrane thickness would inadvertently reduce permeation flux. To get around this problem, a composite or nonhomogeneous membrane is employed, where a thick layer


of polymer material with large pore size supports a top thin layer of active membrane.

The second question is about the issue of commercial availability of membrane configurations or membrane modules for particular membrane materials. A module is the smallest unit into which the membrane material is packed. The reason for using modules is that although polymer membranes are made in two basic physical forms—flat sheet and tubular—many practical membrane systems that need large membrane areas can be accommodated only in membrane modules. For pressure-driven membrane processes, membrane distillation, and pervaporation there are four primary configurations (modules), each with inherent advantages and weaknesses: spiral wound, hollow fiber, plate-and-frame, and tubular.

### ***Membrane modules***

#### *Spiral wound module*

A spiral wound module is a logical step from a flat sheet membrane. In spiral wound modules, a flat membrane envelope or set of envelopes is rolled into a cylinder, as shown in Fig. 3.14. The envelope is constructed from two sheets of membrane, sealed on three edges. The inside of the envelope is the permeate side of the membrane. A thin porous spacer inside the envelope keeps the two sheets separated. The open end of the envelope is sealed to a perforated tube (the permeate tube) with a proper glue so that the permeate can pass through the perforations; for pervaporation, it is also the place to which the vacuum or sweep gas is applied. Another




**Figure 3.14.** A schematic illustration of a spiral wound module (courtesy of Dr. Leland Vane of USEPA).



spacer is laid on top of the envelope before it is rolled, creating the flow path for the feed liquid. This feed spacer generates turbulence due to the undulating flow path that disrupts the liquid boundary layer, thereby enhancing the feed-side mass transfer rate. It is the envelopes and spacers wrapped around the permeate tube that give the module its name, spiral wound module. The spiral wrapped envelopes and spacers are then wrapped again with tape or glass or netlike sieve before fitting into a pressure vessel. In this way, a reasonable membrane area can be housed in a convenient module, resulting in a very high surface-area:volume ratio. One noticeable drawback lies in the permeate path length. A permeating component that enters the permeate envelope farthest from the permeate tube must spiral inward several feet. Depending upon the path length, permeate spacer design, gel layer, and permeate flux, significant permeate side pressure drops can be encountered. The other disadvantage of this module is that it is a poor choice for treating fluids containing particulate matters.

#### *Hollow fiber module*

In a hollow fiber configuration, small-diameter polymer tubes are bundled together to form a hollow fiber module like a shell and tube heat exchanger (Fig. 3.15). These modules can be configured for liquid flow on the tube side, or lumen side (inside the hollow fibers), or vice versa. These tubes have diameters on the order of 100 microns. As a result, they have a very high surface-area:module-volume ratio. This makes it possible to construct compact modules with high surface areas. The drawback is that the liquid flow inside the hollow fibers is normally within the range of the laminar flow regime due to its low hydraulic diameter. The consequence




**Figure 3.15.** A schematic illustration of a hollow fiber module (courtesy of Dr. Leland Vane of USEPA).


of prevalent laminar flows is high mass transfer resistance on the liquid feed side. However, because of the laminar flow regime, the modeling of mass transfer in a hollow fiber module is relatively easy and the scale-up behavior is more predictable than that in other modules. One noticeable problem with a hollow fiber module is that a whole unit has to be replaced if failure occurs.

*Plate-and-frame module*

Plate-and-frame configuration is a migration from filtration technology and is formed by the layering of flat sheets of membrane between spacers. The feed and permeate channels are isolated from one another using flat membranes and rigid frames (Fig. 3.16). This configuration was an early favorite; it is a natural scale-up from bench-scale laboratory membrane



**Figure 3.16.** A schematic illustration of a plate-and-frame module (courtesy of Dr. Leland Vane of USEPA).



**Figure 3.17.** A schematic illustration of a tubular module.

cells that have one feed chamber and one permeate chamber separated by a flat sheet of membrane. A single plate-and-frame unit can be used to test different membranes by swapping out the flat sheets of membrane. Further, it allows the use for membrane materials that cannot be conveniently produced as hollow fibers or spiral wound elements. The disadvantages are that the ratio of membrane area to module volume is low compared to spiral wound or hollow fiber modules, dismounting is time-consuming and labor-intensive, and higher capital costs are associated with the frame structures.

### *Tubular module*

Polymeric tubular membranes are usually made by casting a membrane onto the inside of a preformed tube, which is referred to as the *substrate tube*. The tube is generally made from one or two piles of nonwoven fabric, such as polyester or polypropylene. The diameters of tubes range from 5–25 mm (Fig. 3.17). A popular method of construction of these tubes is a helically wound tape that is welded at the edges. The advantage of the tubular membrane is its mechanical strength if the membrane is supported by porous stainless steel or plastic tubes. Tubular arrangements often provide good control of flow to the operators and are easy to clean. Additionally, it is the only membrane format for inorganic membranes, particularly ceramics. The disadvantage of this type of modules is mainly higher costs in investment and operation. The arrangement of tubular membranes in a housing vessel is similar to that of the hollow fiber element. Tubular membranes sometimes are arranged helically to enhance mass transfer by creating a second flow (Dean vortex) inside the substrate tube (Moulin et al., 1999).

Although the specification for the process is the most critical issue in process design of membrane systems, certain auxiliary steps must also be considered in the operation of a membrane system. For example, temperature, pH limits, and tolerance to certain chemicals, particularly cleaning agents such as alkalis and detergents should be considered before a process is put online. These cleaning chemicals, as well as seals and glues used in the membrane modules, have to be approved by FDA or other regulatory agencies for use in food processing—an aspect of process design that is often neglected by some designers.

### ***Whose fault? Membrane fouling!***

As described in the previous sections, concentration polarization phenomena of membrane processes cause noticeable decline of membrane performance. In membrane filtration processes such as microfiltration and ultrafiltration, concentration polarization phenomena always accompany the formation of a gel layer that is either irreversible or reversible. The cause of gel layer formation is thought to be the result of the rapid accumulation of retained solutes near the membrane surface to the point that the concentration of a macromolecule solute reaches the gel-forming concentration. High retention of solutes near the membrane surface inevitably also leads to concentration polarization and, as a result, the performances of membrane filtration processes (pressure-driven processes) suffer. The version of concentration polarization in pervaporation is slightly different from its kindred in membrane filtration, as stated in the previous section. Concentration polarization also negatively affects the performance of an electro dialysis process. For membrane distillation, temperature polarization is the main culprit for the decline in the process performance.

Membrane fouling is suspected if the membrane flux is continuously declining after a period of time of operation. This is usually an irreversible, partially concentration-dependent, and time-dependent phenomenon, which distinguishes it from concentration polarization. The identification of membrane fouling is imprecise and often based upon operator's experience, performing fouling tests with membrane filtration index apparatus, and membrane vendor's recommendations. Membrane fouling is intimately related to concentration polarization, but the two are not exactly interchangeable in our description of membrane performance deterioration. We now know that all membrane filtration processes experience some degree of concentration polarization, but fouling occurs mainly in microfiltration

and ultrafiltration. Relatively large pores in these membranes are implicitly vulnerable to fouling agents such as organic and inorganic precipitates and fine particulate matters that could lodge in these pores or deposit irreversibly on the membrane surface. The exact cause of membrane fouling is very complex and therefore difficult to depict in full confidence with available theoretical understandings. Even for a known solution, fouling is influenced by a number of chemical and physical parameters such as concentration, temperature, pH, ionic strength, and specific interactions (hydrogen bonding, dipole-dipole interactions).

Membrane fouling in membrane filtration processes like concentration polarization is unavoidable—this is particularly true for protein concentration or fractionation. However, certain steps that will greatly reduce the severity of membrane fouling can still be achieved. One effective way of reducing membrane fouling is to provide pretreatment to the feed liquids. Some simple adjustments such as varying pH values and using hydrophilic membrane materials can also do wonders in protein concentration operations. There are persistent interests in modifying membrane properties to minimize the membrane-fouling tendency around the world. Because membrane fouling is intimately associated with the concentration polarization phenomenon, any action taken to minimize concentration polarization will also benefit the fight against membrane fouling. Unfortunately, no matter how much effort put forward fighting membrane fouling, it will eventually occur. The only solution by then is employing a cleaning regimen. The frequency of cleaning depends upon many factors and should be considered as a part of a process optimization exercise. There are three basic types of cleaning methods currently used: hydraulic flushing (back-flushing), mechanical cleaning (only in tubular systems) with sponge balls, and chemical washing. When using chemicals to perform defouling, cautions must be observed because many polymeric membrane materials are susceptible to chlorine, high pH solutions, organic solvents, and a host of other chemicals.


## **Ion Exchange**

Ion exchange is a process in which ions of a particular species in solution are replaced by ions with a similar charge but of different species attached to an insoluble resin. In essence, ion exchange is a sorption process and can also be considered a reversible chemical reaction. The common appli-


cations of ion exchange are water softening (removal of “hardness” ions such as  $\text{Ca}^{2+}$  and  $\text{Mg}^{2+}$ ) and nitrate removal in advanced wastewater treatment operations. These ion exchange resins are either naturally occurring inorganic zeolites or synthetically produced organic resins. The synthetic organic resins are the predominant type used today because their characteristics can be tailored to specific applications.

An organic ion exchange resin consists of an organic or inorganic network structure with attached functional groups that can exchange their mobile ions for ions of similar charge from the surrounding medium. Each resin has a distinct number of mobile ion sites that set the maximum quantity of exchanges per unit of resin. Ion exchange resins are called *cationic* if they exchange positive ions and *anionic* if they exchange negative ions. Cation exchange resins have acidic functional groups such as sulfonic, whereas anion exchange resins are often classified by the nature of the functional group as strong acid, weak acid, strong base, and weak base. The strength of the acidic or basic character depends on the degree of ionization of the functional groups, similar to the situation with soluble acids or bases. Accordingly, a resin with sulfonic acid groups would act as a strong cation exchange resin.

Ion exchange reactions are stoichiometric and reversible, and in that way they are similar to other solution phase reactions—for example (Equation 3.38):




In this reaction, the magnesium ions of the magnesium sulfate ( $\text{MgSO}_4$ ) are exchanged for the calcium ions of the calcium hydroxide  $\text{Ca(OH)}_2$  molecule. Similarly, a resin with hydrogen ions available for exchange will exchange those ions for magnesium ions from solution. The reaction can be written as follows (Equation 3.39):



R indicates the organic portion of the resin and  $\text{SO}_3$  is the immobile portion of the ion active group. Two resin sites are needed for magnesium ions with a plus 2 valence ( $\text{Mg}^{+2}$ ).


As stated previously, the ion exchange reaction is reversible. The degree the reaction proceeds to the right will depend on the resins preference or selectivity for magnesium ions compared with its preference for hydrogen

ions. The selectivity of a resin for a given ion is measured by the selectivity coefficient,  $K$ , which in its simplest form for the following reaction (Equation 3.40):



is expressed as:  $K = (\text{concentration of } B^+ \text{ in resin} / \text{concentration of } A^+ \text{ in resin}) \times (\text{concentration of } A^+ \text{ in solution} / \text{concentration of } B^+ \text{ in solution})$ .

The selectivity coefficient expresses the relative distribution of the ions when a resin in the  $A^+$  form is placed in a solution containing  $B^+$  ions. Table 3.1 shows the selectivities of strong acid and strong base ion exchange resins for various ionic compounds. It should be pointed out that the selectivity coefficient is not constant but varies with changes in solution conditions. It does provide a means of determining what to expect when various ions are involved. As indicated in Table 3.1, strong acid resins have a preference for magnesium over hydrogen. Despite this preference, the resin can be converted back to the hydrogen form by contact with a concentrated solution of sulfuric acid ( $H_2SO_4$ ) (Equation 3.41):



This step is known as regeneration. In general terms, the higher the preference a resin exhibits for a particular ion, the greater the exchange efficiency in terms of resin capacity for removal of that ion from solution.

**Table 3.1.** Selectivity of ion exchange resins for some ions in order of decreasing preference (*source*: Weber, 1972).


Strong Acid Cation Exchanger	Strong Base Anion Exchanger
Barium	Iodide
Calcium	Nitrate
Copper	Bisulfite
Zinc	Chloride
Magnesium	Cyanide
Potassium	Bicarbonate
Ammonia	Hydroxide
Sodium	Fluoride
Hydrogen	Sulfate

Greater preference for a particular ion, however, will result in increased consumption of chemicals for regeneration.

Ion exchange resins are classified as cation exchangers that have positively charged mobile ions available for exchange, and anion exchangers, whose exchangeable ions are negatively charged. Both anion and cation resins are produced from the same basic organic polymers. They differ in the ionizable group attached to the hydrocarbon network. It is this functional group that determines the chemical behavior of the resin. Resins can be broadly classified as strong or weak acid cation exchangers or strong or weak base anion exchangers.

### ***Strong acid cation resins***

Strong acid resins are so named because their chemical behavior is similar to that of a strong acid. The resins are highly ionized in both the acid (R-SO<sub>3</sub>H) and salt (R-SO<sub>3</sub>Na) form. They can convert a metal salt to the corresponding acid by the reaction (Equation 3.42):



The hydrogen and sodium forms of strong acid resins are highly dissociated and the exchangeable Na<sup>+</sup> and H<sup>+</sup> are readily available for exchange over the entire pH range. Consequently, the exchange capacity of strong acid resins is independent of solution pH. These resins would be used in the hydrogen form for complete deionization; they are used in the sodium form for water softening (calcium and magnesium removal). After exhaustion, the resin is converted back to the hydrogen form (regenerated) by contact with a strong acid solution, or the resin can be converted to the sodium form with a sodium chloride solution. Hydrochloric acid (HCl) regeneration would result in a concentrated magnesium chloride (MgCl<sub>2</sub>) solution.

### ***Weak acid cation resins***

In a weak acid resin, the ionizable group is a carboxylic acid (COOH) as opposed to the sulfonic acid group (SO<sub>3</sub>H) used in strong acid resins. These resins behave similarly to weak organic acids that are weakly dissociated.


Weak acid resins exhibit a much higher affinity for hydrogen ions than do strong acid resins. This characteristic allows for regeneration to the hydrogen form with significantly less acid than is required for strong acid



resins. Almost complete regeneration can be accomplished with stoichiometric amounts of acid. The degree of dissociation of a weak acid resin is strongly influenced by the solution pH. Consequently, resin capacity depends in part on solution pH.

### ***Strong base anion resins***

Like strong acid resins, strong base resins are highly ionized and can be used over the entire pH range. These resins are used in the hydroxide (OH) form for water deionization. They will react with anions in solution and can convert an acid solution to pure water (Equation 3.43):



Regeneration with concentrated sodium hydroxide (NaOH) converts the exhausted resin to the hydroxide form.

### ***Weak base anion resins***

Weak base resins are like weak acid resins in that the degree of ionization is strongly influenced by pH. Consequently, weak base resins exhibit minimum exchange capacity above a pH of 7.0. These resins merely sorb strong acids: they cannot split salts.

### ***Evaluation of resins***

Resin vendors usually provide detailed information regarding the properties of resins they sell, as is shown in a typical ion exchange resin property sheet from DOW Chemical (Table 3.2). However it is still sensible to evaluate the resins in service for any change in capacity of the resins. The potential loss of active ion exchange sites, due to reduction of cross-linking and other deleterious effects of long-term services, is of particular concern. The common properties of resins for uses in wastewater treatment undergoing evaluations are

- Dry weight capacity
- Wet weight capacity
- Wet volume capacity
- Percentage of moisture content

**Table 3.2.** A commercial ion exchange resin property sheet (courtesy of DOW Chemical Company).

Commercial Name	DOWEX®* 1 X . . .	DOWEX® 50 WX . . .
<b>Type</b>	<b>Strongly Basic Anion Exchanger</b>	<b>Strongly Acid Cation Exchanger</b>
Functional group	Trimethyl ammonium	Sulfonic acid
Cross linkage (% DVB)	2 or 8	2, 4, or 8
Ionic form as shipped	Cl <sup>-</sup>	Na <sup>+</sup> (analytical grade) H <sup>+</sup> (practical grade)
Shipping density (kg/l)	0.7	0.8
Volume change (%)	Cl <sup>-</sup> → OH <sup>-</sup> ~ + 20 %	Na <sup>+</sup> → H <sup>+</sup> ~ + 8 %
Effective working range (pH)	0 – 14	0 – 14
Selectivity for ions	I <sup>-</sup> > NO <sub>3</sub> <sup>-</sup> > Br <sup>-</sup> > Cl <sup>-</sup> > acetate <sup>-</sup> > OH <sup>-</sup> > F <sup>-</sup>	Ag <sup>+</sup> > Cs <sup>+</sup> > Rb <sup>+</sup> > K <sup>+</sup> > NH <sub>4</sub> <sup>+</sup> > Na <sup>+</sup> > Li <sup>+</sup> > Ba <sup>2+</sup> > Sn <sup>2+</sup> > Ca <sup>2+</sup> > Mg <sup>2+</sup> > Be <sup>2+</sup>
Total exchange capacity (eq/l)	1.3 OH <sup>-</sup> form max. 50°C (122°F)	1.9 Na <sup>+</sup> form max. 120°C (248°F)
Thermal stability	Cl <sup>-</sup> form max. 150°C (302°F)	H <sup>+</sup> form max. 80°C (176°F)
Moisture (%)	39 – 80	40 – 82

\*DOWEX® is a registered trademark of Dow Chemical Company.

### ***Ion exchange systems***


In order to design an ion exchange system for removing ions from complex food and agricultural wastewater, several runs of a laboratory scale ion exchange column are necessary to develop system design criteria. Eckenfelder (1989) suggested an experimental procedure for conducting experiments on a lab-scale ion exchange column:

1. Rinse the column for 10 minutes with deionized water at a rate of 50 ml/min.
2. Switch to a waste-containing solution passing through the column at the same flow rate as deionized water.
3. Measure the initial volume of solution to be treated.
4. Start the treatment cycle and develop the breakthrough curve until the ion concentration reaches the maximum effluent limit.

5. Backwash to 25% bed expansion for 5–10 minutes with distilled water.
6. Regenerate at a flow rate of 6 ml/min using the concentration and volume recommended for the resin by the vendor and collect the spent regenerant and measure the recovered ions.
7. Rinse the column with distilled water.


After several runs of the experiment, it is possible to select optimal operating conditions in terms of resin utilization and regenerant efficiency.

Most practical applications of ion exchange use fixed-bed column systems, the basic component of which is the resin column. Complete demineralization operations generally involve the wastewater passing first through a bed of strong acid resin to replace metal ions with hydrogen ions (thus lowering the pH) followed by a weakly basic anion exchanger as shown in Fig. 3.18 of a schematic diagram of this two-stage type of arrangement. Weak base resins are preferred over strong base resins be-



**Figure 3.18.** A schematic diagram of a two-stage ion exchange system.

cause they require less regenerant chemical. A reaction between the resin in the freebase form and HCl would proceed as follows (Equation 3.44):




The weak-base resin does not have a hydroxide ion form, as does the strong-base resin. Consequently, regeneration needs only to neutralize the absorbed acid; it need not provide hydroxide ions. Less expensive weakly basic reagents such as ammonia ( $\text{NH}_3$ ) or sodium carbonate can be employed.

Ion exchanger systems used for wastewater treatment have been based on a process called DESAL (Downing et al, 1968), which utilizes a three-step operation:

1. A weak base anion resin in the bicarbonate form,  $\text{R}-(\text{NH})\text{HCO}_3$
2. A weak acid cation in the hydrogen form,  $\text{R}-\text{COOH}$
3. A weak base anion resin in the free base form

A schematic diagram of the DESAL process is shown in Fig. 3.19.



**Figure 3.19.** A schematic diagram of the DESAL ion exchange system.

**Chapter Remarks**

For organic-rich food and agricultural wastewater, biological treatment has its unrivaled advantages. However, physicochemical processes are still important in treating this type of wastewater stream. First, physicochemical treatment plants have small footprints; this is important for densely populated areas. Second, physicochemical processes can be easily expanded as and when required—for example, if subsequent treatment using biological methods is planned. Third, the processes are often fast compared to biological treatment; they may be included as integral parts of an overall wastewater management strategy if the influent streams are mixed with municipal or other industrial wastewater. Finally, certain pollutants in wastewater are not biodegradable, thus requiring physicochemical processes to remove them.

The disadvantages of physicochemical processes are well known: high operating and capital costs, relatively modest treatment performance, and larger sludge volume. It is not accidental that physicochemical processes in practice are often interspersed with biological treatment processes to achieve optimal results. The ultimate choices of physicochemical processes for a given treatment task are largely dependent upon the deliberate consideration of technological and economical facts within the constraints of treatment requirements and regulatory compliance.

One of the most challenging aspects of treatment process design is the analysis and selection of the treatment processes capable of meeting the permit or recycling requirements. The methodology of process analysis that leads to process selection includes several evaluation steps. These evaluations vary greatly with the project and characteristics of wastewater. Nevertheless, any process analysis needs to consider several important factors: process applicability, applicable flow range and variation, reaction kinetics and reactor selection, performance, treatment residuals and odor, sludge treatment, chemicals/polymers requirements, and energy requirements. Once process analysis is done, process selection or design commences; several methods of process design or selection may be considered—process selection based on empirical relationship from experience or literature and process design based on kinetic analysis or modeling. Chapter 1 provides the basic tools to assist the selection process.

## Further Reading

- Weber, Walter J., Jr. 1972. *Physicochemical Process: For Water Quality Control*. New York: John Wiley & Sons.
- Visvanathan, C. and Ben Aim, Roger. 1989. *Water, Wastewater, and Sludge Filtration*. Boca Raton, FL: CRC Press.
- Metcalf and Eddy, Inc. (Tchobanoglous, G. and Burton, F.L.). 1991. *Wastewater Engineering, Treatment, Disposal, and Reuse*, 3rd edition. New York: McGraw-Hill, Inc.
- Droste, Ronald L. 1996. *Theory and Practice of Water and Wastewater Treatment*. New York: John Wiley & Sons.
- Eckenfelder, W. Wesley, Bowers, Alan R., and Roth, John A. 1996. *Chemical Oxidation: Technology for the Nineties, Volume IV*, Boca Raton, FL: CRC Press.
- Cooney, David O. 1998. *Adsorption Design for Wastewater Treatment*. Boca Raton, FL: CRC Press.
- Qusim, Syed R. 1998. *Wastewater Treatment Plants: Planning, Design, and Operation, Second Edition*. Boca Raton, FL: CRC Press.
- Drinan, Joanne E. 2000. *Water and Wastewater Treatment: A Guide for the Nonengineering Professionals*. Boca Raton, FL: CRC Press.
- Lin, Shun Dar and C.C. Lee. 2001. *Water and Wastewater Calculations Manual*. New York: McGraw-Hill Professional.
- Hahn, H., Hoffman, E., and Odegaard, H. 2002. *Chemical Water and Wastewater Treatment VII: (Gothenburg Symposia)*. London: IWA Publishing.
- Tang, Walter Z. 2003. *Physicochemical Treatment of Hazardous Wastes*. Boca Raton, FL: Lewis Publishers (CRC Press).
- Parsons, Simon. 2005. *Advanced Oxidation Processes for Water and Wastewater Treatment*. London: IWA Publishing.

## References

- Canale, R.P. and Borchardt, J.A. 1972. "Sedimentation." In Walter J. Weber, Jr., *Physicochemical Process: For Water Quality Control*. New York: John Wiley & Sons.
- Cheryan, M. 1986. *Ultrafiltration Handbook*. Lancaster, PA: Technomic Publishing Co.
- Davis, T.A. 1990. "Electrodialysis." In *Handbook of Industrial Membrane Technology*. Porter, M.C., ed. Park Ridge, NJ: Noyes Publications.
- Downing, D.G., Kunin, R., and Pollio, F.X. 1968. "DESAL process—Economic ion exchanger system for treating brackish and acid mine drainage waters and sewage waste effluents." *Water—1968*. Chemical Engineering Progress Symposium Series, 64, 90. American Institute of Chemical Engineers, New York.
- Eckenfelder, W. Wesley. 1989. *Industrial Water Pollution Control*, 2nd edition. New York: McGraw-Hill, Inc.
- Glasgow, L.A. and Liu, S.X. 1995. "Effects of Macromolecular Conformation upon Solid-Liquid Separation and Water Treatment Plant Residuals," *Environmental Technology* 16: 915–927.

- Liu, S.X. 1995. *The Essential Aspects of Floc Structure and Breakage*. Chemical Engineering Department, Kansas State University, Manhattan, KS.
- López-Leiva, M. 1988. "The use of electro dialysis in food processing, II. Review of practical applications." *Lebens-mittel Wissenschaft und Technologie* 21: 177–182.
- Metcalf and Eddy, Inc. (Tchobanoglous, G. and Burton, F.L.). 1991. *Wastewater Engineering, Treatment, Disposal, and Reuse*. 3rd edition, New York: McGraw-Hill, Inc.
- Moulin, P., Manno, P., Rouch, J.C., Serra, C., Clifton, M.J., and Aptel, P. 1999. "Flux improvement by dean vortices: Ultrafiltration of colloidal suspensions and macromolecular solutions." *Journal of Membrane Science* 156: 109–130.
- Mulder, M. 1991. *Basic Principles of Membrane Technology*; Dordrecht, Germany: Kluwer Academic Publishers.
- Rautenbach, R. and Albrecht, R. 1989. *Membrane Processes*. Chichester, Britain: John Wiley & Sons.
- Rosenberg, M. 1995. "Current and future applications for membrane processes in the dairy industry." *Trends in Food Science and Technology* 6: 12–19.
- Weber, J.W., Jr. 1972. *Physicochemical Processes for Water Quality Control*. 640pp. New York: John Wiley & Sons.

4

## BIOLOGICAL WASTEWATER TREATMENT PROCESSES

---

### **Introduction**

Biological wastewater treatment is often associated with secondary wastewater treatment and intends to treat the dissolved and colloidal organics after primary treatment. The goal of all biological wastewater treatment systems is to coagulate and remove or reduce the nonsettling organic solids and the dissolved organic load from the effluents by using microbial communities to degrade the organic load through biochemical reactions. Biological wastewater treatment is generally a major part of secondary treatment design of wastewater and characterized by reduction of the oxygen demand of an influent wastewater to a given level of purification. The microorganisms responsible for reducing the organic matters and consequently the oxygen demand of incoming wastewater can be classified based on the way in which they utilize oxygen: aerobic (need oxygen for their metabolism), anaerobic (thrive in the absence of oxygen), or facultative (can live on oxygen and live without it through different metabolisms). Aerobic biological treatment dominates secondary wastewater treatment scenes and is performed in the presence of oxygen by aerobic microorganisms (principally bacteria) that metabolize the organic matter in the wastewater, thereby producing more microorganisms and inorganic end products (principally  $\text{CO}_2$ ,  $\text{NH}_3$ , and  $\text{H}_2\text{O}$ ). Several aerobic biological processes are used for secondary treatment, differing primarily in the manner in which oxygen is supplied to the microorganisms and in the rate at which organisms metabolize the organic matter. From a nutritional point of view, the majority of microorganisms in biological wastewater treatment systems uses the organic matters in the wastewater as the energy source for growth and maintenance of microorganisms.



Anaerobic processes sometimes are also used in the secondary biological treatment of wastewater. Anaerobic processes, in addition to sludge digestion, are employed to treat high-strength wastewater, such as high-strength food-processing wastewater streams when the prospect of difficulty associated with oxygen supply to the reactor and large biomass produced in an aerobic process is deemed uneconomical.

In secondary wastewater treatment, sedimentation is also employed to remove settleable solids after microorganisms have done their work. The microorganisms must be separated from the treated wastewater by sedimentation to produce clarified secondary effluent. The sedimentation tanks used in secondary treatment, often referred to as *secondary clarifiers*, operate in the same basic manner as the primary clarifiers described in Chapter 3. The biological solids removed during secondary sedimentation, called *secondary* or *biological sludge*, are normally combined with primary sludge for sludge processing. The main difference between sedimentation in a secondary treatment reactor (tank/basin) and sedimentation in a primary treatment reactor (tank/basin) is that sludge in the secondary treatment is composed of biological cells. There are two main types of bioreactors used in the secondary treatment: those where microorganisms are attached to a fixed surface (e.g., trickling filter), and those where microorganisms run freely in the wastewater stream (e.g., activated sludge). The sludge settled in the sedimentation tank in the latter type of reactors is usually recycled back to the system for continuing operations.

Widespread high-rate processes in relatively small reactors include the activated sludge processes, trickling filters, and RBSs (rotating biological contactors). A combination of two of these processes in series (e.g., trickling filters followed by activated sludge) is sometimes used with certain wastewaters containing a high concentration of organic materials from industrial sources, such as food and agricultural processing.

Because a secondary treatment process uses microorganisms to break down the organic matters in order to clarify the wastewater, it is important to know the biology of the secondary wastewater treatment process. The most widely present microorganisms in wastewater treatment are bacteria, and this group of microorganisms is responsible for degrading organic matters present in the wastewater. The following section is centered on bacteria's role in biological wastewater treatment; the essence of the description, however, is applicable to all microorganisms in biological conversions in biochemical systems.

### Kinetics of Biochemical Systems in Wastewater Microbiology

The fundamentals of wastewater microbiology include the roles of microbial groups in specific biological transformation of wastewaters, nutritional requirements, the effects of environmental conditions on microbial activities, and enzymatic reactions that underpin biological conversions of waste materials.

Chapter 2 presents the classifications of various microbial groups and their roles in biological wastewater treatment based on cell structures and function as eukaryotes and prokaryotes. However, microorganisms in wastewater treatment can also be described based on nutritional requirements. Like all living things, nutrients play a critical role in development of microbial communities; they supply the energy source for cell growth and biosynthesis and provide the materials necessary for synthesis of cytoplasmic materials, as well as serve as electron acceptors from biochemical reactions. The nutritional requirements provide a basis of microorganism classifications based on carbon source and energy source. Fig. 4.1 illustrates a general classification of microorganisms based on nutritional requirements.

Environmental factors such as temperature, pH, and oxygen requirements for aerobic or facultative microorganisms are of great importance to microbial growth or even survival. The temperature effect on microbial




Figure 4.1. Classification of microorganisms based on nutritional requirements.


growth tends to be positive; however, overheating may inhibit or kill microorganisms. The effects of pH on microbial communities are more varied; some microorganisms do well in slightly alkaline conditions—such as most bacteria with pH ranging from 6.5 to 7.4—but fungi prefer slightly acidic conditions. Oxygen requirements are critically important for aerobes and are optional for facultative bacteria. Anaerobes are not affected by absence of oxygen; they thrive without it.

Bioconversion of organic matters by microorganisms takes place in a series of biochemical reactions with participation of a class of biological catalysts called *enzymes*. Enzymes are specific proteins that catalyze reactions but do not undergo permanent changes themselves. They work by forming complexes with organic substrate and inorganic molecules, facilitating reaction of these substances resulting in end products, and releasing the enzymes in the original state so the biochemical reaction cycle can continue. Enzymes are substrate-specific; thus, bacteria usually have many different enzymes performing different catalytic roles in converting a broth of organic substances into end products. In general, these enzymes belong to one of two groups: extracellular and intracellular. As the names suggest, extracellular enzymes convert organic substances outside the cell into a form of intermediate products; intracellular enzymes can take over from there to complete the biochemical reactions within the cells. These enzymatic reactions often occur sequentially among different enzymes in a cell. A portion of the organic substrate that attaches to the enzyme is utilized as an energy source while the remainder is scavenged to reproduce more cells.

The microbial population of biological wastewater treatment systems contains a large number of species of microorganisms with diverse physiological and genetic variations; as a result, the properties of the colony in wastewater systems may be described only as averaged behaviors of the microbial population. Additionally, the properties of the microbial population are described in terms of easily quantifiable parameters. For example, the size of the population is often measured in dry weight or nitrogen content because microbial colonies are established along the line of functionally discrete units or cell mass. Thus, the microbial population in wastewater treatment systems is considered a mixture of microorganisms as biomass distributed continuously in treatment systems (or reactors). With that view, we can treat biochemical reactions involving microbial populations in reactors as averaged reactants (biomass and organic substrate) undergoing enzymatic reactions. The models that describe characteristics of these abstract “reactants” are therefore *deterministic* despite

the fact that the behaviors of individual cells within the microbial community can only be described only as *stochastic*.

The kinetic models that describe biological conversion of organic matters in wastewater are those of the reactions that result in changes in concentration of an organic substrate or microorganism responsible for the conversion and may be modeled using simple reaction rate theory, which describes the rate of change in concentration of an organic substrate or microorganism (Equations 4.1 and 4.2):



$$\text{rate} = k (\text{concentration of A})^n$$

The rate of reaction can further be expressed as the following (Equation 4.3):

$$-r = kC_A^n$$

where  $k$  is the reaction rate constant,  $C_A$  is concentration of species A (substrate or biomass), and  $n$  is the order of the reaction. The negative sign in the equation signifies the disappearing of reactant A as the reaction progresses. The order of reaction is a parameter that reflects the kinetics of a biochemical reaction and can theoretically be any number, but often it is one of the three basic reaction kinetics: zero-order, first-order, and second-order, as described in Chapter 1.

Taking the log on both sides of Equation 4.2 yields the following (Equation 4.4):

$$\log r = n \log(\text{concentration of reactant A}) + \log k$$

A plot of  $\log r$  versus  $\log C_A$  will produce a linear line with a slope of  $n$ .

### ***Effects of temperature on reaction rates***

Like any other reactions, the effects of temperature on reaction rates originate from the temperature effects on rate constants. Rate constant,  $k$ , is a lumped parameter that encompasses many environmental factors, such as pH; oxygen concentration; concentrations of trace elements; and, in the

case of photosynthesis, light intensity. One particularly important parameter is temperature, which affects the rates of both chemical and biochemical reactions. It is observed by Van't Hoff that a reaction rate roughly doubles for every 10°C increase in temperature. The effects of temperature on reaction rates often follow the Arrhenius model (Equation 4.5):

$$k = Ae^{-\frac{E_A}{RT}}$$

where T is the absolute temperature or thermodynamic temperature in Kelvin,  $E_A$  is activated energy that reactants must overcome in order to proceed with reactions, R is the gas constant ( $R = 8.314 \text{ J K}^{-1} \text{ mol}^{-1}$ ), and A is the preexponential factor or frequency factor that is related to the collision frequency of reactants.

The Arrhenius equation is widely used in wastewater treatment systems to model the effects of temperature on reactions. It first starts with taking the derivative of Equation 4.5 and is then integrated between the limits  $T_0$  and  $T_f$ ; this gives the following (Equation 4.6):

$$\frac{k_f}{k_0} = \left( \frac{E_A}{RT_f T_0} \right)^{(T_f - T_0)}$$

where  $k_0$  and  $k_f$  are the rate constants at temperatures of  $T_0$  and  $T_f$ , respectively. The reason for taking the derivative and following with integration is that the rate constant is a function of time. Equation 4.6 has been used in the temperature range of 5–25°C; outside this range, the equation is not valid due to significant change in microbial composition in the microbial population.

### ***Effects of pH and dissolved oxygen concentration on reaction rates***

Effects of pH and dissolved oxygen concentration on reaction rates are more substrate-specific. The optimum pH range for carbonaceous oxidation lies in the range of 6.5–8.5. At pH above 9.0, microbial activity is inhibited. At pH below 6.5, fungi dominate over the bacteria in the competition for the substrate. Some types of reactors are less affected by fluctuations of influent pH; obviously, completely mixed reactors, such as CSTRs, will minimize the effect of pH fluctuation. If the pH fluctuation is significant, some adjustment to pH may be needed. Some bacteria have

less tolerance toward pH fluctuation than others; for example, anaerobic bacteria have a viable pH range of 6.7–7.4, with optimum growth occurring in pH 7.0–7.1.


Dissolved oxygen (DO) concentration obviously affects rates of reactions in aerobic biochemical reactions. For instance, DO concentration of 1–2 mg/l may be sufficient for active aerobic heterotrophic microbial activity provided that sufficient nutrients and trace elements are available to microbial activities.

### ***Kinetic equations of bacterial growth***

The kinetics of biochemical reactions in bioreactors described in the previous sections and in Chapter 1 are simplified mathematical descriptions that are not all-inclusive in terms of all aspects of the mechanisms under consideration. Successful environmental control in biological wastewater treatment, however, is rooted in an understanding of the basic principles governing the growth of microorganisms where substrates are assimilated and biomass in the system accumulates. The studies of microorganism growth in pure media under controlled pH, temperature, oxygen concentration, and other substances have produced reliable kinetic models of microorganism growth.

The general growth pattern of bacteria in a batch culture is illustrated in Fig. 4.2. The diagram is a record of a number of viable microorganisms in the culture medium of fixed volume over time. The pattern of the curve shown in Fig. 4.2 shows four distinct phases: the lag phase, the log-growth phase, the stationary phase, and the log-death phase:

- *The lag phase.* Once the inoculum is introduced in the culture medium, the microorganisms take time to acclimate themselves in the environment.
- *The log-growth phase.* This is the normal growth pattern under sufficient food (organic substrate) and nutrients for microbial growth.
- *The stationary phase.* The microbial population is stabilized as a result of a stand-off between growth of microorganisms and death of old cells. Usually, there is some insufficiency of substrate and/or nutrients available for microbial growth.
- *The log-death phase.* During this phase, the death rate of microbial cells exceeds the growth rate of new cells. This is an indication of deteriorating environmental conditions in addition to lack of substrate.



**Figure 4.2.** A diagram of a number of viable microorganisms in the culture medium of fixed volume over time.

The common autocatalytic equation, a first-order reaction, is used to describe the log-growth phase (Equation 4.7):

$$r_x = \frac{dX}{dt} = \mu X$$

where  $r_x$  is the rate of production of viable bacteria,  $X$  is the concentration of viable microorganisms, and  $\mu$  is the specific growth rate constant ( $t^{-1}$ ). If the cell concentration of microbial cells at  $t_0$  is  $X_0$ , then after a time interval,  $t$ , the viable cell concentration  $X_t$  is the following (Equation 4.8):

$$X_t = X_0 e^{\mu t}$$

Taking logs of Equation 4.8 shows a linear relationship between  $\ln X$  and  $\ln X_0$ .

When cell concentration doubles between  $t_d$  and  $t_0$ , it shows the following relationship (Equation 4.9):

$$2X_0 = X_0 \exp(\mu t_d) \quad 2 = \exp(\mu t_d) \quad \ln 2 = \mu t_d$$

There are several models that relate cell growth to substrate utilization; Monod model is the most widely used model. Monod model describes the relationship between the residual concentration of the cell-growth limiting substrate or nutrient and the specific growth rate of biomass of cells,  $\mu$  in the following mathematical expression (Equation 4.10):

$$\mu = \mu_m \frac{S}{S + k_s}$$

where  $\mu_m$  is the maximum specific growth rate at saturation concentration of the growth limiting substrate;  $S$  is the substrate concentration; and  $k_s$  is the saturation constant (mg/l), which is the concentration of growth-limiting substrate at which the specific growth rate  $\mu = \mu_m/2$ .

### Idealized Biochemical Reactors

Almost all bioreactors used for kinetics studies, whether batch or continuous reactors are the types of well-mixed reactors. Two well-mixed reactors are briefly described in the next several sections: the ideal batch reactor and the ideal continuous-flow stirred-tank reactor (CSTR).

#### *The ideal batch reactor*

In a batch reactor, the concentrations of nutrients, substrates, products, and bacterial cells vary with time as the microbial growth proceeds.

A molar material balance on component A in a batch reactor yields the following relation (Equation 4.11):

$$\frac{d}{dt} \left[ \left( \frac{\text{culture}}{\text{volume}} \right) \left( \frac{\text{molar concentration}}{\text{of component A}} \right) \right] = \left( \frac{\text{culture}}{\text{volume}} \right) \cdot \left( \frac{\text{moles A formed by reaction}}{\text{unit culture volume} \cdot \text{unit time}} \right)$$



Or, mathematically the following (Equation 4.12):

$$\frac{d}{dt}(V_R \cdot C_A) = V_R \cdot r_A$$

where  $V_R$  is culture volume,  $C_A$  is molar concentration, and  $r_A$  is reaction rate. The volume of the batch reactor is not the culture volume,  $V_R$ , unless the reactor is full.  $V_R$  is often considered as constant as long as there is not addition or removal of liquids from the reactor. This fact leads to the following simplification (Equation 4.13):

$$\frac{dC_A}{dt} = r_A$$

In order to calculate the change in concentration of component A, Equation 4.13 needs to be integrated over the time period,  $t-t_0$  (Equation 4.14):

$$\int_{C_{A0}}^{C_A} \frac{dC_A}{r_A} = \int_{t_0}^t dt = t - t_0$$

where  $C_{A0}$  is the concentration of A at time,  $t_0$ . The function that relates  $r_A$  to  $t$  can be obtained based on the order of the reaction; the kinetic equations of biochemical reactions described in Chapter 1 can be used to solve Equation 4.14.

### ***The ideal plug-flow reactor***

The plug-flow reactor is also called a *piston-flow reactor*. All materials leaving the plug-flow reactor will have been in the reactor for the same length of time. It is assumed that there is no longitudinal mixing or diffusion. A mathematical derivation of a plug-flow reactor, as shown in Fig. 4.3, can be made based on material balance for an element of reactor volume,  $dV$ , for a component A (Equation 4.15):


input – output = disappearance due to reaction

since input =  $F_A$ ,

output =  $F_A + dF_A$

and disappearance =  $-r_A dV$ ; so

$$F_A = F_A + dF_A + (-r_A)dV$$



**Figure 4.3.** A schematic diagram of a plug-flow reactor.

where  $F_A$  is the flow rate of material A.

Because

$$d = d[F_{A0} (1 - X_A)] = - F_{A0} dX_A$$

So Equation 4.15 becomes


$$F_{A0} dX_A = (-r_A)dV$$

$$\frac{dV}{F_{A0}} = \frac{dX_A}{-r_A}$$

This can be integrated to produce the governing equation for a plug-flow reactor,

$$\frac{C_{A0}V}{F_{A0}} = r_A = C_{A0} \int_0^{X_A} \frac{dX_A}{-r_A}$$

where  $C_{A0} = F_{A0}/V$  and  $r_A$  can be a zero, first, or second order reaction.



**Figure 4.4.** A schematic diagram of a CSTR type of reactor.

### *Ideal continuously stirred tank reactor (CSTR)*

Fig. 4.4 schematically depicts a CSTR type of reactor. In CSTRs, the liquid inside the reactor is completely mixed. The mixing is provided through an impeller, rising gas bubbles (usually oxygen), or both. The most characteristic feature of a CSTR is that it is assumed that the mixing is thorough and complete such that the concentrations in any phase do not change with position within the reactor.

As indicated in Fig. 4.4, the dissolved oxygen in the tank is the same throughout the bulk liquid phase. Because of this uniformity of oxygen distribution in the reactor, a CSTR for wastewater treatment operations has the advantage of decoupling the aerator or stirrer from the reaction as long as oxygen is well provided for (no need to consider pesky fluid mechanics), thus simplifying process design and optimization. Under the steady state, where all concentrations within the reactor are independent of time, we can apply the following materials balance on the reactor (Equation 4.20):

$$\left[ \begin{array}{l} \text{Rate of addition} \\ \text{to reactor} \end{array} \right] + \left[ \begin{array}{l} \text{Rate of accumulation} \\ \text{within reactor} \end{array} \right] = \left[ \begin{array}{l} \text{Rate of removal} \\ \text{from reactor} \end{array} \right]$$

Replacing the statements in the above expression with mathematical symbols leads to the following (Equation 4.21):

$$FC_{A0} + V_R r_A = FC_A \quad F(C_{A0} - C_A) = -V_R r_A$$

where  $F$  is the volumetric flow rate of feed and effluent liquid streams.

Rearrangement of Equation 4.21 yields the following (Equation 4.22):

$$r_A = \frac{F}{V_R}(C_A - C_{A0}) = D(C_A - C_{A0})$$

where  $D = F/V_R$  and is called the *dilution rate*. The term characterizes the holding time or processing rate of the reactor under steady state condition. It is the number of tankful volumes passing through the reactor tank per unit time and equal to the reciprocal of the mean holding time of the reactor.

Because of lack of time dependence of concentrations in CSTR and thus differential form of reactor analysis as in a batch reactor, CSTRs have the advantage of being well-defined, easily reproducible reactors and are used frequently in many cell growth kinetics studies despite relatively high cost and long time for achieving steady state. Batch reactors, which can be as simple as a sealed beaker or flask and used in large number simultaneously in an incubator shaker, are still widely used for their inexpensive, quick, and unbridled benefits. No matter what type of reactor is used, the goal of studying cell growth kinetics should be based on the intended application and scope of the use of the kinetics. Only then, the experimental design and implementation may be formulated.

### Completely Mixed Aerated Lagoon (CMAL)

Lagoons are one of the oldest wastewater treatment systems created by mankind. They consist of lined in-ground earthen basins in which the wastewater is detained for a specified time (detention time) and then discharged. The size and depths can vary, as well as the degree of treatment. Although these lagoons, or ponds as they are sometimes called, are very simple in design, there are complex chemical, biological and physical processes occurring. There are five main types of lagoons: facultative lagoon (stabilization pond), aerobic lagoon, anaerobic lagoon, partial mixed aerated lagoon, and completely mixed aerated lagoon.

A completely mixed aerated lagoon in wastewater treatment is a relatively shallow basin (with a depth between 5 and 15 feet, or between 152 cm and 457 cm) with a large surface area (of several acres), which operates on a flow-through mode, in many ways similar to CSTRs. They are

designed and operated to exclude algae by completely mixing the solids and therefore blocking all light. The earthen basin is generally lined with impervious material such as asphalt or plastic. The complete mixing is achieved through the use of mechanical surface aerators of either the fixed or floated type. The mixing energy must be sufficient enough so that all solids are suspended and light is reduced in the wastewater to the extent that very little algal growth occurs (because the control of algal growth is crucial in the reduction of effluent suspended solids). The holding time in a CMAL is typically 7 to 10 days. The degree of treatment is a function of the mass of organic matters in suspension and holding time.

The microbial population in a CMAL is predominately heterotrophic, and aerobic respiration is the path of metabolism of the microbial population in excess of oxygen. The bacteria in a CMAL utilize the organic matters, and other higher-ups, such as protozoans, rotifers, daphnia, and insect larvae in the food chain are likely to chew on these bacteria and their predators. The ecology of a CMAL is rather complex and may also involve growth of algae; however, algae growth should be suppressed. This issue and other possible interactions within the flora of a CMAL should be an important factor during the treatability studies of wastewater streams. A photograph of a typical CMAL installation is shown in Fig. 4.5.



**Figure 4.5.** A photograph of a typical CMAL installation..

In a typical CMAL treatment system, a series of lagoons is placed to treat expected ranges of food and agricultural wastewater. The number of lagoons can vary; so can the sizes. When CMALs are used for wastewater treatment before land applications, the first successive lagoons provide biological treatment of the wastewater, and the last lagoon provides storage. CMALs are usually employed to achieve one of two objectives: degrading soluble solids into insoluble biomass (microbial cells) and stabilizing the organic solids. CMALs are used as a pretreatment for industrial wastewaters or as total wastewater treatment systems for a small community. The main advantage to using lagoon systems such as CMALs is their simplicity of treatment. Lagoons treat wastewater over an extended period of time and can be designed to completely degrade sludge. They are not as susceptible to “shock” loading. For example, should a toxic chemical or high pH load be introduced into the lagoon system, the constituent is diluted and can be isolated. The regular wastewater can be bypassed to the next lagoon for continued treatment. Lagoon systems also help equalize peak inflows. Lagoon systems are simple, low-capital investment systems and also have low operation and maintenance costs since fewer staff and less mechanical equipment are needed to operate this type of system. Minimal sludge is produced, which reduces capital and operational costs associated with sludge stabilization, conditioning, dewatering, and disposal. The main disadvantages of lagoon systems are that they require more land than mechanical wastewater treatment facilities and thus are not a viable option for communities with high population intensity, and that there is no operational control over the rates of biochemical reactions; the degree of treatment is affected by the temperature as temperature effects the kinetics of biochemical reactions. Seasonal changes tend to have impact on the degree of the treatment with CMALs.

Completely mixed aerated lagoons offer a reasonable treatment alternative to more costly mechanical biological wastewater treatment such as trickling filters and activated sludge systems for readily biodegradable wastewater—those streams from food processing operations. However, the decision of whether to use CMALs should be based on the total cost analysis, treatability study, and local environmental regulations.

### **Trickling Filter (TF)**

Trickling filters (also called *biofilters*) have been used to remove organic matter from wastewater for nearly 100 years. The TF is an aerobic treatment

system that utilizes microorganisms attached to a medium to remove organic matter from wastewater. The colonies of microorganisms attached to solid surfaces are called *biofilms* due to their thin layers of biological structures. This type of system is common to a number of biological wastewater technologies, such as rotating contactors and packed bed reactors (also called *bio-towers*). TFs are mainly composed of four major components: a filter medium such as stones, plastic shapes, or wooden slats; an enclosure to hold the liquid; a distribution system; and an under-drain system. The filter medium provides the surface on which the microorganisms grow. The enclosure holds both wastewater and filter medium, while a distribution system ensures a uniform hydraulic load over the entire TF and the under-drain system provides drainage, holds filter medium, and supplies oxygen to the bottom section.

### ***How TFs work***

A rotary or stationary distribution system distributes wastewater from the top of the filter, percolating it through the interstices of the medium (see Fig. 4.6). As the wastewater flows over the medium, the organic matters in the wastewater are adsorbed by a population of microorganisms (aerobic, anaerobic, and facultative bacteria; fungi; algae; and protozoa) attached to the medium as a biological film or slime layer (approximately 0.1 to 0.2 mm thick). As the wastewater flows over the medium, microorganisms already in the water gradually attach themselves to the rock, crushed granite, or plastic structure surface and form a film. The aerobic microorganisms in the outer part of the slime layer (biofilm) then decompose the organic material. As the layer thickens through microbial growth, oxygen cannot penetrate the medium surface, and anaerobic organisms prosper. As the biological film continues to grow, the microorganisms near the surface lose their ability to cling to the medium, and a portion of the slime layer falls off the filter. This process is known as *sloughing*. The sloughed solids (sludge) are collected by the under-drain system and transported to a clarifier for removal from the wastewater.

### ***Advantages and disadvantages***

There are advantages and disadvantages of TFs associated with biological treatment of food and agricultural wastewater; their importance depends on the needs of the end user and characteristics of wastewater.




Figure 4.6. A schematic diagram of a trickling filter system.

- *Advantages*
  - Simple, reliable, biological process
  - Suitable in areas where large tracts of land are not available for land-intensive treatment systems
  - May qualify for equivalent secondary discharge standards
  - Effective in treating high concentrations of organic matters, depending on the type of medium used
  - Rapidly reduces soluble BOD<sub>5</sub> in wastewater streams
  - Efficient nitrification units
  - Low power requirements
  - Moderate level of skill and technical expertise needed to manage and operate the system



- *Disadvantages*
  - Additional treatment may be needed to meet more stringent discharge standards
  - Possible accumulation of excess biomass that cannot retain an aerobic condition and can impair TF performance
  - Requires regular operator attention
  - Incidence of clogging is relatively high
  - Requires low loadings, depending on the medium
  - Flexibility and control are limited in comparison with activated-sludge processes
  - Odor problems
  - Snail problems

### ***Design criteria***

A TF consists of permeable medium made of a bed of rock, slag, or plastic over which wastewater is distributed to trickle through, as shown in Fig. 4.6. Rock or slag beds can be up to 60.96 m (200 ft) in diameter and 0.9–2.4 m (3 to 8 ft) deep, with rock size varying from 2.5–10.2 cm (1 to 4 in). Most rock media provide approximately  $149 \text{ m}^2/\text{m}^3$  (15 sq ft/cu ft) of surface area and less than 40% void space. Packed plastic filters (biotowers), on the other hand, are smaller in diameter (6 to 12 meters (20 to 40 ft)) and range in depth from 4.3 to 12.2 m (14 to 40 ft). These filters look more like towers, with the media in various configurations (e.g., vertical flow, cross flow, or various random packings). Research has shown that cross-flow media may offer better flow distribution than other media, especially at low organic loads. When comparing vertical media with the  $60^\circ$  cross-flow media, the vertical media provide a nearly equal distribution of wastewater minimizing potential plugging at higher organic loads better than cross flow media. The plastic medium also required additional provisions, including ultraviolet protective additives on the top layer of the plastic medium filter and increased plastic wall thickness for medium packs that are installed in the lower section of the filter where loads increase. The design of a TF system for wastewater also includes a distribution system. Rotary hydraulic distribution is usually standard for this process, but fixed nozzle distributors are also being used in square or rectangular reactors. Overall, fixed nozzle distributors are being limited to small facilities and package plants. Recently some distributors have been equipped with motorized units to control their speed.

Distributors can be set up to be mechanically driven at all times or during stalled conditions.

In addition, a TF has an under-drain system that collects the filtrate and solids, and also serves as a source of air for the microorganisms on the filter. The treated wastewater and solids are piped to a final settling tank where biosolids are separated from the water. Table 4.1 lists common trickling filters used in biological wastewater treatment.

### **Rotating Biological Contactor (RBC)**

Rotating Biological Contactors (RBCs) are used in the treatment of wastewater as a secondary treatment process. The RBC process involves allowing wastewater to come in contact with a biological medium in order to remove contaminants in sewage before discharge of the treated wastewater to the environment, usually a river.

The construction of an RBC consists of a series of plastic discs, the media, mounted on a driven shaft that is contained in a tank or trough. Commonly used plastics for the media are polythene, PVC, and expanded polystyrene. The shaft is aligned with the flow of sewage so that the discs rotate at right angles to the flow, with several rotors usually combined to make up a treatment train. About 40% of the disc area is immersed in the sewage.

The biological growth that becomes attached to the discs assimilates the organic materials in the wastewater. Aeration is provided by the rotating action, which exposes the media to the air after contacting them with the wastewater, facilitating the digestion of the organic compounds that need to be removed. The degree of wastewater treatment is related to the amount of media surface area and the quality and volume of the inflowing wastewater.

The RBC process may be used where the wastewater is suitable for biological treatment. The RBC process can be used in many modes to accomplish varied degrees of carbonaceous and/or nitrogenous oxygen demand reductions. The process is simpler to operate than activated sludge because recycling of effluent or sludge is not required. Special consideration must be given to returning supernatant from the sludge digestion process to the RBCs. The advantages of RBC technology include a longer contact time (8 to 10 times longer than trickling filters), a higher level of treatment than conventional high-rate trickling filters, and less suscepti-

**Table 4.1.** Trickling filter types in biological wastewater treatment (adapted from Metcalf and Eddy, Inc., 1991).

Filter Type	Filter Medium	Hydraulic Loading (gal/ft <sup>2</sup> -min)	BOD <sub>5</sub> Loading (lb/ft <sup>3</sup> -day)	BOD <sub>5</sub> Removal (%)	Depth (ft)	Recirculation Ratio	Film Sloughing	Nitrification
Low rate	Rock & slag	0.0-0.06	0.005-0.025	80-90	6-8	0	Intermittent	Well
Intermediate rate	Rock & slag	0.06-0.16	0.015-0.03	50-70	6-8	0-1	Intermittent	Partial
High rate	Rock	0.16-0.64	0.03-0.06	65-85	3-6	1-2	Continuous	Little
Super high rate	Plastic	0.2-1.2	0.03-0.1	65-80	10-40	1-2	Continuous	Little
Roughing	Plastic & redwood	0.8-3.2	0.1-0.5	40-65	15-40	1-4	Continuous	None
Two-stage	Rock & plastic	0.16-0.64	0.06-0.12	85-95	6-8	0.5-2	Continuous	Well

bility to upset from changes in hydraulic or organic loading than the conventional activated sludge process.

Whether used in small or large facilities, the RBC process should be designed to remove at least 85% of the BOD from domestic sewage. The process can also be designed to remove ammonia nitrogen ( $\text{NH}_3\text{-N}$ ). In addition, the RBC process can treat effluents and process wastewater from dairies, bakeries, food processors, pulp and paper mills, and other biodegradable industrial discharges.

### ***Process selection***

Choice of the process mode most applicable will be influenced by the degree and consistency of treatment required, type of waste to be treated, site constraints, and capital and operating costs. The process design of an RBC facility involves an accurate determination of influent, septic dumps, and side-stream loadings, proper media sizing, staging and equipment selection to meet effluent requirements, air requirements, and selection of an overall plant layout that shall provide for flexibility in operation and maintenance.

A comprehensive on-site pilot plant evaluation is recommended to incorporate the factors affecting RBC performance as an accurate source of information for a RBC design. Other approaches to determine the expected performance of RBCs may be based upon results of similar full-scale installations and/or thorough documented pilot testing with the particular wastewater. Small-diameter RBC pilot units are suitable for determining the treatability of wastewater. If small-diameter units are operated to obtain design data, each stage must be loaded below the oxygen transfer capability of a full-scale unit to minimize scale-up problems. Direct scale-up from small-diameter units to full-scale units is not possible because of the effects of temperature, peripheral speed of media, and other process and equipment factors.

In all RBC systems, the major factors controlling treatment performance are

- Organic and hydraulic loading rates
- Influent wastewater characteristics
- Wastewater temperature
- Biofilm control
- Dissolved oxygen levels
- Flexibility in operation

### ***Pretreatment***

Raw municipal wastewater shall not be applied to an RBC system. Primary settling tanks are required for effective removal of grit, debris, and excessive oil or grease prior to the RBC process. In some cases, fine screens (0.03–0.06 inches) may be considered. Screening and comminution are not suitable as the sole means of preliminary treatment ahead of RBC units.

Sulfide production must be considered in the system design. Separate facilities to accept and control feeding of septage waste or in-plant side streams should be considered where the potential for sulfide production or increased organic and ammonia nitrogen loadings will have a significant impact on the RBC system.

### ***Design criteria***

#### *Unit sizing*

Organic loading is the primary design parameter for the RBC process. This is generally expressed as the organic loading per unit of media surface area per unit of time, or in units of pounds BOD<sub>5</sub> per thousand square feet per day. Wastewater temperatures above 55°F have a minimal effect on organic removal and nitrification rates; however, below 55°F, manufacturers shall be contacted to obtain the various correction factors that must be utilized to determine the needed additional media surface area. In determining design-loading rates on RBCs, the following parameters should be utilized:

- Design flow rates and primary wastewater constituents
- Total influent BOD<sub>5</sub> concentration
- Soluble influent BOD<sub>5</sub> concentration
- Percentage of total and soluble BOD<sub>5</sub> to be removed
- Wastewater temperature
- Primary effluent dissolved oxygen
- Media arrangement, number of stages, and surface area of media in each stage
- Rotational velocity of the media
- Retention time within the RBC tank(s)
- Influent soluble BOD<sub>5</sub> to the RBC system, including soluble BOD<sub>5</sub> from in-plant side-streams, septage dumps, etc.
- Influent hydrogen sulfide concentrations
- Peak loading, BOD<sub>5</sub> max/BOD<sub>5</sub> avg

In addition to the above parameters, loading rates for nitrification will depend upon influent DO concentration, influent ammonia nitrogen concentration and total Kjeldahl nitrogen (TKN), diurnal load variations, pH and alkalinity, and the allowable effluent ammonia nitrogen concentration.

Because soluble BOD<sub>5</sub> loading is a critical parameter in the design of RBC units, it should be verified by influent sampling whenever possible.

#### *Loading rates*

When peak:average flow ratio is 2.5:1.0 or less, average conditions can be considered for design purposes. For higher flow ratios, flow equalization should be considered.

The organic loading to the first-stage standard density media should be in the range of 3.5 to 6.0 pounds total BOD<sub>5</sub> per thousand square feet per day or 1.5 to 2.5 pounds soluble BOD<sub>5</sub> per thousand square feet per day. First-stage organic loadings above 6 pounds total BOD<sub>5</sub> or 2.5 pounds soluble BOD<sub>5</sub> per thousand square feet per day will increase the probability of developing problems such as excessive biofilm thickness, depletion of dissolved oxygen, nuisance organisms and deterioration of process performance. The most critical problem in most instances is the structural overloading of the RBC shaft(s).

For average conditions, the design loading should not exceed 2.5 pounds of soluble BOD<sub>5</sub>/1,000 square feet of standard media surface per day on the first-stage shaft(s) of any treatment train. Periodic high organic loadings may require supplemental aeration in the first-stage shafts. High-density media should not be used for the first-stage RBCs.

For peak conditions, the design loading shall not exceed 2.0 pounds of soluble BOD<sub>5</sub>/1,000 square feet for the first high-density media shaft(s) encountered after the first two shafts or rows of shafts in a treatment train.

For average conditions, the overall system loading shall not exceed 0.6 pounds of soluble BOD<sub>5</sub>/1,000 square feet of media. This soluble BOD<sub>5</sub> loading to all shafts should be used to determine the total number of shafts required. The equation in the later section of could be used as an option to determine the number of stages required.

#### *Staging units*

Staging of RBC media is recommended to maximize removal of BOD and ammonia nitrogen (NH<sub>3</sub>-N). In secondary treatment applications, RBCs shall be designed with a minimum of three stages per flow path. For com-

bined BOD<sub>5</sub> and NH<sub>3</sub>-N removal, a minimum of four stages is recommended per flow path. For small installations, multiple stages are acceptable on a single shaft if interstage baffles are installed within the tank and introducing the flow parallel to the shaft. Whenever multiple process trains are employed with three or more shafts in a row; the flow path should be introduced perpendicular to the shafts, and the wastewater should be distributed evenly across the face of the RBCs.

The organic loading must be accurately defined by influent sampling whenever possible. For existing facilities that are to be expanded and/or rehabilitated, it is unacceptable to calculate only the expected load to the shafts. Flow and load sampling must be done to demonstrate the load that is generally accomplished by composite sampling after primary clarification. To predict effluent quality for a range of loadings, the influent and effluent soluble:total BOD<sub>5</sub> ratio can be assumed to be 0.5.

An alternative method of estimating soluble organic removal in the interstages, devised by E. J. Opatken (1986), utilizes a second-order reaction equation. The equation may be used for RBC design during the summer months; however, a temperature correction factor should be used for the cold winter months. Wastewater temperatures below 15°C decrease shaft rotational speeds and increase loping problems resulting in insufficient biomass sloughing. This equation is as follows (Equation 4.23):

$$C_n - 1 = \frac{\sqrt{1 + 4kt(C_n - 1)}}{2kt}$$

where:  $C_n$  is the concentration of soluble organics in the nth stage (mg/l),  $k$  is the second-order reaction constant of 0.083 (l/mg/hr),  $t$  is the average hydraulic residence time in the nth stage (hour), and  $C_n - 1$  is the concentration of soluble organic matters entering the nth stage (mg/l).

The design engineer shall be aware that this equation may be used only where appropriate, and that in the available RBC literature there may be a number of applicable equations.

#### *Design safety factor*

Effluent concentrations of ammonia nitrogen from the RBC process designed for nitrification are affected by diurnal load variations. An evaluation of equalization versus additional RBC media surface area is required when consistently low ammonia nitrogen levels are necessary to meet ef-

fluent limitations. If flow equalization is not provided, it may be necessary to increase the design surface area proportional to the ammonia nitrogen diurnal peaking rates.

#### *Secondary clarification*

The concentration of suspended solids leaving the last stage of an RBC system treating municipal wastewater is generally less than 200 mg/l when preceded with primary clarification. To attain secondary effluent quality standards, secondary clarifiers must be used in conjunction with RBCs. The surface overflow rate, generally, should not exceed 800 gallons per day per square foot for secondary clarifiers. Consideration may be given to covering the clarifiers to improve efficiency.

### **Combined Aerobic Processes**

The combined aerobic processes are designed to sustain shock loads in activated sludge, aerobic contactor, and trickling filter (biofilter) processes. There are several possible combinations of these aerobic processes: activated biofilter process, trickling filter solids-contact process, biofilter activated-sludge process, and trickling filter-activated sludge process.

The activated biofilter process is a trickling filter with recycling of secondary sludge back to the trickling-filter to create a higher level of BOD<sub>5</sub> removal through a combined attached and suspended microbial growth. High BOD<sub>5</sub> loading in wastewater streams such as those found in food processing operations can be amply handled. Design loading of BOD<sub>5</sub> normally ranges from 3.21 to 4.0 kg/m<sup>3</sup>·day for 60%–65% BOD<sub>5</sub> removal in the filter (Arora and Umphres, 1987).

The basic trickling-filter solids-contact process consists of a trickling filter, an aerobic contact tank, and a final clarifier. The trickling filter does the most BOD<sub>5</sub> removal (about 65%–85% according to Parker 1999). The biosolids formed on the filter are sloughed off and concentrated through sludge recirculation in the contact tank. In the contact tank, the suspended solids are aerated for less than 1 hour, causing flocculation of the solids, thus further removing the BOD<sub>5</sub>. The overall performance of a TF/SC process is determined by calculating the BOD<sub>5</sub> removal from the trickling filter and the aerobic contact tank (Parker and Bratby, 2001).



### **Contact Anaerobic Systems**

Anaerobic treatment is used in both biological wastewater treatment and sludge digestion. Anaerobic treatment using contact anaerobic systems is an effective treatment method for treating high strength wastewater containing a large amount of organic materials (high BOD<sub>5</sub>). Food and agricultural wastewater sometimes falls into this category of wastewater streams (such as blood water or stick-water). For example, meatpacking and fish-processing wastewater are treated successfully with anaerobic treatment processes. In the pilot scale studies of anaerobic treatment of fish-processing wastewaters, the removal rates of solids were 75%–80% with loads ranging from 3 to 4 kg COD/m<sup>3</sup> (day of digester (Balslev-Olsen et al., 1990; Mendez et al., 1990)).


The microbiology of the anaerobic treatment involves facultative and anaerobic microorganisms, which, in the absence of oxygen, convert organic materials into gaseous methane and carbon dioxide. The anaerobic process consists of two distinct stages: acid fermentation and methane fermentation. The anaerobic process starts with degrading insoluble complex organic materials such as proteins into soluble organic materials that, in turn, are consumed by acid-producing bacteria to yield volatile fatty acids, along with CO<sub>2</sub> and H<sub>2</sub>. The methane-producing bacteria devour precedent biochemical products to produce methane and carbon dioxide. Fig. 4.7 summarizes the reactions and intermediates involved in an anaerobic treatment.

#### *Advantages and disadvantages of anaerobic processes*

Compared to aerobic wastewater treatment processes, anaerobic processes have certain advantages:

- Biomass produced with anaerobic processes is much lower, thus reducing costs associated with sludge treatment and management.
- Treatment of high-strength, organic-rich wastewater is better with anaerobic processes because anaerobic processes are not limited by the oxygen transfer rate (usually the bottleneck of aerobic processes).

However, anaerobic processes of wastewater treatment also suffer from the following shortcomings:



**Figure 4.7.** A diagram of the reactions and intermediates involved in an anaerobic treatment.

- Higher thermal energy is required to maintain temperature needed for anaerobic processes; however, this problem can be overcome with the possible utilization of methane from the processes.
- Higher holding time (or detention time) is required for completing the processes.
- Undesirable odors are commonly associated with anaerobic processes due to the formation of  $H_2S$  and mercaptans; certain food wastewater sources are rich in S and N compounds, which could aggravate the odor problem.
- Sludge from anaerobic processes is harder to treat, thus requiring extra money/time/equipment to handle it.
- Anaerobic systems are difficult to operate and subject to negative effect of “shock loading.”

**Anaerobic contact processes**

The anaerobic wastewater treatment processes in use include the anaerobic contact process, the upflow sludge-blanket reactor, the anaerobic filter (fixed-bed) reactor, and the expanded-bed process. The loading and

**Table 4.2.** Common process and performance data for anaerobic processes used for the treatment of industrial wastewaters (adapted from Metcalf and Eddy, Inc., 1991).

Process	Input COD, mg/L	Hydraulic Detention Time, h	Organic Loading kg COD/m <sup>3</sup> ·d	COD Removal (%)
Anaerobic contact process	1,500–5,000	2–10	0.001873–0.009364	75–90
Upflow anaerobic Sludge-blanket	5,000–15,000	4–12	0.015607–0.078035	75–85
Fixed-bed	10,000–20,000	24–48	0.003746–0.01873	75–85
Expanded-bed	5,000–10,000	5–10	0.01873–0.03746	80–85

performance data for anaerobic contact processes are summarized in Table 4.2.


#### *Upflow anaerobic sludge-blanket (UASB) process*

The upflow anaerobic sludge-blanket process is a suspended-growth bioreactor and its schematic diagram is shown in Fig. 4.8.

As its name indicates, the wastewater flows in from the bottom of the tank upward and active anaerobic bacteria convert the waste into methane and carbon dioxide. A sludge blanket is developed in the lower portion of the tank and the component particles in the sludge blanket are aggregated to resist the hydraulic shear of the upwardly flowing wastewater and prevent the blanket from being carried over and out of the tank.

In general, the UASB process is capable of achieving high removing efficiency at high COD loadings. Lettinga et al. (1980) conducted anaerobic treatment of sugar beet wastewater using UASB systems at different scales. The experiments carried out in a 6 m<sup>3</sup> pilot-plant had shown to be capable of handling organic space loads of 15–40 kg COD/m<sup>3</sup>·day at 3–8 hr liquid detention times. In the first 200 m<sup>3</sup> full-scale plant of the UASB concept, organic loadings of up to 16 kg COD·m<sup>-3</sup>·day could be treated satisfactorily at a detention time of 4 hr. The performance of USAB reactors was limited by the capability of a gas-liquid separator to withhold the sludge in the reactors.


The design of a UASB reactor needs to ensure adequate sludge zone as most sludge resides there, and sometimes baffles are added to the locations above the sludge blanket to assist to separate biogas, sludge, and liquid.



**Figure 4.8.** A schematic diagram of an upflow anaerobic sludge-blanket process.

*Anaerobic filter (AF)*

In a similar configuration of trickling filter, an anaerobic filter reactor uses filter media to support anaerobic microorganisms to degrade carbonaceous organic matters in the wastewater feed from the bottom of the reactor (upflow mode) or from the top of the reactor (downflow mode), as shown in Fig. 4.9. Because the bacteria are retained on the media in the column, the residence time of these cells is quite high; this allows bacteria to have sufficient time to remove the organic matters. This long residence time also enables the anaerobic filter to adapt to varied operating conditions. The fluid dynamics of AF reactors is either completely mixed or partially mixed depending on the rate of recirculation. The filter




**Figure 4.9.** A schematic diagram of an upflow mode anaerobic filter (AF).

medium bed is subject to the bed-clogging due to accumulation of biological and inorganic solids; however, periodical backwashing will alleviate the clogging problem and associated head-loss.

*Anaerobic fluidized bed reactor (AFBR)*

The anaerobic fluidized bed reactor is an expanded-bed reactor (Fig. 4.10) that is filled with a solid medium used for hosting anaerobic bacteria. The wastewater is fed from the bottom of the reactor and flows upward through the medium-containing column of the reactor that is able to retain the media in the suspension from drag forces exerted by the upflowing wastewater stream.



**Figure 4.10.** A schematic diagram of an anaerobic fluidized bed reactor (AFBR)

The effluent from the reactor is recycled to dilute the influent and to maintain an adequate flow rate so that the bed remains expanded (fluidized). Due to the expansion of the medium bed, a substantially larger amount of biomass can be maintained without incurring the bed clogging and subsequent head-loss than those from anaerobic filter reactors. Reports of biomass concentration of 15,000 to 40,000 mg/L in AFBR reactors are common in the literature (Metcalf and Eddy, Inc., 1991). Because of high flow rate maintained in the AFBR reactors, especially for treating high-strength food wastewater, AFBR reactors can be designed to behave like an ideal completely mixed reactor, a CSTR.

The choice of medium in AFBR needs to be further explained; the ideal medium must be light (easily fluidized), small (easily fluidized and high

surface:volume ratio), porous with large voids (more space for biological and inert solids), inert (to chemical and biological reactions), and resistant (to abrasion and erosion). Silica sand, anthracite coal, reticulated polyester foam, and activated carbon are common media used in AFBR reactors.

## Further Reading

- Grady, C.P.L. and Lim, H.C. 1980. *Biological Wastewater Treatment: Theory and Applications*. New York: Marcel Dekker.
- Metcalf and Eddy, Inc. 1991. *Wastewater Engineering, Treatment, Disposal, and Reuse*, 3rd edition. New York: McGraw-Hill, Inc.

## References

- Arora, M.L. and Umphres, M.B. 1987. "Evaluation of activated biofiltration and activated biofiltration/activated sludge technologies." *Journal-Water Pollution Control Federation* 59: 4.
- Balslev-Olsen, P., Lynggaard, A., and Nickelsen, C. 1990. "Pilot-plant experiments on anaerobic treatment of wastewater from a fish processing plant." *Water Science and Technology* 22: 463–474.
- Lettinga, G., van Velsen, A.F.M., Hobma, S.W., de Zeeuw, W., and Klapwijk, A. 1980. "Use of the upflow sludge blanket (USB) reactor concept for biological wastewater treatment, especially for anaerobic treatment." *Biotechnology and Bioengineering* 22: 699–734.
- Mendez, R., Omil, F., Soto, M., and Lema, J.M. 1990. "Pilot plant studies on the anaerobic treatment of different wastewaters from a fishing canning factory." *Water Science and Technology* 25: 37–44.
- Metcalf and Eddy, Inc. 1991. *Wastewater Engineering, Treatment, Disposal, and Reuse*, 3rd edition. New York: McGraw-Hill, Inc.
- Opatken, E.J. 1986. "An alternative RBC design-second order kinetics." *Environmental Progress* 5: 51–56.
- Parker, D.S. 1999. "Trickling filter mythology." *Journal of Environmental Engineering, ASCE* 125: 618–625.
- Parker, D.S. and Bratby, J.R. 2001. "Review of two decades of experience with TF/SC process." *Journal of Environmental Engineering, ASCE* 127: 380–387.
- Parker, D.S., Brischike, K.V., and Matasci, R.N. 1993. "Upgrading biological filter effluents using the TF/SC process." *Journal of the Institution of Water & Environmental Management* 7: 90–100.

5

## ADVANCED WASTEWATER TREATMENT PROCESSES

---

Biological treatment processes, in combination with primary sedimentation, typically remove 85% of the BOD<sub>5</sub> and soluble solids originally present in the raw wastewater and some of the heavy metals. Activated sludge generally produces an effluent of slightly higher quality, in terms of these constituents, than trickling filters or RBCs. When coupled with a disinfection step, these processes can provide substantial but not complete removal of bacteria and virus. However, they remove very little phosphorus, nitrogen, nonbiodegradable organics, or dissolved minerals, and in an increasing number of cases this level of treatment has proved to be insufficient to protect the receiving waters from contaminations or to provide reusable water for industrial recycle. As a consequence, additional treatment steps have been added to wastewater treatment plants to provide for further organic and solids removals or to provide for removal of nutrients and/or toxic materials. These postprimary and/or postsecondary wastewater treatment processes are grouped into a category of treatment schemes called advanced wastewater treatment. In a way, *advanced wastewater treatment* can be defined broadly as any process designed to produce an effluent of higher quality than normally achieved by secondary treatment processes or containing unit operations not normally found in the secondary wastewater treatment.

The treatment processes in advanced wastewater treatment can be simply a number of unit operations added to the existing primary and/or secondary treatment processes (sometimes, this arrangement is called *tertiary treatment*) or entirely stand-alone units of physicochemical processes, biological processes, or a combination of the above processes. The specific processes employed in advanced wastewater treatment may be similar to those used in primary and/or secondary wastewater treatment or they




may be totally different from those in conventional wastewater treatment processes in order to remove the pollutants that either cannot be removed at all or be reduced to the quantity that is at the safe level. The applications of advanced wastewater treatment depend on the treatment goal of the effluents. Whether it is to remove excessive amounts of BOD/solids, nutrients, or heavy metals/toxic materials, advanced wastewater treatment has an important role in ensuring the quality of treated wastewater.

The pollution problems arising from excessive amounts of certain nutrients in wastewater are the most common reason for advanced wastewater treatment and mainly caused by nitrogen-rich and phosphorus-rich compounds. The nitrogen-rich substances, such as proteins, are biologically converted into ammonia through a process called *ammonification*. The excessive amount of nutrients in discharged treated wastewater will lead to a problem called *eutrophication*. The eutrophication problem associated with algae blooms and deaeration of the receiving waterbody results from oxidation of ammonia to nitrate by the nitrifying bacteria (this process is called *nitrification*) and can suffocate fishes and other animals living in the polluted water. High concentrations of nitrate in water are toxic to both humans and animals. A schematic diagram in Fig. 5.1 shows the simplified nitrogen cycle in the environment.

Another area of pollution problem associated with wastewaters, which is not addressed adequately by the conventional wastewater treatment, is the category of priority pollutants and volatile organic compounds (VOCs) identified by the regulatory agencies since the early 1980s. These pollutants are found to be toxic to humans and the aquatic ecosystem; if left untreated, the pollutants will enter the domestic water supply when insufficiently treated wastewater is allowed to discharge to surface water or groundwater.

There are a number of physicochemical methods useful for nitrogen and phosphorous removal from wastewater effluents, such as ammonia air stripping and ion exchange; however, the high cost and low reliability of these methods have hindered their popularity. By far the most widely used method of nitrogen removal in practice has been biological processes. VOCs are found to be quite resistant to biological treatment, and physicochemical processes such as air stripping have their own limitations in terms of VOC removal from wastewater and may turn a water pollution problem into an air pollution quandary. Membrane technology, particularly pervaporation, has now grown out of the perception of being an academic laboratory curiosity and has found practical use in various wastewater treatment projects (Peng et al., 2003).



**Figure 5.1.** A simplified diagram of the nitrogen cycle in nature.

### Biological Removal of Nitrogen: Nitrification and Denitrification

The goal of nitrogen removal, regardless of what exactly forms of nitrogen compounds in wastewater streams, has been the production of nitrogen gas, an inert, water-insoluble gas that is easily separated from liquid media. The necessity of producing nitrogen gas in the treatment processes of nitrogen removal is mainly due to high solubility of nitrogen compounds such as  $\text{NO}_3^-$ ,  $\text{NH}_4^+$ , and  $\text{NO}_2^-$  present in the nitrogen removal. There is some indication that this old paradigm is being challenged. Because nitrogen gas, as in wastewater treatment operations, does not have economical value, some researchers are seeking to remove nitrogen compounds in dissolved forms (Aiyuk et al., 2004). The most promising method of removing dissolved forms of nitrogen compounds is the application of adsorption-employing zeolite columns in an integrated wastewater treatment process. The recovered nitrogen compounds can be used as fertilizers. However, due to high costs of zeolite columns, the most economical way of removing nitrogen compounds from wastewater streams now is the conventional biological processes consisting of nitrification and denitrification processes.

The biology of nitrification-denitrification has been briefly discussed in Chapter 2; in a nutshell, biological nitrogen removal from wastewater converts organic nitrogenous compounds to ammonia, then to nitrate (nitrite), and finally to gaseous nitrogen, as illustrated in the nitrogen cycle diagram in Figure 5.1. Organic nitrogen materials in food and agricultural wastewater streams are either in the forms of proteins, nucleic acids and urea, or as ammonium ion ( $\text{NH}_4^+$ ). Normally, domestic and most industrial wastewater streams rarely contain nitrate. Nitrate in some agricultural wastewater streams may come from the fields in which excessive amounts of nitrogen-rich man-made fertilizers have been applied.

Nitrification is a microbial process by which reduced nitrogen compounds (primarily ammonia) are sequentially oxidized to nitrite and nitrate and is the first step in the removal of nitrogen from wastewater streams by the nitrification-denitrification process. It is primarily accomplished by two groups of autotrophic nitrifying bacteria, *Nitrosomonas* and *Nitrobacter*, that can build organic molecules using energy obtained from inorganic sources, in this case ammonia or nitrite. In the first step of nitrification, ammonia-oxidizing bacteria oxidize ammonia to nitrite. *Nitrosomonas* oxidizes ammonia to the intermediate product, nitrite, and nitrite is further converted into nitrate by *Nitrobacter*. Overall equations for nitrite production and nitrate formation by these two categories of nitrifying bacteria are represented in Chapter 2, Equations 2.9 and 2.10.

A number of environmental factors influence the nitrification process: substrate concentration, temperature, oxygen, pH, and toxic or inhibiting substances. Nitrifying bacteria are susceptible to a number of inhibitors, both organic and inorganic agents. They are also sensitive to pH value and a range of 7.5 to 8.6 is found to be optimal for the growth of nitrifying bacteria. There is also a dissolved oxygen level that could limit the nitrification process; a concentration of above 1 mg/l is essential for nitrification to occur.

Temperature has a strong effect on nitrifying bacteria just as in the case of heterotrophic aerobic bacteria. The temperature dependence for the nitrification process fits an Arrhenius type of equation, at least lower than 30°C. At higher temperatures (30–35°C), the growth rate of nitrifying bacteria is constant, and it starts declining between 35 and 40°C (Henze et al., 2001).

## **Physicochemical Removal of Nitrogen**

As described previously, biological nitrogen removal is not the only technology available for nitrogen compound removal from wastewaters. Some nonbiological processes are able to recover nitrogen compounds in their dissolved forms for potential uses as fertilizers and are viable alternatives under some circumstances. On the whole, however, physicochemical processes for removing nitrogen from wastewater are not practically popular. The reasons for the unpopularity are often cited as cost, inconsistent performance, and operating and maintenance problems. The principal processes employed for nitrogen removal from wastewaters are air stripping, breakpoint chlorination, and selective ion exchange.

Air stripping is used to remove ammonia from wastewater because ammonia in water can be easily volatilized and carried away by the flowing air stream, particularly in high pH values. The gaseous ammonia in air can later be captured. The process is temperature-sensitive, and fogging and icing occur in cold temperature. This is an expensive operation that requires lime for pH control, and it can be justified only in some special cases, such as the need for a high pH for other reasons at the time.

Breakpoint chlorination is a process that involves the addition of chlorine to wastewater to oxidize the ammonia in the wastewater to nitrogen gas and other possible stable compounds. It can, with proper control, theoretically remove all ammonia in wastewater and therefore it is used to polish the effluents from other nitrogen removal processes. The downside of the breakpoint chlorination process is that the process is sensitive to pH, thus requiring proper control of pH with skillful operators during the application of chlorine. The process is expensive because of chlorine and skilled labor requirements, and its residual may be toxic to the aquatic life.

Ion exchange is a separation technology (see Chapter 3 for the description of ion exchange systems) that utilizes ion-selective resins (mostly synthetic, but also natural, such as zeolites) to remove certain ions from wastewater. In ion exchange operations, the ions in wastewater displace the ions on the resins, thus separating from the rest of the components in the wastewater streams. The removed ions in the resins can be washed out with appropriate regenerants. For nitrogen removal with a zeolite ion exchange system, lime can be used to regenerate zeolites. Because of the presence of organic materials in wastewater, restorants such as sodium hy-

dioxide, hydrochloric acid, methanol and bentonite are employed to remove organic materials from resins.

### **Biological Removal of Phosphorus**

Phosphorus is a constituent of wastewater, averaging around 10 mg/liter in most cases. The principal form in food and agricultural wastewater is organically bound phosphorus. Organically bound phosphorus originates from body and food waste and, upon biological decomposition of these solids, is converted to orthophosphates.


Biological phosphate removal is a relatively new technology dating back to the late 1950s; it wasn't until the 1970s that there were full-scale processes developed for practical use in advanced wastewater treatment. Based on a series of tests and experiments on biological phosphorus removal, Fuhs and Chen (1975) determined that a genus called *Acinetobacter* was responsible for biological phosphorus removal and postulated that these bacteria utilized substrates, a type of volatile fatty acid (VFA) produced from an anaerobic phase, for growth and excessive phosphorus uptake under aerobic conditions. However, this explanation of biological phosphorus removal was challenged by a number of researchers using molecular ecology techniques (e.g., Bond et al., 1995; Mino et al., 1998). Nevertheless, it was recognized from a process engineering point of view that the necessary condition for biological phosphorus removal is existence of a true anaerobic phase in the process; this insight has helped develop several process configurations of biological phosphorus removal in the world.

It was later discovered that the main function of the anaerobic phase was not only to provide polyphosphate-accumulating bacteria with VFAs but also to enable this type of bacteria to use phosphate as an energy reserve to pick up substrates (Wentzel et al., 1986; Arun et al., 1987; Smolders et al., 1994; Maurer et al., 1997; Mino et al., 1998). The available VFAs enable bacteria to utilize the VFAs as a carbon source under anaerobic condition and release phosphate into the solution, and a subsequent aerobic phase as well as anoxic conditions take up the phosphate in water. As a result, a greater amount of phosphorus is removed from wastewater as sludge. Glycogen is also utilized under anaerobic conditions and replenished during the aerobic phase of the cycle.

*Acinetobacter* is only responsible for some portions of biological phos-

phorus removal. It is clear today that phosphorus-accumulating organisms (PAOs) include many heterotrophic microorganisms. However, not all heterotrophic bacteria are PAOs, and in a wastewater treatment plant with biological phosphorus removal processes, these non-PAOs may compete with those heterotrophic PAOs for the substrate, particularly those low molecular fatty acids, which is needed for the phosphorus storage mechanism. The result of this competition determines the success of the biological phosphorus removal process. As mentioned previously, the anaerobic phase is of great importance in steering the substrate utilization toward the direction of the heterotrophic PAOs.


The biological treatment or removal of phosphorus from wastewater depends on the accumulation of a large amount of bacteria that are capable of storing phosphorus in the form of polyphosphate inside the bacterial cells; polyphosphate as stored energy for bacteria is produced as a result of sequestering volatile fatty acids by aerobic bacteria under anaerobic conditions, resulting in poly(hydroxyalkanoates) (PHAs) under simultaneous use of glycogen. This requires that the influent of wastewater for biological phosphorus removal has to first mix with sludge in order to create a true anaerobic environment free from electron acceptors such as oxygen and nitrate. In the anaerobic environment or zone, volatile fatty acids (may be formed by fermentation) in the incoming wastewater stream can be accumulated by polyphosphate-accumulating bacteria. Thus, a successful design of a biological phosphorus removal process relies on the creation of such a true anaerobic zone; this will also be influenced by the characteristics of incoming wastewater streams. Depending on whether there is a presence of volatile fatty acids produced by fermentation, the size of the anaerobic zone or reactor varies with the predominant anaerobic process. The volatile fatty acids-containing wastewater streams require small reactors; incoming wastewaters from an aerobic process without volatile fatty acids need larger reactors because the anaerobic phase has to be based on a slower fermentation process. Fig. 5.2 shows a basic schematic diagram of a biological phosphorus removal process. In this diagram, substrate is taken up by polyphosphate-accumulating bacteria and phosphate is released into the liquid phase in the anaerobic phase. In the aerobic phase, the bacteria grow and accumulate phosphate in the cells, resulting in removal of phosphate from the wastewater. It is generally observed that in order to operate a successful biological phosphorus removal process, it is crucial that the incoming wastewater stream should contain the correct balance of nutrients, carbon



**Figure 5.2.** A schematic diagram of a typical biological phosphorus removal process.

sources, and pH; careful considerations must be given to the food: microorganism ratio, hydraulic retention time, solid retention time, temperature, and DO concentration (Mulkerrins et al., 2004). In addition to this basic biological phosphorus removal process, there are several combined processes of chemical and biological phosphorus removal. Fig. 5.3 gives a schematic diagram of metabolisms of PAOs under aerobic and anaerobic conditions.

It has been shown that some PAOs called *denitrifying PAOs* can also accomplish denitrification while accumulating phosphorus. The combined processes of biological phosphorus and nitrogen removal by denitrifying phosphate-accumulating bacteria such as UCT (University of Cape Town)-type processes have been demonstrated (Kuba et al., 1996, 1997). In these combined processes, PAOs used nitrate or nitrite as an electron acceptor instead of oxygen. Contrary to the earlier view of different PAOs involved in denitrification and biological phosphorus removal in the combined processes, it now appears that *Accumulibacter* was the denitrifying PAOs in both anaerobic and anoxic conditions in the combined processes (Ahn et al., 2002; Zeng et al., 2003). Further microbial analysis in the study of Zeng et al. (2003) revealed that *Accumulibacter* was the dominant species in both PAO and denitrifying PAO sludge. The current trend in biological phosphorus removal is development of a simultaneous nitrification, denitrification, and phosphorus removal process that can save capital and operational costs as well as leave a smaller environmental footprint.



**Figure 5.3.** A schematic diagram of metabolisms of PAOs under anaerobic and aerobic conditions.

### Physicochemical Removal of Phosphate

There are several physicochemical phosphate removal processes that can be used with conventional secondary wastewater treatment. These processes generally involve using chemicals to facilitate precipitation of phosphate and a primary clarifier (sedimentation tank or basin) to separate phosphate-containing sludge from the treated wastewater; or in some cases, dissolved air flotation is used to remove the phosphorus-containing complexes. The principal chemicals employed in this type of removal are alum, sodium aluminat, ferrous chloride or sulfate, ferric chloride or sulfate, and lime. Ferrous sulfate and ferrous chloride are available as by-products of



steel-making operations (called *pickle liquor*) and thus have cost advantage in use. Polyelectrolytes have been used effectively along with alum or lime as flocculant aids. The assortment of chemicals used in precipitation of phosphate has a striking similarity to those flocculents employed in the formation of flocs from colloidal dispersion of particulates.

The chemistry of chemical precipitation reactions involved may be reviewed from the descriptive materials in Chapter 3. The choice of using any of the chemicals mentioned above for phosphorus removal is determined by the following factors:

- Incoming flow phosphorus level
- Suspended solids and colloids
- Alkalinity
- Chemical cost including transportation
- Reliability of chemical availability
- Sludge handling facilities and method as well as cost including disposal
- Compatibilities with other treatment processes (primary and secondary treatment processes)


Iron and alum salts can be added at various points in primary and secondary treatment processes. However, in order to achieve maximum removal of phosphorus, alum and iron salts are best added after the secondary treatment in organic phosphorus-containing wastewater streams (where organic phosphorus is transformed as orthophosphorus). Additional nitrogen removal might occur as a result of this sequence of adding alum or iron salts. The various chemical addition points and sequences are dependent on characteristics of wastewater treatment objectives.

The obvious drawback of physicochemical processes of phosphorus removal is the cost associated with the chemicals or coagulants. Additionally, the increase in sludge volume due to addition of chemicals and inability of the physicochemical processes to remove nitrogen compounds are also known disadvantages.

### ***Lime precipitation of phosphate***

A lime phosphate precipitation system is similar to a primary settling tank or basin. Wastewater inflow is mixed with lime and flocculated to cause the precipitation of phosphate in the wastewater in the form of insoluble

calcium salt. The main reaction required to determine the quantity of sludge produced during the precipitation of phosphorus with lime is expressed as the following (Equation 5.1):




However, the same lime may also cause precipitations of  $\text{Mg}(\text{OH})_2$  and  $\text{CaCO}_3$  in addition to orthophosphorus.

The lime sludge from the clarifier is often recycled for reducing the cost of lime in the treatment. The process generally achieves 80–95% removal rate of phosphate in wastewater. Lime can also soften the water; however, the large amount of lime used presents a new challenge: dealing with the increased amount of sludge in the treatment.

### ***Ferrous precipitation of phosphate***

The process uses ferrous chloride to convert soluble phosphate in wastewater streams into an insoluble form. The relevant reaction of phosphorus precipitation in the presence of ferrous salts can be written as the following (Equation 5.2):



It is possible  $\text{Fe}(\text{OH})_2$  may also generate and precipitate when ferrous salts are added.


Polyelectrolyte is also used to aid flocculation of phosphate complex with ferrous chloride in the clarifier. Other salts can also be used in lieu of ferrous chloride; ferric chloride and sodium aluminate are among them. Recall that in Chapter 3, we discussed flocculation using iron salts and polyelectrolytes to reduce colloidal particulates. This process can be viewed as an extension to the conventional primary wastewater treatment processes.

Like all processes involving chemical precipitation reaction, the cost of ferrous precipitation of phosphate depends on the cost of metal salts. If the metal salts can be economically had, the cost of the phosphate removal operation will be reasonable. Ferrous chloride used in wastewater treatment can be obtained from steel plants in which ferrous chloride is a waste of steel production. Application of ferrous chloride to the primary sedimentation facilities for phosphate removal also has an unintended benefit: it

reduces the BOD load on secondary treatment facilities because it causes flocculation of and subsequent settling of organic colloids from wastewater. The downside of the use of ferrous chloride as flocculent is that it requires the use of corrosion-resistant equipment that the ferrous or ferric sludge may inflict damage on; the sludge may not be compatible with some dewatering techniques described in Chapter 6.


### ***Alum and ferric precipitation of phosphate***

A representative reaction expression for phosphorus removal with addition of alum is as follows (Equation 5.3):



It is likely that  $\text{Al}(\text{OH})_3$  may also precipitate from the wastewater.

A pertinent reaction for phosphorus removal with addition of ferric salts is expressed as the following (Equation 5.4):



Again, it is almost unavoidable that  $\text{Fe}(\text{OH})_3$  will form and precipitate out of the wastewater stream if the pH value is alkaline.

## **Membrane Processes for Advanced Wastewater Treatment**

An overview about membrane processes that can be used in wastewater treatment has been presented in Chapter 3; the general characteristics of various processes determine the applications of membrane processes in wastewater treatment. Membrane filtration can theoretically replace conventional processes such as secondary sedimentation, flocculation, settling basin, and granular filtration all together. In reality, however, the applications of membrane filtration in wastewater treatment are carefully implemented. Membrane filtration is usually placed after the secondary treatment as the wastewater has ridged itself of the majority of suspended particulates and FOG; cartridge filters or carbon filters are often used before the membrane unit for extending the working life cycle of the membrane material, which is very susceptible to fouling or forming an adsorbed layer by lipids, proteins, silicates, and other minuscule substances.

## Classification of Membrane Filtration




Figure 5.4. Classification of membrane filtration based on size exclusion.

Low-strength wastewater from food and agricultural processing can be treated with membrane filtration alone, provided that some forms of pre-treatment (filtration) precede membrane filtration. For example, steep or soaking water from grain processing can be treated with a microfiltration unit; wastewaters from milk and cheese processing, including cleaning water and evaporator condensate, may be filtered with ultrafiltration or a combination of microfiltration and ultrafiltration; and oil/water emulsion may be separated with a ceramic membrane filtration unit. A number of membrane filtration processes that are capable of retaining or removing certain materials are classified based on their size exclusion capability, as shown in Fig. 5.4.

Reverse osmosis (RO) is often associated with water treatment or ultrapure water production because of its ability to retain the dissolved ions (in the case of ultrapure water production, RO serves as pretreatment for ion exchange deionization). One successful commercial application of reverse osmosis is desalination of seawater or brackish water and production of bottled water. RO is also used with some success in removing arsenic from drinking water sources. RO may also be used to desalt effluents from a

wastewater treatment plant to reduce the salt concentration before discharge. RO is widely used in food processing as a concentration process and recovery process of useful components in food wastewaters; it is conceivable that RO can also be used to reduce the volume of the wastewater in food wastewater treatment (for example, RO may be used to treat nutrients such as nitrate or phosphate) or to produce recycled water for reuse in food processing operations.

Like RO, electrodialysis (ED) is used to desalt impaired waters or remove ions such as nitrate, arsenic, and phosphate. ED may also be used to separate acids from food wastewaters. Recovery of carboxylic acids (such as acetic, citric, and lactic) is a known application of ED in food and agricultural processing.

As explained in Chapter 3, there are four common types of membrane module designs available for membrane processes; however, not all module types are suitable for all membrane processes. Table 5.1 provides a guideline for selecting modules for membrane processes.

One current interest in applications of membrane processes in food wastewater treatment is recovery of valuable commodities from food wastewater streams. Chapter 8 is devoted entirely to the recovery of useful materials and energy from food and agricultural wastewaters including using membrane-based technologies to achieve the objectives of the recovery.

One problem that has hindered the widespread use of membrane technology is the noticeable occurrence of concentration polarization/fouling in membrane processes. The detrimental effect of concentration polarization and/or membrane fouling add significant costs to the operator. In membrane filtration processes, concentration polarization is formed as the result of the rapid accumulation of retained solutes near the membrane surface to the point that the concentration of macromolecule solute reaches the gel-forming concentration and the retained molecules diffuse back into the bulk fluid. The cause of concentration polarization in pervaporation or electrodialysis is slightly different from that of membrane filtration in that it is triggered by the relatively slow diffusional mass transfer rates of solutes or ions from the bulk to the membrane surface.

Membrane fouling is commonly observed as the membrane flux is continuously declining after a period of time of operation. This is usually an irreversible, partially concentration-dependent, and time-dependent phenomenon, which distinguishes it from concentration polarization. The identification of membrane fouling often relies on operator experience, performing fouling tests with lab-scale static filtration experiments or silt

**Table 5.1.** Membrane modules for common membrane processes.

Process	Tubular	Hollow Fiber	Plate-and-Frame	Spiral Wound
Microfiltration	Good	Not suitable	Good	Not suitable
Ultrafiltration	Good	Adequate	Good	Adequate
Nanofiltration	Good	Good	Good	Adequate
Reverse Osmosis	Adequate	Good	Adequate	Good
Pervaporation	Adequate	Good	Good	Good
Electrodialysis	Not suitable	Not suitable	Good	Not suitable

density index (SDI) measurement, and the membrane vendor's recommendations. Membrane fouling is intimately related to concentration polarization, but the two are not exactly interchangeable in our description of membrane performance deterioration. The exact cause of membrane fouling is very complex and therefore difficult to depict in full confidence with available theoretical understandings. Fouling is influenced by a number of chemical and physical parameters, such as concentration, size of particulates, pore size distribution, temperature, pH, ionic strength, and specific interactions (hydrophobic interaction, hydrogen bonding, dipole-dipole interactions).

Membrane fouling can be greatly reduced in several ways. One effective way is to provide pretreatment to the feed liquids. Some simple adjustments, such as varying pH values and using hydrophilic membrane materials, can also provide some relief from membrane fouling. There are also persistent interests in modifying membrane properties to minimize the membrane-fouling tendency around the world. Because membrane fouling is intimately associated with the concentration polarization phenomenon, any action taken to minimize concentration polarization will also help reduce membrane fouling. Fouled membranes can be cleaned and they regain some of the original performance. Frequent cleaning and washing with detergents will inevitably lead to the demise of the membrane. There are three basic types of cleaning methods currently used: hydraulic flushing (back-flushing), mechanical cleaning (only in tubular systems) with sponge balls, and chemical washing. When using chemicals to perform defouling, caution must be observed because many polymeric membrane materials are susceptible to chlorine, high pH solutions, organic solvents, and other chemicals.

## **VOC Removal with Pervaporation**

As described in Chapter 3, pervaporation is an energy-efficient technology that has been used commercially for alcohol dehydration, VOC removal from contaminated water, and hydrocarbon separations. The driving force of pervaporation processes is the chemical potential difference across the membrane between the feed and permeate; the performance of pervaporation is not restricted by vapor-liquid equilibrium like distillation (Dutta et al., 1996). Recently, it has been shown to be a valuable tool for value-added wastewater treatment through flavor and aroma recovery from food processing by-products (e.g., Karlsson and Trägårdh, 1996; Peng and Liu, 2003c). The application of pervaporation in VOC removal has also been intensively researched (e.g., Jiang et al., 1997; Hitchens et al., 2001; Vane et al., 1999, 2001a; Peng and Liu, 2003a, 2003b; Liu and Peng 2006). These VOC removal research programs have led to several successful field demonstrations (e.g., Alvarez et al., 2001; Vane et al., 2001b).

In general, pervaporation processes can be easily adapted to VOC removal in water or wastewater because of their energy efficiency and targeted removal without introducing additional chemicals or new pollutants in different forms (e.g., carbon adsorption and air stripping). Almost all VOCs can be removed with pervaporation; however, VOCs of particular interest including petroleum-based solvents, such as benzene, toluene, ethyl benzene, and xylenes (BTEX), and chlorinated solvents, such as trichloroethylene (TCE) and tetrachloroethylene (PCE) are particularly well suited for pervaporation removal. The water solubilities of these compounds are low; therefore, the amount of VOCs dissolved in water is too small to be economically removed from water by conventional chemical process separation technologies such as distillation. In the past, air stripping and/or activated carbon treatments were deployed for the task; however, the former is susceptible to fouling and merely turns a water pollution problem into an air pollution issue, and the latter needs costly regeneration steps and may not be suitable for VOCs that are easily displaced by other organic compounds. Over the decades, a growing literature has been added to the knowledge base of VOC removal with pervaporation.


## **Disinfections**

Disinfection is a process in which pathogens are destroyed or inactivated by physicochemical treatments. Disinfection is a final step for water treat-


ment; however, increasingly, wastewater treatment plants also apply disinfection in wastewater treatment because of the concern for pathogens in treated wastewater being discharged to a receiving water body or field. Pathogens in raw wastewater, to a large extent, have been either removed or inactivated among the trail of wastewater treatment processes. Nevertheless, there are still many opportunities for recontaminating treated wastewater because many treatment processes are conducted in open facilities outdoors. Other reasons for wastewater disinfection or use of disinfectants such as chlorine or its derivatives in wastewater treatment are oxidation of ammonia and of organic materials that contribute to BOD; destruction and control of ion-fixing and slime-forming bacteria; and destruction and control of filter flies, algae, and slime growth on trickling filters.

The mechanism of disinfection is said to be inactivation of enzymes of the pathogens by denaturing them. Without functional enzymes, microorganisms are destroyed or inactivated. In order to gain access to the enzymes in pathogen cells, the walls of the cells have to be penetrated by disinfectants or destroyed by thermal, chemical, or physical means. Chemical disinfectants, such as ozone, chlorines, and chlorine dioxide, work through oxidizing and reacting with cells of pathogens. Heat energy, irradiation, and ultrasound, even high pressure, perform their duties through physical destruction.

Chlorine and its derivatives are the most common disinfectants used in water and wastewater treatment. Chlorine in an aqueous solution hydrolyzes to yield the following (Equation 5.5):




HOCl may be further hydrolyzed to yield the following (Equation 5.6):



Both HOCl and OCl<sup>-</sup> are disinfectants. Although chlorine is a very effective disinfectant, handling of it is inconvenient to say the least. Sodium hypochlorite (NaOCl) is often used in place of chlorine for disinfection of water and wastewater. Chlorinated lime (containing up to 70% CaOCl<sub>2</sub> and 20% Ca(OH)<sub>2</sub>, as well as carbonate), also called *bleaching powder*, is also widely used in the same manner as NaOCl in applications. Calcium hypochlorite (Ca(OCl)<sub>2</sub>) is another chlorine derivative that is broadly employed in water and wastewater disinfection. Chlorine dioxide, an unsta-



ble gas, is also used in disinfection—it is often generated on-site through the following reaction (Equation 5.7):



Another group of disinfectants belongs to strong oxidizing agents. Ozone ( $\text{O}_3$ ) is a particularly powerful but unstable oxidizing agent and is used extensively in Europe for both disinfection and removal of objectionable odor, taste, and color. The popularity of ozone in Europe is also linked to its lack of residual products or by-products that might be harmful to human health. However, ozone is unstable and ozone-treated water does not have residual protection from recontamination like that treated with chlorine does; as a result, in the United States, chlorine and its derivatives are still dominant in water and wastewater disinfection. Hydrogen peroxide ( $\text{H}_2\text{O}_2$ ) is an unstable liquid oxidizing agent; its oxidizing power is somehow not entirely related to its disinfecting power. It is believed that some bacteria can produce an enzyme called *catalase* that decomposes hydrogen peroxide into water and  $\text{O}_2$ , thus rendering hydrogen peroxide harmless to those bacteria. Consequently, hydrogen peroxide is not a suitable disinfectant for any large-scale water or wastewater disinfection.

The disinfection or inactivation of microorganisms is, in a way, a physicochemical process that is not instantaneous. The rate of disinfection is believed to follow a first-order relationship called *Chick's law* (Equation 5.8):

$$-\frac{dN^\circ}{dt} = kN^\circ$$

Which can be integrated to result in the following (Equation 5.9):

$$N^\circ = N_0^\circ e^{-kt}$$

where  $N^\circ$  is the number concentration of surviving microorganisms at time,  $t$ , and  $k$  is the rate constant.

Chick's law should be used as a rough estimation of the rate of disinfection in a practical application of disinfectants. This rate may be increased or decreased depending on the environmental factors, disinfectants, and microorganisms. Also, the concentration of disinfectants or dosage of disinfectants is not reflected in Equation 5.8 and 5.9. The temperature effect

of rate of disinfection cannot be easily included in the rate constant,  $k$ , because temperature also affects certain reactions involved in disinfection in addition to disinfection rate. The value of pH can also exert influence on the disinfection rate, as well as reaction steps involved in certain disinfection processes. Extreme pH can inactivate microorganisms without disinfectants. Organic matters may interfere with disinfection processes by reacting with disinfectants or shielding microorganisms that attach to the surfaces of organic matters.

Nonchemical disinfection may also be used in lieu of chemicals. Thermal treatment is an effective method of inactivation of microorganisms; extended thermal treatment such as high-temperature steam or boiling water can achieve sterilization. But thermal treatment is an unlikely choice of disinfection method for wastewater treatment due to the enormous cost it entails. Ultraviolet irradiation has certain bactericidal effects, but its effectiveness is debatable; also, the presence of substances, including water, zaps the strength of ultraviolet irradiation. Gamma- and x-ray irradiation can inactivate certain species of bacteria; however, once again, this technology is impractical in disinfecting wastewater because the economical feasibility for treatment of a large volume of water dictates the selection of disinfection methods.

### Further Reading

Henze, M., Harremose, P., Jansen, J.L.C., and Arvin, E. 2001. *Wastewater Treatment: Biological and Chemical Processes*, 3rd edition. Berlin: Springer.

### References

- Abou-Nemeh, I., Majumdar, S., Saraf, A., Sirkar, K.K., Vane, L.M., Alvarez, F.R., and Hitchens, L. 2001. "Demonstration of pilot-scale pervaporation systems for volatile organic compound removal from a surfactant enhanced aquifer remediation fluid. II. Hollow fiber membrane modules." *Environmental Progress*, 20: 64–73.
- Ahn, J., Daidou, T., Tsuneda, S., and Hirata, A. 2002. "Characterization of denitrifying phosphate-accumulating organisms cultivated under different electron conditions using polymerase chain reaction-denaturing gradient gel electrophoresis assay." *Water Research* 36: 403–412.
- Aiyuk, S., Amoako, J., Raskin, L., van Haandel, A., and Verstraete, W. 2004. "Removal of carbon and nutrients from domestic wastewater using a low investment, integrated treatment concept." *Water Research* 38: 3031–3042.

- Alvarez, F.R., Vane, L.M., and Hitchens, L. 2001. "Demonstration of pilot-scale pervaporation systems for volatile organic compound removal from a surfactant enhanced aquifer remediation fluid. I. Spiral wound membrane modules." *Environmental Progress* 20: 53–63.
- Arun, V., Mino, T., and Matsuo, T. 1987. "Biological mechanisms of acetate uptake mediated by carbohydrate consumption in excess phosphate removal systems." *Water Research* 22: 565–570.
- Bond, P., Hugenholtz, P., Keller, J., and Blackall, L. 1995. "Bacterial community structures of phosphate removing and non-phosphate removing activated sludge from sequencing batch reactor." *Applied Environmental Microbiology* 61: 1910–1916.
- Dutta, B.K., Ji, W., and Sikdar, S.K. 1996. "Pervaporation: Principles and applications." *Separation and Purification Methods* 25: 131–224.
- Fuhs, G.W. and Chen, M. 1975. "Microbiological basis of phosphate removal in the activated sludge process for the treatment of wastewater." *Microbiology and Ecology* 2: 119–138.
- Henze, M., Harremose, P., Jansen, J.L.C., and Arvin, E. 2001. *Wastewater Treatment: Biological and Chemical Processes*, 3rd edition. 430 pp. Berlin: Springer.
- Hitchens, L., Vane, L.M., and Alvarez, F.R. 2001. "VOC removal from water and surfactant solutions by pervaporation: A pilot study." *Separation and Purification Technology* 24: 67–84.
- Jiang, J.-S., Vane, L.M., and Sikdar, S.K. 1997. "Recovery of VOCs from surfactant solutions by pervaporation." *Journal of Membrane Science* 136: 233–247.
- Karlsson, H.O.E. and Trägårdh, G. 1996. "Applications of pervaporation in food processing." *Trends in Food Science & Technology* 7: 78–83.
- Kuba, T., Loosdrecht, M.C.M. van, Brandse, F., and Heijnen, J.J. 1997. "Occurrence of denitrifying phosphorus removing bacteria in modified UCT-type wastewater treatment plants." *Water Res* 31: 777–787.
- Kuba, T., Loosdrecht, M.C.M. van, and Heijnen, J.J. 1996. "Phosphorus and nitrogen removal with minimal COD requirement by integration of denitrifying dephosphatation and nitrification in a two-sludge system." *Water Res* 30: 1702–1710.
- Liu, S.X. and Peng, M. 2006. "Assessment of semi-empirical mass transfer correlations for pervaporation treatment of wastewater contaminated with chlorinated hydrocarbons." In press, *JZUS*.
- Maurer, M., Gujer, W., Hany, R., and Bachmann, S. 1997. "Intracellular carbon flow in phosphorus accumulating organisms in activated sludge systems." *Water Research* 31: 907–917.
- Mino, T., van Loosdrecht, M.C.M., Heijnen, J.J. 1998. "Microbiology and biochemistry of the enhanced biological phosphate removal process." *Water Research* 32: 3193–3207.
- Mulkerrins, D., Dobson, A.D.W., and Colleran, E. 2004. Parameters affecting biological phosphate removal from wastewaters. *Environment International* 30: 249–259.
- Peng, M. and Liu, S.X. 2003a. "VOC removal from contaminated groundwater through membrane pervaporation. Part II: 1,1,1-trichloroethane—Surfactant solution system." *Journal of Environmental Sciences* 15: 821–827.
- . 2003b. "VOC removal from contaminated groundwater through membrane pervaporation. Part I: Water—1,1,1-trichloroethane system." *Journal of Environmental Sciences* 15: 815–820.

- . 2003c. “Recovery of aroma compound from dilute model blueberry solution by pervaporation.” *Journal of Food Science* 68: 2706–2710.
- Peng, M., Vane, L., and Liu, S.X. 2003. “Recent advances in VOC removal from water by pervaporation.” *Journal of Hazardous Materials* B98: 69–90.
- Smolders, G.J.F., van Loosdrecht, M.C.M., and Heijnen, J.J. 1994. “A metabolic model for the biological phosphorus removal process.” *Water Science and Technology* 31:461–470.
- Vane, L.M., Alvarez, F.R., and Giroux, E.L. 1999. “Reduction of concentration polarization in pervaporation using vibrating membrane module.” *Journal of Membrane Science* 153: 233–241.
- Vane, L.M., Alvarez, F.R., and Mullins, B. 2001a. “Removal of methyl t-butyl ether (MTBE) from water by pervaporation: bench-scale and pilot-scale evaluations.” *Environmental Science & Technology* 35: 391–397.
- Vane, L.M., Hitchens, L., Alvarez, F.R., and Giroux, E.L. 2001b. “Field demonstration of pervaporation for the separation of volatile organic compounds from a surfactant-based soil remediation fluid.” *Journal of Hazardous Materials* 81: 141–166.
- Wentzel, M.C., Lotter, L.H., Loewenthal, R.E., and Marais, G.v.R. 1986. “Metabolic behaviour of *Acinetobacter* sp. in enhanced biological phosphorus removal—A biochemical model.” *Water SA* 12: 209–224.
- Zeng, R.J., Saunders, A.M., Yuan, Z., Blackall, L.L., and Keller, J. 2003. “Identification and comparison of aerobic and denitrifying polyphosphate-accumulating organisms.” *Biotechnol Bioeng* 83: 140–148.

## 6

# NATURAL SYSTEMS FOR WASTEWATER TREATMENT

---

### **Introduction**

Natural wastewater treatment refers to a category of technologies that specifically and substantially utilize natural methods to reduce contaminants from wastewaters in large open fields without incurring the cost of energy-intensive mechanical equipment operations for major treatment responses. The natural wastewater treatment systems have enjoyed a revival, not only in developing countries, but also in the United States; the impetus for this renewed interest in natural systems for our residual problem of modernity is a combination of cost-consciousness and a new mindset of recycling and reuse of yesterday's rejects.

Large-scale land application of wastewater has been practiced for more than 150 years. Initially, municipal and industrial wastewaters were routinely discharged into rivers and lakes. As the population of major cities in Western Europe and America grew exponentially due to the urban migration from rural areas and natural growth of population with the industrial revolution moving full speed ahead, the practice of discharging wastewater into rivers or lakes became a public scourge and the source of epidemic outbreaks. In London during those precarious times, the famed river Thames was constantly filled with human feces and other unmentionables; the city was drenched with stinking air. The House of Parliament was said to smartly soak the drapes with chlorine of lime to ward off the overwhelming odor during parliament sessions. It wasn't until Sir Edwin Chadwick that the suffering of this indignity finally came to an end. Sir Chadwick advocated separation of sewers by practicing the principle of "the rain to the river and the sewer to the soil." This was believed to be the beginning of large-scale land applications of municipal and industrial wastewaters.

The benefits of this practice of sewer disposal were quickly realized with its fertilizing capability. By the turn of the twentieth century, almost all wastewater generated in Western European cities and the North American continent was applied to the land. Today, natural systems including land applications are still used for wastewater treatment and management in many parts of the nation, albeit with different regulations and ordinances enforced in many different jurisdictions.

The natural systems for wastewater treatment are different from the wastewater treatment technologies in the previous chapters in the sense that the natural components of the treatment systems accomplish the majority of the process objectives. This means that natural systems for wastewater management and treatment do not involve large-scale energy and materials input. On the contrary, physical and biological wastewater treatment processes are often complex operations requiring intensive energy input (for mechanical devices/equipment) and/or material input (e.g., flocculants and oxidants), even though these processes also utilize the natural components of the processes (for example, gravity for sedimentation and screening and microorganisms for BOD and nutrient removal). The natural systems for wastewater treatment also provide silent, odor-free, and robust treatment processes; they do, however, require a larger swath of land than those of conventional and more energy-intensive treatment processes. Overall, the natural systems for wastewater treatment and management are categorized based on environs of the systems: aquatic, terrestrial, and wetland.

Constructed wetlands, aquacultural operations, and sand filters are generally the most successful methods of polishing the treated wastewater effluent from the stabilization lagoons. These systems have also been used with more traditional, engineered primary treatment technologies, such as Imhoff tanks, septic tanks, and primary clarifiers. Their main advantage is to provide additional treatment beyond secondary treatment where required.

In recent years, there has been a revival of the uses of the natural systems for agricultural wastewaters from intensive animal farming. North Carolina and other southern states of the United States of America have renewed interests in employing aquatic plants to treat animal wastewaters that contain large amounts of nitrogen compounds and phosphorus compounds; one of the plants used in the region is duckweed, which looks like “oversized” algae floating on a pond or river. Duckweed is one of the smallest flowering plants in the world and can be used as food for fishes,

birds, and of course, ducks. The other application of the high-strength wastewater in growing biomass for value-added biobased materials or energy also attracts interests in the animal farming industries in the region.

### **Stabilization Ponds**

One of the ancient wastewater treatment technologies, the stabilization pond (also referred to as a *lagoon*), has been used continuously as a method of sewage disposal. In some cases, these ponds were also utilized for aquaculture. Stabilization ponds are used for both municipal wastewater treatment and industrial wastewater treatment, particularly for wastewaters from small communities and seasonal industrial wastewaters as well as less affluent communities throughout the world (Fig. 6.1). Although stabilization ponds can be used in most regions of human habitation, their performances in treating wastes are at best in warm climates with adequate sunlight. The current interest in waste stabilization ponds (WSPs) is a result of the accidental discovery of their capabilities when WSPs were used initially as simple sedimentation basins or emergence holding ponds at wastewater treatment plants. A WSP is a relatively shallow body of wastewater contained in an earthen man-made basin into which wastewater flows and from which, after a certain retention time (time that takes the effluent to flow from the inlet to the outlet), a well-treated effluent is discharged. Many characteristics make WSPs substantially different from other wastewater treatment. This includes design, construction and operation simplicity, cost effectiveness, low maintenance requirements, low energy requirements, easy adaptation for upgrading, and high efficiency. They are used for sewage treatment in temperate and tropical climates, and they provide one of the simplest, lowest cost, and most efficient wastewater treatment technologies available. Waste stabilization ponds are very effective in the removal of fecal coliform bacteria. Solar energy is the only requirement for its operation. WSPs have been in use in the United States since 1901. But until fairly recently, the United States Environmental Protection Agency (USEPA) has formalized the design and operational criteria for WSPs (USEPA, 1983).

Over 7,500 WSP systems have been built in the United States serving rural communities with a mean population of less than 10,000. In Canada, there are over 1,000 WSPs in operation representing about a half of the wastewater treatment capacity in the country (Townshend and Knoll,



**Figure 6.1.** A waste stabilization pond system in Mèza, France. It contains two small anaerobic ponds, four experimental facultative ponds, and one series pond system composed of a facultative pond and four maturation ponds.

1987). WSPs are the most common type of wastewater treatment systems in many other countries; particularly in warmer climates (the Middle East, Africa, South Asia, and Latin America), ponds are commonly used for large populations (up to around 1 million). In developing countries and especially in the tropical and equatorial regions, sewage treatment by WSPs has been considered an ideal way of using natural processes to improve sewage effluents. In the recent decades, Europe has seen an increased number of WSPs built in many parts of the region where small populations reside (Gomes de Sousa, 1987). In France, there are approximately 2,500 WSPs in operation throughout the country, mostly for small communities (Racault et al., 1995). The capital and operational costs of WSPs are lower than other comparable wastewater treatment technologies (Mara and Pearson, 1998).

Waste stabilization ponds can be used alone or in combination with other wastewater treatment processes. A typical system consists of several constructed ponds operating in series; treatment of the wastewater occurs as constituents are removed by sedimentation or transformed by biological and chemical processes. In the bottom of the ponds, a sludge layer is




formed, which can impact performance by changing the pond's hydraulics due to a decrease in the pond's effective volume and changes in the shape of the bottom surface. Therefore, periodic sludge removal is usually required. Stabilization ponds suitable for wastewater treatment are those that maintain the right biological conditions for biological interactions and reactions that break down the organic matters and inorganic nutrients. There are five basic types of WSPs. All use microorganisms to degrade and decontaminate organic and inorganic constituents; the types of organisms as well as the amount of oxygen present in the pond systems differ among the five categories forming the basis for classifying stabilization ponds:

- Facultative ponds
- Maturation ponds
- Aerated ponds
- Aerobic ponds
- Anaerobic ponds

The term *oxidation pond* is also used to describe any pond system that utilizes oxygen to break down organic matters, either with or without a significant portion of the dissolved oxygen (DO) provided by photosynthetic algae. All stabilization ponds, with the exception of anaerobic ponds, can be grouped into the oxidation pond category.

### ***Facultative ponds***

The facultative ponds are the most common type of stabilization ponds in use and are able to completely treat both raw, settled sewage and a wide range of industrial wastewaters, including food and agricultural wastewaters with detention time of 5–30 days. These ponds have depth ranging from 1.2–1.5 m (4–8 ft), consisting of two layers of biological treatment zones: an aerobic layer on top of an anaerobic layer, often containing sludge. The aerobic layer stabilizes the wastewater while the fermentation takes place in the anaerobic layer. The oxygen needed for aerobic stabilization comes from photosynthesis of algae in the pond (Fig. 6.2). The algae are photosynthetic organisms and therefore provide a source of oxygen for use by heterotrophic bacteria in the pond for the aerobic breakdown of organic matter. Respiration of organic matter provides a source of carbon dioxide for the algae. This symbiotic relationship between the algae and the bacteria provides the basis for this natural method of waste-



**Figure 6.2.** A schematic diagram of a facultative pond with description of interactions among its components.

water treatment. Because algae in the discharged effluent need to be removed, the treatment process usually involves a facultative pond, one or two maturation ponds and a tertiary treatment phase, such as rock filters or intermittent sand filtration for the removal of algae before discharge of the final effluent to an adjacent watercourse. Total containment ponds are suitable for climates where evaporative loss of water exceeds the rainfall; controlled discharged ponds are used in many areas and climates. The controlled discharged ponds operate discharges once or twice a year, depending on the quality of the treated water being discharged, and tend to have longer detention time.

The longer detention time and the issue of blooming algae in the treated water offset the savings associated with facultative ponds. An obvious solution to the inherited drawbacks of facultative ponds is to add oxygen to the ponds. In an aerated pond, oxygen is supplied to the pond through mechanical aeration equipment and air diffusers. The aerated ponds (which could still be classified either as facultative or as aerobic depending on their DO profile), unlike facultative ponds, can be built deeper, usually in the range of 2–6 m (6–20 ft) because oxygen can be introduced in lower depth. As a result, the detention time is shortened and is in the neighbor-

hood of 3–10 days. Depending on the way the oxygen is delivered to the pond, an aerated pond can be designed as a completely mixed or partially mixed reactor, thus reducing the footprint of the pond. A completely mixed reactor used for an aerated pond has many similar design characteristics of an activated sludge reactor.

### ***Maturation ponds***

Maturation ponds, sometimes also called *tertiary-maturation ponds*, are low-rate stabilization ponds designed to provide secondary effluent (conventional secondary processes or facultative ponds) polishing and pathogen removal. The mechanism for pathogen removal in maturation ponds is actually simple: the removal of microorganisms (pathogens) is due to natural die-off, predation, sedimentation, and adsorption. The majority of pathogens settle onto the sludge in the bottom of the ponds, thus are removed from effluents. In fact, all pond systems can, to some degree, remove pathogens from wastewaters. In order for maturation ponds to remove pathogens substantially, detention times in these ponds must be long enough for pathogens to settle down in the ponds. There is a risk if the sludge is removed from the maturation ponds; handling of the sludge requires caution and the sludge needs to be treated or kept out of the public access.

For high-strength wastewaters, maturation ponds are used for improving the effluent quality prior to surface water discharge of treated wastewaters. Their design, size, and number, in series, are decided in many parts of the world based on the need of removing pathogen from treated wastewater. If the objective of using maturation ponds is for maximum purity in terms of BOD<sub>5</sub> reduction and pathogen removal, algae production is discouraged for maximum light penetration. Maturation ponds, however, are of the same depth as facultative ponds (1 to 1.5 m or 3 to 4.5 ft). A minimum of 15 to 20 days is used as detention time for maturation ponds. Nitrogen removal is presented in these ponds through denitrification in the sludge settled in the ponds. Phosphorus may also be removed by diverse communities of algae. However, algal growth is not desired, particularly if the effluent form of maturation pond is slated to discharge into the receiving water because of turbidity and suspended solids caused by algae. Rock filters in submerged beds are used sometimes for removal of these algal solids. The algae retained by rock filters decompose and are utilized by bacterial biofilm on rock materials. In general, the arrangement of pond


systems starts with an anaerobic pond, and then a facultative pond, and finally a maturation pond in a series, depending on the quality of the influent and the treatment objective.

### *Aerated lagoons*

An aerated lagoon is a stabilization pond with its aerobic condition maintained by mechanical or diffused aeration equipment. Bubble aeration is provided sometimes to keep the pond aerobic in locations where pond surfaces are frozen for extended periods in winter. Unlike aerobic ponds, aerated lagoons do not rely on algae for oxygen delivery. The microbial characteristics of an aerated pond are very similar to those of an activated sludge process. Its detention times are in the order of 1 to 10 days, depending on organic loading rate, temperature, and the degree of treatment required. The organic loading of aerated lagoons is expressed as BOD<sub>5</sub> per unit volume per day. Aeration ponds are susceptible to a large amount of BOD<sub>5</sub> loadings or toxic wastes, which can severely hinder the ponds' efficiency. The solids in the pond need to be suspended all the time to avoid the solids settling in the bottom of the pond and forming an anaerobic layer, thus reducing the efficiency and generating odor. Fig. 6.3 shows a schematic portrait of an aerated lagoon and a photo of an aerator at work in an aerated pond.

### *Aerobic ponds*

Aerobic ponds, also called high-rate aerobic ponds, are designed to maintain a constant dissolved oxygen (DO) level throughout the depth of the ponds. The aerobic ponds can be viewed as "turbo-charged" facultative ponds with added oxygen functioning. As a unit process, aerobic ponds fall between facultative ponds and activated sludge processes. They are usually shallow (30–45 cm or 12–18 in), allowing light to penetrate the entire depth of the ponds. Oxygen is provided by both an external device and algae through photosynthesis; mixing is also provided to disperse oxygen and expose algae to sunlight as well as prevent anaerobic conditions in the ponds. The detention time for this type of pond is relatively short, about 3–5 days. In order to maintain the constant oxygen level in all depths, these ponds are best used in warm and sunny locations where photosynthesis of algae is quick enough to provide sufficient DO needed to degrade the organic matters in wastewater.



**Figure 6.3.** A schematic diagram of an aerated pond with surface aerators.

### *Anaerobic ponds*

For strong food and agricultural wastewater, anaerobic ponds can be used to degrade the heavy loading of organic matters. In general, there are three identifiable zones in a basic design of an anaerobic lagoon: the scum layer, the supernatant layer, and the sludge layer. The system requires longer time (20–50 days); its depth is in the range of 2.5–5 meters (8–16.3 ft) and produces acid and methane. In anaerobic ponds,  $BOD_5$  removal is achieved by sedimentation of solids and subsequent anaerobic digestion in the resulting sludge. The process of anaerobic digestion is more intense at temperatures above 15°C. The anaerobic bacteria are usually sensitive to  $pH < 6.2$ . Thus, acidic wastewater must be neutralized prior to its treatment in anaerobic ponds. A well-designed anaerobic pond will achieve about a 40% removal of  $BOD_5$  at 10°C, and more than 60% at 20°C. A shorter retention time of 1.0–1.5 days is commonly used. The design criteria for anaerobic lagoons are different from other designs of the stabilization ponds; the main noticeable difference is depth of the lagoon. Oxygen transfer through the air-water interface of a lagoon is not important at all; in fact, it is undesirable for the anaerobic lagoon. Thus, anaerobic lagoons are typically deep basins 2–5 meters (6.5–16.3 ft) in depth.

Anaerobic lagoons are often used as a preliminary treatment for high-strength wastewaters with high content of organic materials, such as those found in food processing wastewaters rich in fat and proteins. As a result, anaerobic lagoons can only partially stabilize wastewaters, and further treatment, most likely aerobic processes, is needed before the wastewaters can be discharged to the receiving waters. It is common to place facultative ponds or activated sludge processes right after anaerobic lagoons for




**Figure 6.4.** A photograph of an anaerobic pond for wastewater treatment in the field.

desired treatment goals. Slaughterhouses and meat processing wastewaters ( $BOD_5$ : ~1,400 mg/l; FOG: ~500 mg/l; pH: ~7; temperature: 28°C) are particularly suitable for treatment by anaerobic lagoons after preliminary treatment such as removal of coarse solids and excessive grease or blood. Fig. 6.4 shows a picture of an anaerobic stabilization pond in the field.

### ***Design of stabilization ponds***

WSPs often comprise a single string of anaerobic, facultative or aerated/aerobic, and maturation ponds in series, or several such series in parallel depending on the organic strength of influents and the effluent quality objectives. In essence, anaerobic and facultative or aerated/aerobic ponds are designed for removal of BOD, and maturation ponds for pathogen removal. For ease of maintenance and flexibility of operation, at least two trains of similar ponds in parallel are built in for many designs. High-strength wastewaters, with  $BOD_5$  concentration in excess of about 300



**Figure 6.5.** Several stabilization pond configurations: A = anaerobic pond; F = facultative pond; M = maturation pond (adapted from Pescod and Mara, 1988).

mg/l, will frequently be introduced into first-stage anaerobic ponds, which achieve a high volumetric rate of removal. However, wherever anaerobic ponds are deemed unacceptable by the regulatory agencies or the public at large, wastewaters, regardless of strength, may be discharged directly into primary facultative ponds. Effluent from first-stage anaerobic ponds will overflow into secondary facultative ponds, which comprise the second-stage of biological treatment. Pescod and Mara (1988) summarized several common pond system configurations (Fig. 6.5), though other combinations may conceivably be used. The design loadings for stabilization ponds are usually measured in BOD per unit area. In anaerobic ponds, the loading is expressed as BOD per unit volume; this is because light, which is strongly affected by the surface area, is not an important factor in anaerobic ponds.

Facultative pond design is based on BOD removal, and most states set

**Table 6.1.** Recommendations for loading rates for various climatic conditions (adapted from Reed et al., 1995).

Climatic Condition	BOD <sub>5</sub> Loading Rate
Air temperature above 15°C in winter	45–90 kg/ha·d (40–80 lb/ac·d)
Air temperature between 0 and 15°C in winter	22–45 kg/ha·d (20–40 lb/ac·d)
Air temperature below 0°C in winter	11–22 kg/ha·d (10–20 lb/ac·d)

up their own design criteria for BOD loading and/or hydraulic detention time for facultative ponds. Reed et al. (1995) recommended the load rates for various climatic conditions for designing facultative ponds based on their experience (Table 6.1). Over the years, several empirical and rational models have been developed for the design of the ponds (Reed et al., 1995). These models range from ideal plug flow models to completely mixed pond models as well as something between these two extremes. Each of these models has produced satisfactory results in certain circumstances, but its use in the real world is limited because they require evaluating multiple coefficients, which have to be evaluated from the similar WSP systems. Reed et al. (1995) have compared several design models for facultative ponds and concluded that there was no “best procedure” for recommendation in designing facultative ponds.

The BOD loading rate in the first cell is limited to 40 kg/ha·d or less, and the total hydraulic detention time in the system is 120–180 days when the average temperature is below 0°C; the loading can be increased to 100 kg/ha·d when the average temperature is above 15°C (Reed et al., 1995).

#### *The size of facultative ponds*

The size of facultative ponds is determined by the following (Equation 6.1):

$$L_s = 10 L_i Q / A_f$$

where:

$L_s$  = surface BOD<sub>5</sub> loading, kg/ha·d

$L_i$  = influent BOD<sub>5</sub>, mg/l

$Q$  = flow, m<sup>3</sup>/d

$A_f$  = facultative pond area, m<sup>2</sup>



**Table 6.2.** BOD<sub>5</sub> reduction as a function of detention time and temperature (adapted from WHO, 1987).

Temperature (°C)	Detention Time (d)	BOD <sub>5</sub> Removal Rate (%)
10	5	0–10
10–15	4–5	30–40
15–20	2–3	40–50
20–25	1–2	40–60
25–30	1–2	60–80

There is no consensus when it comes to the best design approach for anaerobic ponds. Customarily, volumetric BOD<sub>5</sub> loading rate, temperature, and hydraulic detention time form the basis for anaerobic ponds. The World Health Organization (WHO) recommends the following guidelines for BOD removal rate 50% or higher (WHO, 1987):

- Volumetric loading,  $L_v$ , up to 300 g BOD<sub>5</sub> kg/m<sup>3</sup>·d
- Hydraulic detention time of about 5 days
- Depth of the pond between 2.5 and 5 m

Table 6.2 shows BOD<sub>5</sub> reduction as a function of detention time and temperature (adapted from WHO, 1987).

*The size of anaerobic ponds*

Anaerobic ponds can be satisfactorily designed, and without risk of odor nuisance, on the basis of volumetric BOD<sub>5</sub> loading ( $l_v$ , g/m<sup>3</sup>d), which is given by the following (Equation 6.2):

$$l_v = L_i Q / V_a$$

where:

$L_v$  = volumetric BOD<sub>5</sub> loading, kg/m<sup>3</sup>·d or lb/ft<sup>3</sup>·d

$L_i$  = influent BOD<sub>5</sub>, mg/l

$Q$  = flow, m<sup>3</sup>/d or ft<sup>3</sup>/d

$V_a$  = anaerobic pond volume, m<sup>3</sup> or ft<sup>3</sup>

*Hydraulic balance*

To maintain the liquid level in the ponds, the inflow must be, at least, greater than net evaporation and seepage at all times. Thus, we use the following (Equation 6.3):

$$Q_i = 0.001 A (e + s)$$

where:

$Q_i$  = inflow to first pond, m<sup>3</sup>/d or ft<sup>3</sup>/d

$A$  = total area of pond series, m<sup>2</sup> or ft<sup>2</sup>

$e$  = net evaporation (i.e., evaporation less rainfall), mm/d or in/d

$s$  = seepage, mm/d or in/d

Many WSPs are designed to handle with BOD<sub>5</sub> and TSS loadings, and their capacity of removing BOD<sub>5</sub> and TSS is well documented and reasonably representative in their designs; however, nitrogen removal capacity of these ponds is crucial given the fact that food and agricultural wastewaters tend to be rich in nitrogen content and that ammonia in treated wastewaters can be detrimental to fishes in the receiving waters. And in the case of sludge from pond systems that is used in land treatment, nitrogen in the sludge may affect the design of the land application and its costs. There are two important empirical models developed based on the real data from the fields and they are validated by the data in later studies. These two models are summarized in Table 6.3 and Table 6.4.

Phosphorus removal in stabilization ponds is an important design consideration only in north central United States and Canada. For example, the discharge limit for phosphorus in the Great Lakes is 1 mg/l. In order to achieve this criterion, chemicals are added to the pond system to reduce the phosphorus level. A typical alum dosage of 150 mg/l may reduce phosphorus to less than 1 mg/l and less than 20 mg/l BOD<sub>5</sub> and TSS (Reed et al., 1995).

Without chemical addition, phosphorus removal in stabilization ponds can still be achieved. The mechanisms of phosphorus removal most likely take place in maturation ponds (Mara et al., 1992). The efficiency of total phosphorus removal in WSPs depends on how much biomass settled in the bottom of the pond systems; the biomass utilizes the phosphorus in wastewater (as described in biological phosphorus removal in Chapter 5). Thus, the best way of increasing phosphorus removal in WSPs is to increase the

**Table 6.3.** Design model for nitrogen removal from stabilization pond systems (Pano and Middlebrooks, 1982).

For temperatures below 20°C:

$$C_e = C_i / \{1 + [(A / Q) (0.0038 + 0.000134T) \exp ((1.041 + 0.044T) (pH - 6.6))]\}$$

For temperatures above 20°C:

$$C_e = C_i / \{1 + [5.035 \times 10^{-3} (A / Q)] [\exp (1.540 \times (pH - 6.6))]\}$$

Where:

- $C_e$  = ammonia-N concentration in pond effluent, mg N/l
- $C_i$  = ammonia-N concentration in pond influent, mg N/l
- $A$  = pond area, m<sup>2</sup>
- $Q$  = influent flow rate, m<sup>3</sup>/d
- pH = 7.3 exp(0.0005  $A_i$ )
- $A_i$  = influent alkalinity, mg CaCO<sub>3</sub>/l

**Table 6.4.** Design model for nitrogen removal from stabilization pond systems (Reed, 1984).

$$C_e = C_i \exp\{-[0.0064 (1.039)^{T-20}] [q + 60.6 (pH - 6.6)]\}$$

Where:

- $C_e$  = total nitrogen concentration in pond effluent, mg N/l
- $C_i$  = total nitrogen concentration in pond influent, mg N/l
- $T$  = temperature, °C (range: 1–28°C)
- $q$  = retention time, d (range 5–231 d)
- pH = 7.3 exp (0.0005  $A_i$ )
- $A_i$  = influent alkalinity, mg CaCO<sub>3</sub>/l

number of maturation ponds so that, little by little, phosphorus becomes immobilized in the sediments. For a well running two-pond system, 70% mass removal of total phosphorus may be achievable.

### Land Treatment Systems


Land application of wastewater is perhaps the oldest method for disposal and treatment of wastewaters. Early systems were used in England as

“Land Farms,” which received untreated wastewater and night soil from nearby communities. Today, land application systems have included application to edible and nonedible crops, to rangelands, to forests and wood plantations, to recreational areas including parks and golf courses, and to disturbed lands such as mine spoil sites.

Land application of wastewater also plays a role in recharging groundwater and recycling fresh water. On the average, water that is used once and then discharged to the ocean would not return as rain on land for about 2,600 years. This fact has shed a spotlight on the wastewater reuse issue. Wastewater reuse in agriculture and other fields is not new; however, increasing environmental awareness has made the reuse of wastewater, even after careful treatment, a tainted prospect. This level of concern about reuse of wastewater is not unreasonable, given the checkered history of wastewater disposal throughout human development across the world. But as wastewater treatment technologies advance and quality of treated effluents steadily improves, the land application of treated wastewater from food and agriculture becomes a cost-effective alternative to discharging into the surface water, including oceans.

There are two major categories of reuse of wastewater, which have been practiced throughout the world: potable use and nonpotable use. The potable use of wastewater mainly includes injecting reclaimed water to the drinking water supply after multiple levels of treatments, or using natural systems (including land applications) to treat wastewater directly. Nonpotable uses of wastewater are many: direct irrigation of agriculture fields using food wastewater with low BOD<sub>5</sub> and TSS; irrigation of parks, forests, or golf courses with low-load wastewater; and use for aquaculture are the most promising examples. In many areas of the world, wastewater reuse has been practiced using a combination of treatment technologies that achieve a very high degree of treatment. Many states in the western U.S. have, over the past 20 years, been treating wastewater to tertiary treatment standards and then allowing the wastewater to be reused for irrigation or for recharge to groundwater aquifers. Although this is an effective method for many arid regions in the western U.S., it is very expensive and is rarely practiced in other regions of the world.

The land application of wastewaters is not without risk of contamination of soil and groundwater beneath it. The challenge is to utilize the physico-chemical and biological properties of the soil as an acceptor for the wastewater streams without undue effect on the crops that are to be grown or to the ecosystem of which the land is a part, to the characteristics of the soil,



**Figure 6.6.** A schematic illustration of land applications of wastewaters.

and to the quality of the groundwater and the surface water. The wastewater and the soil to which the wastewater is applied should be managed as an integrated system to obtain the best outcome of the application.

Land application of wastewaters incorporates organic and inorganic materials into the soil for recycle and reuse. The assimilative capacity of a soil is dependent on its characteristics and environmental conditions. The maximum capacity of a soil represents the maximum wastewater loading of the soil. This is true for raw wastewaters as well as treated wastewaters. Each application site will have a controlling parameter dependent on characteristics of the wastewater applied and characteristics of the soil, and most importantly, the environmental ramification. In most cases, permits are required for applying wastewater to the land.

Fig. 6.6 is a schematic diagram of the use of land for plantation and wastewater land applications. As shown in the diagram, many factors are involved in the overall effect of the water cycle on plants, including land application of wastewater. In most cases, the treated wastewater is applied to the land surface via furrow-flood, sprayer, or drip irrigation. BOD<sub>5</sub>, TSS, and fecal coliform (FC) are partially removed in the conventional

**Table 6.5.** Characteristics of land wastewater treatment systems (adapted from USEPA, 1981, 1984).

Feature	Slow Rate	Overland Flow	Rapid Infiltration
Application Techniques	Sprinkler or Surface <sup>a</sup>	Sprinkler or Surface	Usually Surface
Annual loading rate, m	0.5–6	3–20	6–125
Field area required, ha <sup>b</sup>	23–280	6.5–44	3–23
Typical weekly loading rate, cm	1.3–10	6–40 <sup>c</sup>	10–240
Minimum preapplication provided in the United States	Primary sedimentation <sup>d</sup>	Grit removal and screening	Primary sedimentation <sup>e</sup>
Disposition of applied wastewater	Evapotranspiration and percolation	Mainly surface runoff and evapotranspiration	Percolation
Need for vegetation	Required	Required	Optional

<sup>a</sup>Includes ridge-and-furrow and border strip.

<sup>b</sup>Field area in hectares not including buffer area, roads, or ditches for 3,785 m<sup>3</sup>/d (1 Mgal/d) flow.

<sup>c</sup>Range includes raw wastewater to secondary effluent, higher rates for higher level of preapplication treatment.

<sup>d</sup>With restricted public access; crops not for direct human consumption.

<sup>e</sup>With restricted public access.

wastewater treatment steps; the land application system removes additional BOD<sub>5</sub>, TSS, and FC as well as nitrogen and phosphorus.

Various designs of land application systems have been developed, including application of wastes to the soil-surface using *slow rate*, *overland flow*, and *rapid infiltration* land treatment systems, and to the subsurface using leaching fields and absorption beds. The suitability of a particular system depends on site characteristics, including soil properties, ground topography such as slope and relief, local hydrology, groundwater depth and quality, land use, climatic factors such as temperature, precipitation, evapotranspiration, wind, length of growing season, and expected waste loading rates, as well as consideration of possible social and economic

**Table 6.6.** Comparison of site characteristics for land treatment processes (adapted from USEPA, 1981, 1984).

Characteristics	Slow Rate	Overland Flow	Rapid Infiltration
Slope	Less than 20% on cultivated land; less than 40% on noncultivated land	Finish slopes 1–8% <sup>a</sup>	Not critical; excessive grades require much earthwork
Soil permeability	Moderately slow and moderately rapid	Slow (for cold clays, silts, soils with impermeable barriers)	Rapid (sands, sandy loams)
Depth to ground water	0.6–1 m (minimum) <sup>b</sup>	Not critical <sup>c</sup>	1 m during flood cycle <sup>b</sup> ; 1.5–3 m during drying cycle
Climatic restrictions	Storage often needed for cold weather and during heavy precipitation	Storage needed for cold weather	None (possibly modify storage usually needed in cold weather)

<sup>a</sup>Steeper grades might be feasible at reduced hydraulic loadings.

<sup>b</sup>Under-drains can be used to maintain this level at sites with high ground water table.

<sup>c</sup>Impact on ground water should be considered for more permeable soils.

constraints. Tables 6.5 and 6.6 list the characteristics of three major types of land application systems and comparison of site characteristics for natural systems.

In designing any land application system, several common attributes of land application systems are often included in overall considerations:

- Public health
- Groundwater issues
- Site evaluation and selection
- Crop selection and management if needed
- Preapplication treatment


- Distribution methods
- Design hydraulic loading rate
- Application rate
- Climatic consideration and storage
- BOD<sub>5</sub> loading rate if needed
- Nitrogen removal
- Limiting nitrogen loading rate if required
- Suspended solid removal
- Phosphorus removal
- Land requirements
- Recovery of effluent from land application if possible

### ***Slow-rate (SR) systems***

Slow rate systems are the prevailing form of land application system in use today and involve the application of pretreated wastewaters to vegetated soil to provide treatment of the wastewater and meet the growth needs of the existing vegetation through evapotranspiration and percolation (see Fig. 6.7). The systems are similar to those found in common agricultural irrigation. The annual loading rate of the systems ranges from 0.5 to 6 m/year. There are roughly three types of slow-rate systems categorized by the objectives of applications of the slow-rate systems (Paranychianakis et al., 2006):

- Type I is based on the objective of reuse of wastewater for crop and vegetation growth. The application of pretreated wastewater can be achieved through the uses of sprinklers, ridge-and-furrow, border strip flooding, and other surface or subsurface methods.
- Type II focuses on treatment of wastewater not on reuse of wastewater. When the primary objective of the SR process is treatment, the hydraulic loading is usually limited, either by the hydraulic capacity of the soil or the nitrogen removal capacity of the soil-vegetation matrix. Under-drains are sometimes needed for development of sites with high groundwater tables, or where perched water tables or impermeable layers prevent deep percolation. Perennial grasses are often chosen for the vegetation because of their high nitrogen uptake, a longer wastewater application season, and the avoidance of annual planting and cultivation. Corn and other crops with higher market values are also grown on systems where treatment is the major objective.





**Figure 6.7.** (a)(b)(c) A schematic diagram of a slow-rate wastewater treatment system (USEPA, 1981).

- Filter beds treat wastewaters through the actions of percolation and filtration of the beds. The treated effluents are collected by a vast underground drain system. Filter bed systems are effective in nutrient removal and suitable for population-intensive areas such as urban areas. Specifically modified filter beds can be used for treating various indus-

trial wastewaters such as those from animal farming and dairy operations (Jayawardane et al., 1997).

### *SR system design*

Slow-rate systems must be combined with other processes in order to produce a complete wastewater treatment. Preapplication treatment is often required to ensure protection of public health, nuisance control, and distribution systems constraints. The main concern is the pathogen content in wastewaters. There are several common processes that can be used: fine screening, primary sedimentation, and pH adjustment, as well as biological processes such as stabilization ponds.

Crop selection is also important for slow-rate land systems for application of pretreated wastewaters, particularly for water reuse. The choice of individual crops depends on the nitrogen content and revenue for Type I systems and maximum nutrient uptake for Type II. Revenue-generating field crops such as corn, soybean, sugar beets, barley, and wheat are all good choices. For forage crops, alfalfa, quack grass, ryegrass, orchard grass, bromegrass, and Kentucky bluegrass are suitable crops for maximum removal of nutrients.

For hydraulic loading for Type I systems, the water balance equation is used to determine the hydraulic rate (Equation 6.4):

$$L_w = ET - P_r + P_w$$

where:

$L_w$  = wastewater hydraulic loading rate based on soil permeability

$ET$  = evapotranspiration rate, in/mo

$P_r$  = precipitation rate, in/mo

$P_w$  = percolation, in/mo

The  $ET$  is normally the monthly average  $ET$  rate of the selected crop and is determined from the historical evaporation data (at least 15 consecutive years). The value of  $P_r$  should be determined from a frequency analysis of wetter than normal years (using 10 years as a basis). The design percolation rate  $P_w$  is estimated to be 4–10% of the measured field test data or published data based on wet:dry ratio, thus is determined by the following (Equation 6.5):

$$P_w \text{ (daily)} = K (24 \text{ h/d})(\text{Adjustment Factor})$$

where:

$P_w$  = design percolation rate, cm/d or in/d

$K$  = permeability of limiting soil layer, cm/h or in/h

Adjustment Factor = 4% to 10% to account for wet:dry ratio and ensure a conservative and safe value for infiltration of wastewaters

For hydraulic loading based on nitrogen limits, the nitrogen balance for the SR system is the following (Equation 6.6):

$$L_n = U + f(L_n) + A(C_p)(P_w)$$

where:

$L_n$  = mass loading of nitrogen, kg/ha·yr or lb/ac·yr

$U$  = crop uptake, kg/ha·yr or lb/ac·yr

$f$  = fraction of applied nitrogen lost to denitrification, volatilization, and soil storage

$A$  = unit conversion factor, 0.1 for metric units and 2.7 in imperial units

$C_p$  = percolation nitrogen concentration, mg/l, usually set at 10 mg/l due to the limiting nitrogen concentration

$P_w$  = percolation rate, cm/yr or ft/yr

Crop uptake can be found from the literature and the  $f$  value is based on wastewater characteristics and climate: 0.5 to 0.8 if the BOD<sub>5</sub>:nitrogen ratio is 5 or more, 0.25 to 0.5 for primary treatment effluents in municipal wastewater plants, and 0.15 to 0.25 should be used for effluents from secondary treatment processes of municipal wastewater treatment plants; a value of 0.1 is used for effluents from advanced wastewater treatment processes.

For Type II slow-rate systems, hydraulic loading rate is based on water balance and is expressed as the following (Equation 6.7):

$$L_w = IR - P_r$$

where:

$L_w$  = hydraulic loading rate

$IR$  = crop irrigation requirement

$P_r$  = precipitation, cm/yr, m/yr or in/yr

The crop irrigation requirement depends on the crop ET, the irrigation efficiency, and the leaching requirement. Incorporating these three factors into Equation 6.7 yields the following (Equation 6.8):

$$L_w = (ET - P_r)(1 + LR)(100/E)$$

where:

LR = leaching requirement

$P_r$  = precipitation, cm/yr, m/yr or in/yr

ET = evapotranspiration rate, inch/month

E = efficiency of the irrigation systems



The leaching factor ranges from 0.05 to 0.30 depending on the crop, the amount of precipitation, and the total dissolved solids in the wastewater. For the total dissolved solids of 400 mg/l or more, LR is in the range from 0.1 to 0.2. The efficiency of the irrigation system is 0.65 to 0.75 for surface irrigation systems, 0.7 to 0.8 for sprinklers, and 0.9 to 0.95 for drip irrigation systems.

### ***Overland-flow systems***

Overland-flow is essentially a biological treatment process in which wastewater is treated as it flows over the upper reaches of sloped terraces and is allowed to flow across the vegetated surface to runoff collection ditches. Unlike slow-rate systems, overland-flow systems are designed to facilitate the runoff of wastewaters. In order to ensure a runoff, the soil on the slope should be either impervious to water or slowly permeable to limit percolation.

A schematic view of the overland-flow treatment is shown in Fig. 6.8 (a), and a pictorial view of a typical system is shown in Fig. 6.8(b). As shown in Fig. 6.8(a), there is relatively little percolation involved either because of an impermeable soil or a subsurface barrier to percolation. Wastewaters are either sprinkler-applied, fan-sprayed, or surface-applied (e.g., gated pipe) to the top of the slope. The treatment of the wastewater occurs as the flow runs down the graded land. The slopes are normally 2–8% grade and 30–61 m (100–200 ft) in length, as tabulated in Tables 6.5 and 6.6.

The objectives of overland-flow systems are to achieve high effluent quality by applying to the land pretreated wastewaters and to remove ni-



**Figure 6.8.** (a)(b) A schematic diagram of an overland flow wastewater treatment system (USEPA, 1984).

trogen, phosphorus,  $BOD_5$ , and suspended solids. The pretreatment includes grit and fine screening, primary sedimentation, secondary processes, or pond systems. It is also feasible for treating high-strength food processing wastewaters. The collected overland-flow treated water from the ditches is discharged to surface waters.

The primary removal mechanisms for organics and suspended solids are biochemical oxidation, sedimentation, adsorption, and filtration. Nitrogen removal is a combination of plant uptake, denitrification, and volatilization of ammonia nitrogen. The dominant mechanism in a particular site will depend on the forms of nitrogen present in the wastewater, the amount of carbon available, the temperature, and the loading rates and schedules of wastewater application. Permanent nitrogen removal by the plants is possible only if the crop is harvested and removed from the field. Ammonia volatilization can be significant if the pH of the wastewater is above 7. Nitrogen removals usually range from 75–90%, with the form of runoff nitrogen dependent on temperature and on application loading rates and schedule. Because microbial activities for denitrification occur at or near the soil surface, the denitrification reactions are adversely affected by cold weather; the same problem also afflicts plant uptake of ammonia as the majority of crops die off or are in the dormant state in cold winter. Less removal of nitrate and ammonium may result from cold temperature in winter in many nontropical or non-subtropical regions of the world.

Phosphorus is removed by adsorption and precipitation. Treatment efficiencies are somewhat limited because of the limited contact between the wastewater and the adsorption sites within the soil. Phosphorus removals usually range from 50–70% on a mass basis. Increased removals may be obtained by adding coagulants such as alum or ferric chloride to the wastewater just prior to application on the slope.

#### *Overland-flow system design*

The soil permeability is an important parameter for designing an overland-flow system, because runoff of wastewater along the slope of the land is required. The best sites for overland-flow systems have soil permeabilities less than 0.5 cm/h (0.2 in/h) or less. The high permeability soils can be compacted mechanically to reduce permeability to acceptable levels. Low temperature and rainfall can affect overland-flow systems and as such, the wastewater application may be curtailed or ceased; the wastewater is stored.

The hydraulic loading rate of wastewater is empirically selected to be from 2 to 10 cm/d (0.8 to 4 in/d). Because there is little percolation, the application rate (see the definition below) is more relevant a performance parameter than hydraulic load rate. The two rates are related in the following expression (Equation 6.9) (Reed et al., 1995):

$$L_w = [qp (100 \text{ cm/m})]/z$$

where:

$L_w$  = hydraulic loading rate, cm/d or in/d

$q$  = application rate per unit width of the slope,  $m^3/h \cdot m$  or gal/min·ft

$p$  = application period, h/d (ranging from 6 to 12 hours per day; 8 h/d is selected for the purpose of convenience)

$z$  = distance down-slope, m or ft (ranging from 30 to 60 m or 100 to 200 ft; for surface application, the length should be 30 to 45 m or 100 to 150 ft)

The application rate is also related to slope length and BOD removal through the following first-order reaction equation (Equation 6.10) (Reed et al., 1995):

$$(C_z - C)/C_0 = A \exp[(-kz)/q^n]$$

where:

$C_z$  = BOD<sub>5</sub> concentration of surface flow at a distance ( $z$ ) down-slope, mg/l

$C$  = background BOD<sub>5</sub> at the end of the slope

$C_0$  = BOD<sub>5</sub> concentration of applied wastewater, mg/l

$z$  = distance down-slope, m or ft

$A$  = empirically determined coefficient dependent on the value of  $q$

$q$  = application rate,  $m^3/h \cdot m$  or gal/min·ft

$n$  = empirically determined exponents (<1)

$k$  = empirically determined rate constant

For overland-flow treatment of high-strength industrial wastewater such as some food processing wastewaters, the BOD<sub>5</sub> loading must be considered. In order to avoid an excessive amount of organic loading on the slope, which leads to anaerobic activities due to exhausting of oxygen at or near the soil surface, the BOD<sub>5</sub> loading rate is controlled at the following (Equation 6.11):

$$L_{BOD} = B L_w C_0$$

where:

$L_{BOD}$  = BOD<sub>5</sub> loading rate, kg/ha·d or lb/ac·d

$B$  = conversion factor = 0.1 for metric units or 0.225 for imperial units

$L_w$  = hydraulic loading rate, cm/d or in/d  
 =  $qPw/z$

$q$  = application rate,  $m^3/h \cdot m$  or gal/min·ft

$P$  = application period, h/d

$W$  = width of application slope, m or ft

$z$  = distance down-slope, m or ft

$m$  = conversion factor = 100 cm/m or 96.3 for imperial units

$C_0$  = BOD<sub>5</sub> concentration of applied wastewater, mg/l

When BOD<sub>5</sub> concentration of wastewater exceeds 800 mg/l, the wastewater has been diluted in order to avoid excessive anaerobic activities.

Land requirements for overland-flow systems depend on the flow, the application rate, and the application period. The required surface area for overland-flow treatment is the following (Equation 6.12):

$$A_s = Q z / (q P C)$$

where:

$A_s$  = field surface area required, ha or ac

$Q$  = wastewater flow rate,  $m^3/d$  or gal/min

$z$  = distance down-slope or slope length, m or ft

$q$  = application rate,  $m^3/h \cdot m$  or gal/min·ft

$P$  = application period, h/d

$C$  = conversion factor = 10,000  $m^2/ha$  or 726 for imperial units

If wastewater storage is anticipated, the field area becomes the following (Equation 6.13):

$$A_s = (365Q + V_s) / (D L_w C')$$

where:

$A_s$  = field surface area required, ha or ac

$V_s$  = net loss or gain in storage volume due to precipitation, evaporation, and seepage,  $m^3/yr$  or  $ft^3/yr$

$D$  = number of operating days per year

$L_w$  = design hydraulic loading, cm/d or in/d

$C'$  = conversion factor = 100 for metric units and 3630 for imperial units



If BOD<sub>5</sub> loading is a limiting factor, the field area is expressed as the following (Equation 6.14):

$$A_s = (C_0 C'' Q_a) / L_{\text{LBOD}}$$

where:

$A_s$  = field surface area required, ha or ac

$C_0$  = BOD<sub>5</sub> concentration of applied wastewater, mg/l

$C''$  = conversion factor = 0.1 for metric units and  $6.24 \times 10^{-5}$  for imperial units

$L_{\text{LBOD}}$  = limiting BOD<sub>5</sub> loading rate = 100 kg/ha·d or 89 lb/ac·d


$Q_a$  = design flow rate to the overland-flow site, m<sup>3</sup>/d or ft<sup>3</sup>/d

### ***Rapid-infiltration systems***

The objective of the application of rapid-infiltration systems is to recharge or store renovated water in the underground aquifer and, in some cases, recharge surface waters using under-drains or wells to channel the water to the adjacent surface water body. In rapid-infiltration land treatment, most of the applied wastewater percolates through the soil, and the treated effluent drains naturally to surface waters or joins the ground water. The wastewater is applied to moderately and highly permeable soils (such as sands and loamy sands), by spreading in basins or by sprinkling, and it is treated as it travels through the soil matrix. Vegetation is not usually planned, but there are some exceptions, and emergence of weeds and grasses usually does not cause problems.

The schematic view in Fig. 6.9(a) shows the typical hydraulic pathway for rapid infiltration systems. A much greater portion of the applied wastewater percolates to the groundwater than with SR land treatment. There is little or no consumptive use by plants. Evaporation ranges from about 0.6 in/yr for moderately permeable soil (2 ft/yr for highly permeable soil) for cool regions to 2 in/yr for moderately permeable soil (6 ft/yr for highly permeable soil) for hot arid regions. This is usually a small percentage of the hydraulic loading rates.

In many cases, recovery of renovated water is an integral part of the system. This can be accomplished using under-drains or wells, as shown in Fig. 6.9(b). In some cases, the water drains naturally to an adjacent surface water body, as in Fig. 6.9(c). Such systems can provide a higher level



**Figure 6.9.** (a)(b)(c) A schematic diagram of a rapid infiltration wastewater treatment system (USEPA, 1984).

of treatment than most mechanical-intensive systems for discharging to the same surface water.

Removals of wastewater constituents by the filtering and straining action of the soil are superb. Suspended solids, BOD<sub>5</sub>, and fecal coliforms are almost completely removed. Nitrification of the applied wastewater is essentially complete when appropriate hydraulic loading cycles are used. Hence, for communities that have ammonia standards in their discharge requirements, rapid-infiltration can provide an effective way to meet such standards. Generally, nitrogen removal averages 50% unless specific operating procedures are established to maximize denitrification. These procedures include optimizing the application cycle, recycling the portions of the renovated water that contain high nitrate concentrations, reducing the infiltration rate, and supplying an additional carbon source. Using these procedures in soil column studies, average nitrogen removals of 80% have been achieved.

Phosphorus removals can range from 70–99%, depending on the physical and chemical characteristics of the soil. As with slow-rate systems, the primary removal mechanism is adsorption with some chemical precipitation, so the long-term capacity is limited by the mass and the characteristics of soil in contact with the wastewater. Removals are related also to the residence time of the wastewater in the soil, the travel distance, and other climatic and operating conditions.

#### *Rapid-infiltration system design*

The design of the annual hydraulic loading rate of a rapid-infiltration system is based on the permeability of the soil or the effective hydraulic conductivity of the soil media that the wastewater infiltrates. The rate is expressed as follows (Equation 6.15) (Metcalf and Eddy, Inc., 1991):

$$L_w = (IR)(OR) F C'''$$

where:

$L_w$  = hydraulic loading rate, ft/yr or cm/yr

IR = infiltration rate, in/h, cm/h

OD = number of operating days per year, day/yr

F = application factor (10–15% of the minimum measured infiltration rate if basin infiltration is used; 4–10% of the conductivity of the most restrictive soil layer if vertical hydraulic conductivity measurements)

$C'''$  = conversion factor = 2 for imperial units and 24 for metric units

Application of a rapid-infiltration system to wastewater treatment is not continuous but in cycle; the purpose of nonapplication periods (dry periods) is to allow the land to reaerate and decompose the accumulated organic matters in the soil. The application rate thus can be calculated based on the hydraulic rate, operating cycle time, and application period. The land requirement of a rapid-infiltration system is obtained by dividing the annual wastewater flow rate by the design of the annual hydraulic loading rate in Equation 6.15.

### **Wetland Systems**

Natural wetlands (e.g., swamps, bogs, marshes, fens, sloughs, etc.) are long recognized as providing many benefits, including food and habitat for wildlife, water quality improvement, flood protection, shoreline erosion control, and opportunities for recreation and aesthetic appreciation. Many of these same benefits have been realized by projects across the country, which involve the use of wetlands in wastewater treatment.

Wetlands are constructed as either surface flow (see Fig. 6.10) or subsurface flow systems (see Fig. 6.11). Both types of wetlands treatment systems typically are constructed in basins or channels with a natural or constructed subsurface barrier to limit seepage (USEPA, 1993). Surface flow systems require more land, but generally are easier to design, construct, and maintain. They consist of shallow basins with emergent and submergent wetland plants that tolerate saturated soil and aerobic conditions. Water flows in one end of the basin, moves slowly through, and is released at the other end. These systems provide habitat and public access. Subsurface flow systems are designed to create subsurface flow through a permeable medium, keeping the water being treated below the surface, thereby helping to avoid the development of odors and other nuisance problems. Such systems have also been referred to as *root-zone systems*, *rock-reed-filters*, and *vegetated submerged bed systems*. The media used (typically soil, sand, gravel or crushed rock) greatly affect the hydraulics of the system. These systems demonstrate higher rates of contaminant removal than surface flow wetlands. Both systems utilize the roots of plants to provide substrate for the growth of attached bacteria that utilize the nutrients present in the effluents and for the transfer of oxygen. Bacteria do the bulk of the work in these systems, although there is some nitrogen uptake by the plants. The surface flow system most closely approximates a




**Figure 6.10.** A surface flow wetland system in the U.S. (courtesy of USEPA).



**Figure 6.11.** A subsurface flow wetland system in the U.S. (courtesy of USEPA).

natural wetland. Typically, these systems are long, narrow basins, with depths of less than 2 feet, which are planted with aquatic vegetation such as bulrush (*Scirpus* spp.) or cattails (*Typha* spp.) (Fig. 6.12). The shallow subsurface flow systems use a gravel or sand medium, approximately 18 inches deep, which provides a rooting medium for the aquatic plants and through which the wastewater flows.



**Figure 6.12.** A common aquatic species for constructed wetlands (USEPA, 1993).

Organic and inorganic matters are removed from wastewater through several mechanisms. Processes of sedimentation, microbial degradation, precipitation, and plant uptake remove most contaminants. Organic compounds can be broken down for consumption by microorganisms in a wetland system. This biodegradation removes the organic compounds from water as they provide energy for the organisms. Organics can also be degraded when taken up by plants. They can also sorb to surfaces in the wetland, usually to plant debris. Organic compounds containing nitrogen sorb to the surface in the wetland, and organic nitrogen is converted to ammonia. Ammonia can volatilize, be exchanged with other cations in the sediment, or be nitrified if oxygen is present. Nitrate is the form of N taken up by plants, so emergent plants use it during the growing season. Excess nitrate in an anaerobic system is reduced to  $N_2$  and  $N_2O$  gases as a result of denitrification, the main mechanism of nitrate removal.

The design considerations for constructed wetlands systems are varied and site-dependent. Food and agricultural wastewater treatment systems are most concerned with the reduction of suspended solids, organic matter, pathogens, phosphates, ammonia, and organic nitrogen. Some system designs anticipate exactly what kinds of contaminants the wetlands will receive, and at what levels; others face variable and unpredictable wastewater streams.

Food and agricultural wastewater destined for wetlands treatment often

travels through a treatment train, although in some cases wastewater is released directly into a wetland system. The initial step is usually passage through a traditional wastewater treatment plant, where excess ammonia is removed, followed by a sedimentation chamber where any remaining suspended material is removed. Depending on the levels of fecal coliforms and the requirements for effluent contaminant levels, the water may be disinfected with chlorine before release into the constructed wetland system. If the water is to be discharged into a waterway, the minimum contaminant criteria may be different than for a system in which the wetlands are the final destination for the water.

Engineered wetlands for other kinds of wastewater may also consist of a series of treatment steps that have been built according to the expected flow and loading rates. In general, the heavier the load a system receives, the larger the wetlands system will need to be to effectively remove contaminants. The heavier load could be a large volume of water discharged into the system, or volumes with higher concentrations of contaminants.

A series of lined settling and aeration ponds, or lagoons, may be the initial step in treatment, followed by release into the actual wetland. The wetland designs can vary from more traditional systems, with populations of native plants, to aerobic systems that function without aquatic plants and treat waste primarily with added bacteria. An aerobic system may use aquatic plants in a final polishing step.

The principal design parameters for constructed wetland for wastewater treatment include hydraulic detention time, basin depth, basin geometry, BOD<sub>5</sub> loading rate, and hydraulic loading rate (Metcalf and Eddy, Inc., 1991). Table 6.7 provides the typical ranges of design parameters for constructed wetland.

Simplified mathematical expressions for wetland systems are available if we view the systems as aerobic attached-growth biological reactors with plug-flow kinetics for BOD<sub>5</sub> and nitrogen removal. The basic equation for both systems of wetland treatment is the following (Equation 6.16) (Reed et al., 1995):

$$C_e/C_0 = \exp(-k_T t)$$

where:

$C_e$  = effluent pollutant concentration, mg/l

$C_0$  = influent pollutant concentration, mg/l



**Table 6.7.** Typical design parameters for constructed wetlands (*source*: USEPA, 1992).

Design Factor	Surface Water Flow	Subsurface Water Flow
Minimum surface area	23–115 ac/mgd	2.3–46 ac/mgd
Maximum water depth	Relatively shallow	Water level below ground surface
Bed depth	Not applicable	12.30m
Minimum hydraulic residence time	7 days	7 days
Maximum hydraulic loading rate	0.81–4.07 cm/d	2.03–40.5 cm/d
Minimum pretreatment	Primary (secondary optional)	Primary
Range of organic loading as BOD	4.1–8.2 kg/ac·d	0.82–63.6 kg/ac·d

$k_T$  = temperature-dependent first-order reaction rate constant,  $d^{-1}$   
 $t$  = hydraulic residence time, d

The hydraulic residence time in the wetland can be computed as the following (Equation 6.17):

$$T = (L W y n)/Q$$

where:

L = length of the wetland cell, m or ft

W = width of the wetland cell, m or ft

y = depth of water in the wetland cell, m or ft

n = porosity, formed by vegetation, media, roots, and other solids depending on the system, expressed as a percent

Q = the average flow through the wetland ( $Q = (Q_{in} + Q_{out})/2$ ),  $m^3/d$  or  $ft^3/d$

The surface area of the wetland is  $A_s = L W$

One common problem associated with surface flow wetland systems is mosquitoes when certain pockets of the wetland hold still waters. This problem can be controlled by biological means. There are certain fish

species (e.g., mosquito fish, *Gambusia affinis*) that feed upon mosquito's egg, larva, pupa; they can be introduced into the wetland system provided that the DO level in the wetland is above 1 mg/l in order to maintain fish populations.

### **Floating Aquatic Plant Systems**

Aquatic plant systems are engineered and constructed systems that use aquatic plants in the treatment of industrial or domestic wastewater. They are designed to achieve a specific wastewater treatment goal. Aquatic plant systems can be divided into two categories:

- Systems with floating aquatic plants such as water hyacinth, duckweed, and pennywort
- Systems with submerged aquatic plants such as waterweed, water milfoil, and watercress

The use of aquaculture as a means of treating wastewater involves both natural and artificial wetlands and the production of algae and higher plants (submersed and immersed) to remove contaminants such as nitrogen compounds, BOD<sub>5</sub>, hydrocarbons, and heavy metals from the wastewater. Floating aquatic plants such as water hyacinth (*Eichhornia crassipes*) and duckweed (*Lemna* spp.) appear to be some of the most promising aquatic plants for the treatment of wastewater and have received the most attention in this regard. Other plants are also being studied, among them seaweed and alligator weed.

These systems are basically shallow ponds covered with floating plants that detain wastewater at least one week. The main purpose of the plants in these systems is to provide a suitable habitation for bacteria that remove the vast majority of dissolved nutrients. The design features of such systems are summarized in Table 6.8.

These technologies are useful in areas where suitable plants are readily available. In areas where they are not, any introduction of plants species must be undertaken with caution to minimize the possibility of creating nuisance growth conditions. Even introducing them into constructed enclosures should be done carefully, and with the foreknowledge that there is a strong likelihood that they will enter natural water systems (especially because they must be harvested from the treatment systems and disposed of).

**Table 6.8.** Performance of four different wastewater effluent treatment systems using water hyacinth (*source*: USEPA, 1976).

Source	BOD Reduction	COD Reduction	TSS Reduction	Nitrogen Reduction	Phosphorus Reduction
Secondary effluent	35%	n/a	n/a	44%	74%
Secondary effluent	83%	61%	83%	72%	31%
Raw wastewater	97%	n/a	75%	92%	60%
Secondary effluent	60–79%	n/a	71%	47%	11%

- Advantages
  - The cost of plant seeding and wetlands is very low, in most cases negligible.
  - These technologies are traditional, rudimentary, and easy to implement—ideal for rural areas.
  - Wetland systems are easy to build, simple to operate, and require little or no maintenance.
  - Most small-scale wetland treatment systems require relatively small land areas.
  - Wetland technologies reduce nutrient contamination of natural systems.
  - Heavy metals absorbed by the plants in wetland treatment systems are not returned to the water.
  - Water-hyacinth-based and other wetland systems produce plant biomass that can be used as a fertilizer, animal feed supplement, or source of methane.
- Disadvantages
  - In some places, plant seeds may not be readily available.
  - Temperature (climate) is a major limitation because effective treatment is linked to the active growth phase of the immersed (surface and above) vegetation.
  - Herbicides and other materials toxic to the plants can affect their health and lead to a reduced level of treatment.
  - Duckweed is prized as food by waterfowl and fish, and can be seriously depleted by these species.
  - Winds may blow duckweed to the windward shore unless wind-screens or deep trenches are employed.

- Plants die rapidly when the water temperature approaches the freezing point; therefore, greenhouse structures may be necessary in cooler climates.
- Water hyacinth is sensitive to high salinity, which restricts the removal of potassium and phosphorus to the active growth period of the plants.
- Metals such as arsenic, chromium, copper, mercury, lead, nickel, and zinc can accumulate in water hyacinth plants and limit their suitability as fertilizer or feed materials.
- Water hyacinth plants may create small pools of stagnant surface water that can serve as mosquito breeding habitats; this problem can generally be avoided by maintaining mosquitofish or similar fishes in the system.
- The spread of water hyacinth must be closely controlled by barriers because the plant can spread rapidly and clog previously unaffected waterways.
- Water hyacinth treatment may prove impractical for large-scale treatment plants because of the land area required.
- Evapotranspiration in wetland treatment systems can be 2 to 7 times greater than evaporation alone.
- Harvesting the water hyacinth or duckweed plants is essential to maintain high levels of system performance.

The water hyacinth is a perennial, free-floating freshwater aquatic macrophyte with rounded, upright, thick, waxy, and glossy green leaves and spikes of lavender flowers (see Fig. 6.13), native to South America and found naturally in waterways, bayous, and other backwaters in temperate and tropical regions. The water hyacinth is considered one of the worst weeds in the world—aquatic or terrestrial—for its fast growth, which tends to clog the waterways for boat traffic and prevent sunlight and oxygen from getting into the water. It thrives in nitrogen-rich environments and consequently does extremely well in raw and partially treated wastewaters. When it is used for effluent treatment, wastewater is passed through a water-hyacinth-covered basin, where the plants remove nutrients, suspended solids, heavy metals, and other contaminants. Batch treatment and flow-through systems, using single and multiple lagoons, are used. Because of its rapid growth rate and inherent resistance to insect predation and disease, water hyacinth plants must be harvested from these systems. Although many uses of the plant material have been investigated,



Copyright 1996 University of Florida  
Center for Aquatic and Invasive Plants

*Eichhornia crassipes*  
Water hyacinth


**Figure 6.13.** Water hyacinth in a Florida waterway (courtesy of Center for Aquatic and Invasive Plants at University of Florida).

it is generally recommended as a source of methane when anaerobically digested. Its use as a fertilizer or soil conditioner (after composting), or as an animal feed, is often not recommended owing to its propensity to accumulate heavy metals. The plant also has a low organic content (it is primarily water) and, when composted, leaves behind little material with which to enrich the soil.

Duckweed (*Lemna sp.*, *Spirodela sp.*, and *Wolffia sp.*) are small, green freshwater plants with fronds from one to a few millimeters and a short root, usually less than 1 cm in length. Duckweed are the smallest flowering plants. They grow as small colonies of plants floating on the surfaces of quiet bodies of water. Their growth can be extremely rapid, given the proper conditions. These plants are almost all leaf, having essentially no stem tissue, and only one, or a few, very fine roots. Fig. 6.14 shows three species of duckweed. In nature, duckweed serves as food for many species of fish and aquatic birds. In the United States, crayfish are often released in irrigated rice fields in rice-growth areas of the United States to control weeds (often duckweed). Because they are high in proteins and also  $\beta$ -carotene, harvested duckweed can be used as feed for grass carp, sheep, chicken, and tilapia. Duckweed can tolerate and grow under a wide range of conditions, including on water polluted with high concentrations of bacteria and some agricultural wastes. These characteristics have brought duckweed to the attention of environmental engineers and aquaculturists alike.


#### *Water hyacinth systems*

Water hyacinth systems are predominantly floating aquatic plant systems for wastewater treatment. Three types of the systems exist today for BOD<sub>5</sub> and nutrient removals: aerobic nonaerated, aerobic aerated, and facultative anaerobic (Metcalf and Eddy, Inc., 1991). These types of water hyacinth systems reflect the types of stabilization ponds used for wastewater treatment. Not surprisingly, floating aquatic plants, such as water hyacinth, for wastewater treatment thrive in natural or artificial ponds and constructed wetlands. However, use of water hyacinth has been limited, in geographic location, to warm weather regions because of the sensitivity of water hyacinth to freezing conditions (see Fig. 6.15). Water hyacinth systems have been most often used for either removing algae from oxidation pond effluents (by blocking the sunlight to reach the water) or for nutrient removal following secondary treatment.



**Figure 6.14.** Three species of native duckweed in a Florida waterway (courtesy of Center for Aquatic and Invasive Plants at University of Florida).

Design criteria for wastewater treatment using water hyacinth include the depth of the lagoons, which should be sufficient to maximize root growth and the absorption of nutrients and heavy metals; detention time; the flow rate and volume of effluent to be treated; and the desired water quality and potential uses of the treated water. Land requirements for pond construction are approximately  $1 \text{ m}^2/\text{m}^3/\text{day}$  of water to be treated. Phosphorus reductions obtained in such systems range between 10% and 75%, and nitrogen reductions between 40% and 75% of the influent concentration.




**Figure 6.15.** A map of a water hyacinth growing region in the U.S. (USEPA, 1993).

*Duckweed systems*

Duckweed systems have been used successfully to improve the effluent quality from facultative stabilization ponds by reducing algae population, BOD<sub>5</sub>, and nutrients. Duckweed is sensitive to wind and may be blown in drifts to the leeward side of the pond resulting in exposure of a large surface area that is prone to algae blooming. The regions in the U.S. that are suitable for duckweed systems can be seen in Fig. 6.16. Redistribution of the plants to cover the surface requires manual labor. Piles of decomposing plants can result in the production of odors. Drift control, such as floating baffles, can be used to divide the surface area into smaller cells, thus reducing the amount of open surface area to blowing wind.

Similar to water hyacinth systems, design criteria of duckweed systems include hydraulic detention time, water depth, pond geometry, BOD<sub>5</sub> loading, and hydraulic loading rate. Typical treatment results from several U.S. locations involving duckweed wastewater treatment systems for effluents from facultative stabilization ponds are provided in Table 6.9.





**Figure 6.16.** A map of a duckweed growing region in the U.S. (USEPA, 1993).

**Table 6.9.** Performance of duckweed system for treating facultative pond effluents in several U.S. locations (adapted from USEPA, 1988).

Location	BOD <sub>5</sub> , mg/l		TSS, mg/l		Depth, m	Detention Time, Days
	Influent	Effluent	Influent	Effluent		
Biloxi, MS	30	15	155	12	2.4	21
Collins, MS	33	13	36	13	0.4	7
Sleep Eye, MN	420	18	364	34	1.5	70

### Further Reading

- Crites, R.W., Reed, S.C., and Bastian, R. 2000. *Land Treatment Systems for Municipal and Industrial Wastes*. New York: McGraw-Hill Professional.
- Mara, D. 2004. *Domestic Wastewater Treatment in Developing Countries*. London, UK: Earthscan.
- Metcalf and Eddy, Inc. (Tchobanoglous, G. and Burton, F.L.). 1991. *Wastewater Engineering, Treatment, Disposal, and Reuse*, 3rd edition. New York: McGraw-Hill, Inc.
- Reed, S.C., Crites, R.W., and Middlebrooks, E.J. 1995. *Natural Systems for Waste Management and Treatment*, 2nd edition. New York: McGraw-Hill, Inc.

## References

- Gomes de Sousa, J.M. 1987. "Wastewater stabilization lagoon design criteria for Portugal." *Water Science and Technology* 19: 7–16.
- Jayawardane, N.S., Blackwell, J., Cook, F.J., Nicoll, G., and Wallet, D. 1997. *Final report on pollutant removal by the FILTER system during the period November 1994 to November 1996*, Prepared for Griffith City Council. Report No. 97. Canada: CSIRO Division of Land and Water Consultancy.
- Mara, D.D., Alabaster, G.P., Pearson, H.W., and Mills, S.W. 1992. *Waste Stabilisation Ponds—A Design Manual for Eastern Africa*. Leeds, UK: Lagoon Technology International Ltd.
- Mara, D.D. and Pearson, H.W. 1998. *Design Manual for Waste Stabilization Ponds in Mediterranean Countries*. Leeds, UK: Lagoon Technology International Ltd.
- Metcalf and Eddy, Inc. (Tchobanoglous, G. and Burton, F.L). 1991. *Wastewater Engineering, Treatment, Disposal, and Reuse*, 3rd edition. New York: McGraw-Hill, Inc.
- Pano, A. and Middlebrooks, E.J. 1982. "Ammonia nitrogen removal in facultative wastewater stabilization ponds," *Journal of the Water Pollution Control Federation* 54: 344–351.
- Paranychianakis, N.V., Angelakis, A.N., Leverenz, H., and Tchobanoglous, G. 2006. "Treatment of wastewater with slow rate systems: A review of treatment processes and plant functions." *Critical Review in Environmental Science and Technology* 36: 187–259.
- Pescod M.B. and Mara D.D. 1988. "Design, operation and maintenance of wastewater stabilization ponds." In *Treatment and Use of Sewage Effluent for Irrigation*. Pescod, M.B. and Arar, A., eds. Sevenoaks, Kent: Butterworths.
- Racault, Y., Boutin, C., and Sequin, A. 1995. "Waste stabilization ponds in France: A report on fifteen years of experience." *Water Science and Technology* 31: 91–101.
- Reed, S.C. 1984. Nitrogen Removal in Wastewater Ponds. CRREL Report 84-13, Cold Regions Research and Engineering Laboratory, Hanover, NH.
- Reed, S.C., Crites, R.W., and Middlebrooks, E.J. 1995. *Natural Systems for Waste Management and Treatment*, 2nd edition. New York: McGraw-Hill, Inc.
- Townshend, A.R. and Knoll, H. 1987. *Cold Climate Sewage Lagoons*. Report EPS 3/NR/1. Ottawa, Canada: Environmental Canada.
- U.S. Environmental Protection Agency (USEPA). 1976. *Innovative and Alternative Technology Assessment Manual*. EPA 430/9-78-009. Washington, D.C.: USEPA.
- . 1981. *Process Design Manual for Land Treatment of Municipal Wastewater, Supplements on Rapid Infiltration and Overland Flow*. EPA 625/1-81-013a. Cincinnati, OH: Center for Environmental Research Information, USEPA.
- . 1983. *Operational Manual for Stabilization Ponds*. Washington D.C.: USEPA.
- . 1984. *Process Design Manual for Land Treatment of Municipal Wastewater*. EPA 625/1-81-013. Cincinnati, OH: Center for Environmental Research Information, USEPA.
- . 1988. *Design Manual: Constructed Wetlands and Aquatic Plant Systems for Municipal Wastewater Treatment*. EPA 625/1-88-022. Cincinnati, OH: Center for Environmental Research Information, USEPA.
- . 1992. *Wastewater Treatment/Disposal for Small Communities*. EPA-625/R-92-005. Cincinnati, Ohio: Center for Environmental Research Information, USEPA.

- . 1993. *Constructed Wetlands for Wastewater Treatment and Wildlife Habitat*. EPA 832/R-93-005. Cincinnati, Ohio: Center for Environmental Research Information, USEPA.
- WHO. 1987. *Wastewater Stabilization Ponds, Principles of Planning & Practice*. WHO Technical Publication 10. Alexandria, Egypt: Regional Office for the Eastern Mediterranean.

7

## SLUDGE TREATMENT AND MANAGEMENT

---

In essence, wastewater treatment involves a major operation of separation, which concentrates and converts suspended and soluble nutrients into settleable form that can be separated from the bulk of the liquid. The settleable byproducts of wastewater treatment from preliminary treatment, primary treatment, and secondary treatment processes and/or advanced treatment processes are called sludge. The higher degree of treatment of food and agricultural wastewater, the more sludge is created in the processes involved, which has to be appropriately handled unless the sludge is used for land applications or polishing lagoons. The complexity of sludge, due mainly to the characteristics of raw wastewater and treatment processes involved, often means that sludge management is a costly operation in wastewater treatment. The proper utilization and disposal of sludge is one of the most critical issues facing wastewater treatment plants today. Nearly all wastewater treatment plants face the problem of storing and disposing sludges. Landfill costs are skyrocketing; incineration permits are expensive and difficult to obtain; and land application is limited by availability of permitted land.

Additionally, the amount of sludge produced in wastewater treatment is large, though 97% of it is primarily water trapped in the solids; addition of chemicals in physicochemical treatment processes of wastewater treatment increases the amount of sludge produced in the treatment plant. Given the difficulty associated with direct disposal of this enormous watery lump of waste materials to either landfill or waterways, it is not surprising that the main task of sludge treatment is to reduce the quantity of sludge through removal of water. Sludge also needs to be “stabilized” by converting organic solids into harmless inert forms so that the treated sludge can be handled or used as soil conditioners without causing a nuisance or health hazards. Several basic operations of sludge treatment are

commonly used in municipal and industrial wastewater treatment: *thickening, stabilization, conditioning, dewatering, reduction, and disposal.*

### **Sludge Quality and Characteristics**

Sludge is rather complex material, both in the sense of its composition and in the characteristics of its fluid dynamics, which are shaped by its moisture content and interactions between water molecules and other solid particles. In general, when the moisture content of the sludge exceeds 90% by mass or weight, the sludge behaves as a Newtonian fluid, whereas below 90% it behaves as a non-Newtonian fluid in a way similar to those of some polymers (both certain biopolymers such as foods and petroleum-based polymers). The water in the sludge is held as either free water or bound water. It is estimated that in sludge with 95% moisture content, approximately 70% of it is free water and the remaining is bound; the free water molecules are easier to separate from the sludge. Among the 30% bound water, 20% is present as a part of flocs or aggregates, 8% is chemically bound, and 2% is capillary water. As a rule, the intimate bound water, such as capillary water and chemically bound water, requires higher energy than free water. Free water in sludge can be removed by gravity thickening; however, this moisture reduction in sludge may not be enough for sludge handling and further processing. Chemicals and mechanical means are used to “condition” the sludge amendable to dewatering. Mechanical devices break up the structure of the sludge to release trapped water from flocs, whereas chemicals such as coagulants  $\text{FeCl}_3$ , alum, or polyelectrolytes are used to break up and alter the structure and composition of the sludge resulting in improved dewaterability.

The application of basic sludge treatment techniques, whether by stabilization or thickening, depends on the sludge quality and characteristics. Different industries produce different types of sludge that affect sludge treatment options and ultimate disposal. Sludge with gross organic solids such as offal from meat-processing operations; pathogens; and heavy metal and other toxic materials from pharmaceutical, chemical, and metal-processing industries may have few disposal options. This issue needs to be carefully considered by sludge management and treatment personnel and designers during the planning phase of their work. The characteristics of solids and sludges from wastewater treatment processes also vary with the processes or unit operations of wastewater treatment plants. The retained

solids from screens and grit are large-sized inorganic or organic materials, such as vegetable leaves or other food debris, that are large enough to be removed on bar racks. Depending on the nature of the food processing and the season of the year, scum from the flotation process of primary and secondary settling tanks could consist of grease, vegetable, fruit skin, animal fat, and floatable food wastes. Primary sludge from the bottom of the settling tank appears to be gray and slimy and emits offensive odor; sludge from chemical precipitation with metal salts may be dark in color. Sludge from the secondary settling varies with the nature of the biological process employed; sludge from the activated sludge process has a brownish, flocculant appearance and smells far less offensive than that of the primary sludge if the process is well oxygenated. Sludge sloshed down from a trickling filter is brownish, flocculant, and relatively inoffensive. Digested sludges, regardless of whether they are aerobic or anaerobic, are dark brown to black and do not have an offensive odor if treated thoroughly.

Because most wastewater sludges are composed of water, the properties of sludges are dependent on water content; for example, once the percentage of solids and their specific gravity in the sludges are known, the volumes of the sludges can be estimated. The mass balances used to describe the basic unit operations of the sludge treatment can be established based on the solids in the sludges.

The characteristics of stabilized or raw sludge that affect its suitability for land application and beneficial use include organic content, nutrients, pathogens, metals, and toxic organics. The fertilizer value of sludge, if evaluated and found to be suitable, is based mainly on the contents of nitrogen, phosphorus, and potassium. In food and agricultural wastewater treatment, sludge may not have sufficient phosphorus and potassium contents to provide good plant growth. Trace amounts of inorganic compounds in the sludge may spur or stunt growth of plants. Heavy metals in sludge, a perennial problem of municipal wastewater treatment plants, is less severe a problem in most food wastewater treatment processes. Detailed information regarding typical wastewater characteristics, including heavy metals, can be found in Metcalf and Eddy, Inc. (1991).

### **Sludge Thickening (Concentration)**

Further sludge concentration is first accomplished by the use of thickening equipment that will increase the solids content to between 2% and 5%.

Sludge thickening is achieved through one of two means: flotation and settling to the bottom by gravity or centrifugal force. The thickening operation separates water from the sludge as much as possible and is cost-effective because the cost involved in the process is well offset by the savings gained through the reduction of sludge volume, which decreases the capital and operating costs of subsequent sludge processing steps. In addition to reduction in volume that needs to be handled mechanically, sludge thickening is beneficial to the stabilization process (e.g., anaerobic digestion process) because it reduces biomass volume, tank size, and heating requirements.


The flotation process in sludge thickening is in principle similar to the flotation for pretreatment of wastewater. In the flotation process, air is injected into the sludge tank from the bottom under pressure and a large amount of air bubbles disperse into the sludge, attach themselves to the sludge solids and float them to the surface of the thickener. The layer that is formed by the floated sludge particles–air bubbles is removed from the surface by a skimming mechanism for further processing. The flotation method is particularly suitable for activated sludge because of the low specific gravity of the solids, which makes it difficult for gravity-based thickening to remove or separate solids from water. The common parameters for dissolved air flotation process are tabulated in Table 7.1.

Gravity thickeners are essentially circular primary settling tanks with or without mechanical thickening devices. The dilute sludge is fed into the settling tank where solids are allowed to settle over a few days. The thickened sludge is withdrawn from the bottom of the tank and pumped to the digesters or dewatering equipment. Gravity thickening can be achieved in a separate tank or within the clarifier, if it is so designed. Thickening within the clarifier is achieved at the lowest part of the clarifier within a sludge storage zone or hopper. Within the hopper, the sludge is slowly mixed with a motorized rack to enhance the release of water. The mechanical stirrer rack is made of a rotating set of vertical blades or rods, which make the stirrer appear to be a picket fence (this appearance gives rise to the name, *picket fence thickener*) (Fig. 7.1). Often, a secondary tank is used to supplement or replace the thickening zone of the clarifier, especially when extended thickening times are required. These units are typically designed to store the accumulated solids for at least 24 hours. Chemicals are sometimes added to aid the thickening process (e.g., iron and aluminum salts, polyelectrolytes) in a process called *sludge conditioning*. Plain settling tanks can produce solids contents in sludges of up to 8.0% for primary sludges and up to 2.2% for activated sludge. Activated sludge can also be concen-

**Table 7.1.** Air flotation parameters for DAF.

Parameter	Typical Value
Air pressure, psig	40–70
Effluent recycle ratio, % of influent flow	30–150
Detention time, hours	3
Air:solids ratio, lb air/lb solids	0.02
Solid loading, lb/ft <sup>2</sup> -day	10–50
Polymer addition, lb/ton dry solids	10

trated by resettling in primary settling tanks. Gravity thickener design is very similar to that of primary settling basins. The mechanism of the process is also similar. Due to relatively higher solid content in sludge than that in wastewater, a heavy-duty scraper is often called for in sludge gravity thickening in order to move sludge to a hopper from which it is withdrawn and further processed. Gravity sludge thickening is often used for

**Figure 7.1.** A schematic diagram of a picket fence gravity thickener.



**Table 7.2.** Mass loading for designing sludge thickeners.

Type of Sludge	Mass Loading, lb/ft <sup>2</sup> ·day
Primary sludge	22
Primary and trickling filter sludge	15
Primary and waste activated sludge	6–10
Waste activated sludge	4–8

primary sludge thickening, and flotation thickening is frequently employed for activated sludge thickening. A gravity thickener will be designed on the basis of hydraulic surface loading and solids loading. The design principles are to be the same as those for sedimentation tanks. The use of chemical additives (lime or polyelectrolytes) allows higher loading rates. The minimum detention time and the sludge volume divided by sludge removed per day (which represents the time sludge is held in the sludge blanket) is usually less than two days. The design parameters of gravity thickeners for different types of sludges are listed in Table 7.2.

Centrifuges are used both in thickening and dewatering of sludge. Centrifugal thickening involves the settling of particles in watery sludge under the influence of centrifugal forces. Application of centrifuges is limited to the sludge from activated sludge. The advantage of centrifugal thickening is its ability to thicken some difficult sludge. The downside of the centrifuges for sludge thickening are costs associated with power, maintenance, and skilled operators. Other types of sludge thickening equipment are the rotary drum thickener and gravity belt thickener; they are less common in sludge thickening operations.

The main design variables to be considered in selecting a thickening process are

- Solids concentration and volumetric flow rate of the feed system
- Chemical demand and cost if chemicals are employed
- Suspended and dissolved solids concentration and volumetric flow rate of the clarified stream
- Solids concentration and volumetric flow rate of the thickened sludge

Other variables that impact the selection of a thickening process are: subsequent processing steps; operation and maintenance (O/M) cost; and the reliability required for meeting successful operational requirements.

## Sludge Stabilization

Once the sludge is thickened, two options are available for further treatment of the concentrated sludge. It can be dewatered to a solid content of between 30–40% or it can undergo stabilization processes to reduce the organic materials in the sludge before going to the dewatering step. Coarse primary solids and secondary sludge (sometimes called *biosolids*) accumulated in a wastewater treatment process must be treated before disposal to ensure environmentally responsible and lawful outcome. Sludge is often inadvertently contaminated with toxic organic and inorganic compounds and is nutrient-rich.

The objective of sludge stabilization is multifaceted: it reduces pathogens; it eliminates odor; and it reduces organic matters, preventing or inhibiting future decomposition—this is relevant to sludges from many food-processing wastewaters. Sludges are stabilized to prevent anaerobic breakdown naturally during storage of sludges (a process termed as *putrefaction*), producing offensive odor. Stabilization of sludge can be done chemically or biologically, though the latter is more common and effective. Lime stabilization is achieved when a sufficient amount of lime is added to the sludge to alter the value of pH to a high level (>11) that no microorganisms can survive. A similar lime treatment can be applied after sludge dewatering to achieve the same objective of chemical stabilization. Because lime treatment does not destroy or alter any organic matter, in order to prevent future decomposition of organic solids in the sludge, an excessive amount of lime is often required to maintain the high pH value.

Biological stabilization utilizes biological (in many cases, microbiological) agents to reduce organic matters in the sludge, a process often termed *digestion*. There are a variety of digestion techniques, the purpose of which is to reduce, in addition to the amount of organic matter, the number of disease-causing microorganisms present in the solids. The most common treatment options include anaerobic digestion, aerobic digestion, vermistabilization, and composting.

Anaerobic digestion is the most common and widely used sludge stabilization process. Anaerobic digestion also helps reduce global warming. If sludge were landfilled without stabilization, it would still break down naturally (and anaerobically, most likely); however, the biogas (mixture of 55–75% CH<sub>4</sub> and others, mainly CO<sub>2</sub>) would escape directly into the atmosphere, and CH<sub>4</sub> is a worse greenhouse gas than CO<sub>2</sub>. In this way,

anaerobic digestion is considered to be a sustainable technology and biogas is considered to be a renewable fuel if utilized.

### ***Sludge aerobic digestion***

Aerobic digestion is a process of treating the secondary sludge from the biological wastewater treatment process, such as activated sludge and trickling filters; primary sludge is better treated by anaerobic digestion (see Chapter 4). The secondary sludge is primarily insoluble solids such as biomass of microorganisms. The objective of aerobic digestion is to degrade insoluble solids in an aerobic environment. Aerobic digesters are simply CSTRs, not much different from those used in activated sludge. Both bubbling and mechanical aerators achieve mixing oxygen into the liquid in the tank. By optimizing the oxygen supply, the process can be significantly accelerated.

The aerobic digestion is designed to treat excessive amounts of sludge from the activated sludge process and other biological treatment processes. Early attempts to treat this type of sludge with anaerobic digestion met with little success because of its low solids content and the highly aerobic nature of the sludge. High water content (98–99%) of this type of sludge also prevents economical dewatering by mechanical means without substantial thickening. In small communities, the high capital investment requirement associated with thickening and anaerobic digestion equipment also prohibits the use of anaerobic digestion; these communities are likely to choose aerobic digestion instead.

An aerobic digester normally operates by continuously feeding the raw secondary sludge into the tank punctuated with supernatant and sludge withdrawals. The aerobic digester is aerated continuously while the tank is being filled and for the period right after that. Once aeration is stopped, the solids are allowed to settle by gravity. The supernatant is decanted and a portion of the gravity-settled sludge is withdrawn.

### ***Sludge anaerobic digestion***

Anaerobic digestion is a bacterial process that is carried out in the absence of oxygen. The process can either be thermophilic digestion, in which sludge is fermented in tanks at a temperature of 55°C, or mesophilic, at a temperature of around 36°C. Though allowing shorter retention time, thus smaller tanks, thermophilic digestion is more expensive in terms of energy consumption for heating the sludge.

Anaerobic digesters have been around for a long time, and they are commonly used for sewage treatment and for managing animal waste. Increasing environmental pressures on waste disposal has increased the use of digestion as a process for reducing waste volumes and generating useful by-products. It is a fairly simple process that can greatly reduce the amount of organic matter that might otherwise end up in landfills or waste incinerators.

Almost any organic material can be processed in this manner. This includes biodegradable waste materials such as waste paper, grass clippings, leftover food, sewage, and animal waste. Alternatively, anaerobic digesters can be fed with specially grown energy crops to boost biogas production. After sorting or screening to remove inorganic or hazardous materials such as metals and plastics, the material to be processed is often shredded or minced to achieve a better reaction (ultrasound has even been used in the process to aid in the break up of solids). Breaking the material into smaller pieces provides the bacteria with more surface area, allowing them to complete the process quicker. The material is then fed into a sealed digester. In the case of dry materials, water is added.

Anaerobic digestion generates biogas with a high proportion of methane that may be used to both heat the tank and run engines or microturbines for other on-site processes. In large treatment plants, sufficient energy can be generated in this way to produce more electricity than the machines require. The methane generation is a key advantage of the anaerobic process. Its key disadvantage is the long time required for the anaerobic process (up to 30 days) and the high capital cost.

The Goldbar Wastewater Treatment Plant in Edmonton, Alberta, Canada, currently uses the process (Fig. 7.2). Under laboratory conditions, it is possible to directly generate useful amounts of electricity from organic sludge using naturally occurring electrochemically active bacteria. Potentially, this technique could lead to an ecologically positive form of power generation, but in order to be effective such a microbial fuel cell must maximize the contact area between the effluent and the bacteria-coated anode surface, which could severely hamper throughput.

### ***Vermistabilization***

Vermistabilization is a technology that utilizes earthworms to stabilize and dewater wastewater sludge. It provides an all-in-one approach to sludge treatment. The technology works only for sludges with sufficient organic



**Figure 7.2.** An aerial photo of Goldbar Wastewater Treatment Plant in Edmonton, Alberta, Canada.

matters and nutrients to support the earthworm population. The earthworm species *Eisenia foetida* has been shown to be the best worm species due to its growth rate and reproductive responses with temperatures ranging from 20–25°C (68–77°F). Although vermistabilization has been used and studied in composting in many nations, its application in sludge treatment is far from certainty. There are a number of critical issues that prevent vermistabilization from being a common practice; among them is that earthworms can and do accumulate heavy metals and other organic pollutants. Past studies also found that some viruses, bacteria, or parasites could pass through the guts of earthworms and survive. In addition, certain industrial or even municipal sludges contain or do not contain certain substances that adversely affect the growth and reproduction of earthworms. These short-

comings of vermistabilization may not be crucial for many food-processing wastes; however, if food and agricultural wastewaters mix with other industrial or municipal wastewater or food and agricultural wastewaters contain toxic materials or heavy metals, vermistabilization may not be applicable to the sludge originated from these wastewaters.

### ***Composting***

Composting is also an aerobic process for the concurrent stabilization and dewatering of sludges. It involves mixing the wastewater solids with sources of carbon such as sawdust, straw, or wood chips to enable the biological process. In the presence of oxygen, bacteria digest both the sludge and the added carbon source and, in doing so, produce a large amount of heat. There are three basic types of compost systems (Reed et al., 1995): windrow, static pile, and enclosed reactors.

In a windrow system, the mixture of sludge and wood chips to be composted is placed in long rows, which are periodically turned and mixed to expose new surfaces to oxygen in the air.

Static pile systems consist of a porous base made from wood chips or compost in which the air is blown or drawn through either perforated or nonperforated pipe. The wood chips and sludge are piled on top of the porous base and screened compost covers the sludge–wood chip mixture.

Enclosed reactors look more or less like miniature compost containers used by home gardeners. Inside the reactors, there could be static pile or windrow-type layouts; the enclosure is usually for odor control.

Table 7.3 provides a general guideline for designing compost systems for sludge treatment. Monitoring process parameters is essential in any composting operation—it ensures efficient operation and quality of final products. Critical parameters such as moisture, oxygen concentration, heavy metals and organics, pathogens, pH, and temperature need to be watched closely and continuously for successful operations and compliance of laws and regulations.

### **Reed Beds**

Reed beds constructed in wetlands provide long-term storage and volume reduction of sludges (sludge stabilization and dewatering) to mitigate environmental concerns. Widely used throughout Europe, Asia, and Aus-

**Table 7.3.** Design considerations for aerobic sludge composting (adapted from Metcalf and Eddy, Inc., 1991).

Item	Design Considerations
Sludge sources	Untreated sludge or digested sludge
Amendments and bulking agents	Wood chips, sawdust, recycled compost, and straw
Carbon:nitrogen ratio	Ranging from 25:1 to 35:1
Volatile solids	>50%
Air requirement	>50% remaining in all parts of compost
Moisture content	<60% for static pile type; <65% for windrow
pH	6–9
Temperature	Initially 50–55°C and later 55–66°C
Mixing and turning	Periodically, depending on type of compost operations
Heavy metals and trace organics	Do not exceed the limits for compost disposal
Site constraints	Considerations: available area (minimum area for accommodating 30 days of composting production), access, proximity to treatment plant, climatic conditions, and availability of buffer zone

tralia, and in more than 50 locations in the United States, reed-bed technology features low construction costs and minimal day-to-day operation and maintenance costs due to infrequent cleaning of the beds (usually every several years). The reed-bed system reduces water content, minimizes sludges, and provides sufficient storage time to stabilize sludges prior to disposal.

Reed beds use common reed plants (*Phragmites communis*) to dewater solids in a confined area (Fig. 7.3). The phragmite was first used years ago in Europe for handling iron oxide sludges. The beds can be any shape to accommodate existing land conditions and areas. Specially designed ponds with under-drains covered by a sand and gravel mixture are constructed and filled with reed plants. Modified sludge drying beds also work well and are an ideal retrofit. They already have sidewalls, layers of sand and gravel, an under-drain system that collects and carries away filtrate, and an impervious membrane liner. Solids are pumped into the reed



**Figure 7.3.** A photo of a reed bed sludge treatment before planting vegetation.

beds. Dewatering occurs through evaporation, plant transpiration, and decantation. Decanted water seeps through the bottom of the bed and through the layers of sand and gravel into the under-drains, traveling back to the wastewater treatment plant for secondary treatment. During dewatering the solids change from liquid to “cake.” Six inches of solids and water will compress to a half-inch of solid cake. The cake is left in the bed and the process is repeated (Fig. 7.4).

The reeds are planted one foot on center throughout the bed. Aerobically stabilized sludge is typically applied uniformly through a grid-perforated tile. Sludges must be well stabilized, 60% or less volatilized to be used successfully with reed beds. Optimum application rates range between 2% and 4% solids. While plants are young they should be watered with plant effluent. After they are established, they can be fed heavier sludge mixtures. Loading rates (gallons per square foot per year) depend on temperature for well-established beds.

The phragmite is one of the most widespread flowering plants in the world. It is a tough adaptable plant, which can grow in polluted waters and find sustenance in sludge. This reed has a voracious appetite for water. The plant is tolerant to low oxygen levels and to waterlogged conditions. The reeds hold themselves in the soil through roots and rhizomes, an in-





**Figure 7.4.** A photo of a reed bed sludge treatment after planting vegetation.

tricate network of underground stems. New plants in turn will sprout from these stems. These rapidly growing roots provide air passages through the sludge that in turn provide a host area for many biological communities to develop and continue to mineralize the sludge.

Reed beds perform three basic functions: (1) dewater the sludge, (2) transform it into mineral and humus like components, and (3) store sludge for a number of years. Dewatering is accomplished through evaporation (as in a normal sludge drying bed operation), transpiration through the plants root stem and leaf structure, and filtration through the bed's sand and gravel layers and the plant's root system. The leachate is channeled back to the treatment plant through the under-drain.

The plants should be harvested annually to prevent drainage backup. The vegetation can be composted or burned.

Researchers recommend the installation of multiple beds to handle emergencies and downtime due to cleaning. Beds may be out of service for up to a year while rootstalks grow new tops after cleaning. The top level of sand and material removed during clean-out is similar in pathogen

content to composted sludge and can be used in the same way. Many beds have gone 8 to 10 years without having to be cleaned out.

Sludge reed beds are a significant improvement over existing drying beds. Sludge can be dewatered and converted into biomass and low-grade compost without chemical addition or energy. They have lengthy turnover time and are capable of reducing sludge volumes by up to 95% over time.

### **Conditioning of Sludge**

The aim of sludge conditioning is improving dewatering characteristics of sludge. Dewaterabilities of sludges are varied; some, such as activated sludge, are difficult to dewater. The difficulty in activated sludge dewatering is mainly attributed to the presence of extracellular polymer (ECP). ECP is present in varying quantities in sewage sludge, occurring as either a highly hydrated capsule surrounding the bacterial cell wall or loose in solution as slime polymers. ECP is thought to aid the survival of the bacterial cell by preventing desiccation and acting as an ion exchange resin, controlling the ionic movement from solution into the cell. Polysaccharide, protein, and DNA, which entrap the water and cause high viscosity, are the main components of ECP, but humic-like substances, lipids, and heteropolymers such as glycoproteins are also present. Wang et al. (2004) noted that surface properties, like the concentration of ECP, were related to zeta-potential measurements with particle electrophoresis as well as to water contact angle measurements on filter cakes prior to and after the oxidative conditioning: The sludges with high zeta-potentials and low contact angles were sludges with high amounts of ECP. These sludges with a high surface charge density as well as a high hydrophilicity (low contact angle) prevent efficient flocculation. The experimental results of Neyens et al. (2004) indicate that peroxidation of sludge enhances the flocculation and dewaterability. The responsible mechanism is not fully understood, but the oxidative conditioning might be based on partial oxidation and rearrangement of the surface components (extracellular polymers) of the sludge flocs. The effects of temperature, hydrogen peroxide concentration, pH, presence of  $\text{Fe}^{2+}$ , and reaction time on the dewaterability of the sludges were tested by Neyens et al. (2002, 2004). They found that peroxidation gave the best results with respect to improving sludge dewaterability and product quality of the residual filter cake among all advanced sludge treatment processes (Neyens et al. 2002).

The general approaches to conditioning sludge are employment of chemicals (similar to coagulants used in primary sedimentation) and heat treatment to improve the dewaterability of sludge. Other less-common methods—such as freezing, irradiation, solvent extraction, as mentioned previously, and advanced oxidation—are still in the laboratory stages.

Chemical conditioning can reduce 90–99% moisture content of an incoming sludge to 65–85%. As described previously, chemicals such as coagulants (e.g., alum, lime, iron salts, and polymers) disrupt the structure and composition of the sludge by forming aggregates that are more compact in structure and hold less water. The addition of chemicals may contribute to an increase in solid content of the sludge as much as 30%. The dosage and types of chemicals depend on several factors; properties of the sludge are by far the most crucial factor in determining which and how much chemical needs to be added to the sludge. The source of the sludge, solid concentration, age of the sludge, pH, and alkalinity are important properties that affect the selection and dosage of chemicals added to the sludge prior to mechanical dewatering operations. It is generally observed that the difficult-to-dewater sludge requires a larger quantity of chemicals; the more biologically processed the sludge is, the larger the dose of chemicals required. In this vein, aerobically digested sludge that is treated with the most efficient biological process requires the highest dose of chemical conditioners and untreated raw primary sludge needs the least.

Heat treatment can serve both as a stabilization process and as a conditioning process. Heat can facilitate aggregation of particles, break down the gel structure of the sludge, and reduce water affinity to the sludge particles. Heat can also sterilize or inhibit pathogens, bacteria, and enzymes; and heat-treated sludge, if done properly and followed with vacuum filtration or belt presses, seldom causes putrefaction. The other bright spot for the heat-processed sludge is that it has a heating value of 12,000 to 13,000 Btu/lb (28 to 30 kJ/g) of volatile solids (volatile solids are part of the dried sludge that undergoes complete combustion in a muffle furnace at 550°C); this can be valuable in sludge incineration. The disadvantages of heat treatment of sludge are also noticeable: the costs, both capital and operating, are high due to mechanical complexity; operations of heat treatment require skilled operators and elaborate operating procedures; significant odor and gases, which need to be managed, emit from the process; and scale formation in heat exchangers are extensive and difficult to prevent or clean up.


## Dewatering

Dewatering of sludge is a physical unit operation to reduce the moisture of the sludge in preparation for subsequent further treatment processes. As the agricultural use of the sludge and landfilling are increasingly restricted in the United States and elsewhere, drying and incineration are widely implemented. As a result, the costs related to the treatment of sludge have considerably risen and commonly represent 35–50% of the total operating costs of the wastewater treatment. Reducing the amount of sludge produced and improving the dewaterability are of paramount importance. This objective of sludge reduction has stressed the importance of using an extended aeration biology, using a biological phosphorus removal (instead of chemical precipitation), using sludge digesters, etc. A further reduction and an improvement of the dewaterability require advanced sludge treatment technologies, such as the Fenton reaction and peroxide oxidation (Neyens et al., 2002).

A number of techniques of dewatering are used for removing moisture; some rely on natural forces such as evaporation and percolation, and the others are assisted mechanically and thermally during dewatering. The objective of dewatering is moisture content of 60–80%, depending on the disposal method. Dewatering of the sludge is currently achieved through the use of mechanical dewatering and thermal dehydration devices. The most widely used mechanical dewatering device is the filter press. Other technologies employed include vacuum filters, centrifuges, and belt presses. Mechanical dewatering will produce a sludge with an approximately 10–60% solids content (e.g., by using common centrifuges or belt presses, only 20–25% dry solids can be obtained). Sludge dryers are used to further remove moisture from the sludge and are capable of producing a material with 90% solids content. Because all dewatering devices are dependent upon proper sludge conditioning, a carefully designed chemical feed system should be included as part of the dewatering facility.

### *Belt press filtration*

Belt filter presses employ single or double moving belts to continuously dewater sludges through one or more stages of dewatering. All belt press filtration processes include three basic operational stages: chemical conditioning of the feed sludge; gravity drainage to a nonfluid consistency; shear and compression dewatering of the drained sludge. When dewater-




**Figure 7.5.** A schematic diagram of a belt filter for sludge dewatering. (Courtesy of Falke Bruinsma at <http://photos.innersource.com>)

ing a 50:50 mixture of anaerobically digested primary and waste activated sludge, a belt filter press will typically produce a cake solids concentration in the 18–23% range.

Fig. 7.5 depicts a simple belt press and shows the location of the three stages. The dewatering process is made effective by the use of two endless belts of synthetic fiber. The belts pass around a system of rollers at constant speed and perform the function of conveying, draining and compressing. Many belt presses also use an initial belt for gravity drainage in addition to the two belts in the pressure zone.

### ***Centrifugation***

Centrifugal dewatering of sludge is a process that uses the force developed by fast rotation of a cylindrical drum or bowl to separate the sludge solids from the liquid. In the basic process, when sludge slurry is introduced to the centrifuge, it is forced against the bowl's interior walls, forming a pool



**Figure 7.6.** A schematic illustration of a centrifuge for dewatering of sludge.

of liquid. Density differences cause the sludge solids and the liquid to separate into two distinct layers. The sludge solids cake and the liquid *centrate* are then separately discharged from the unit. The two types of centrifuges used for municipal sludge dewatering, basket and solid bowl, both operate on these basic principles. They are differentiated by the method of sludge feed, magnitude of applied centrifugal force, method of solids and liquid discharge, cost, and performance.

#### *Basket centrifuge*

The imperforate basket centrifuge is a semicontinuous feeding and solids discharging unit that rotates about a vertical axis. A schematic diagram of a basket centrifuge in the sludge feed and sludge plowing cycles is shown in Fig. 7.6. Sludge is fed into the bottom of the basket and sludge solids form a cake on the bowl walls as the unit rotates. The liquid (centrate) is displaced over a baffle or weir at the top of the unit. Sludge feed is either continued for a preset time or until the suspended solids in the centrate reach a preset concentration. The ability to be used either for thickening or dewatering is an advantage of the basket centrifuge. A basket centrifuge will typically dewater a 50:50 blend of anaerobically digested primary and waste activated sludge to 10–15% solids.

#### *Bowl centrifuge*

A solid bowl centrifuge is a type of centrifuge with a rotating bowl into which sludge is fed at a constant flow rate; chemicals or polymers can be added to aid the dewatering. The centrate obtained from the separation usually contains fine solids and is returned to the wastewater treatment

systems. The cake is 70–80% of moisture and is discharged from the bowl by a screw feeder into a hopper or a convey belt. Sludge cakes with above 25% solids are desirable for disposal by incineration or landfill.

### ***Filter press***

The filter press is an intermittent dewatering process. A filter comprises a set of vertical, juxtaposed recessed plates, pressed against each other by hydraulic jacks at one end of the set. The pressure applied to the joint face of each filtering plate must withstand the chamber internal pressure developed by the sludge pumping system.

This vertical plate layout forms watertight filtration chambers, allowing easy mechanization for the discharge of cakes. Filter cloths tightly meshed are applied to the two grooved surfaces in these plates. Orifices feed the sludge to be filtered under pressure in the filtration chamber. They are usually placed in the center of the plates, allowing a proper distribution of flow, right pressure, and better drainage of sludge within the chamber. Solids sludge gradually accumulates in the filtration chamber until the final compacted cake is formed. The filtrate is collected at the back of the filtration support and carried away by internal ducts (Fig. 7.7).

The filter press has a number of advantages over other filtration equipment such as vacuum filters and centrifuges. Filter presses can operate well at variable or low-feed solids conditions. They can also produce a relatively dry cake because of the high-pressure differential they can exert on the sludge. A typical filter press operating at 100 psig will produce sludge with a solids content of 25–60% solids, depending on the chemicals used for precipitation. As a comparison, the basket centrifuge produces sludge with a solids content of 10–25%, and the vacuum filter produces sludge with 15–40% solids.

The disadvantages of the filter press include its batch operating cycle, the labor associated with removing the cakes from the press, and the downtime associated with finding and replacing worn or damaged filter cloths. The original filter press design consisted of alternating plates and frames, and these types of units were referred to as the *plate-and-frame filter press*. The new and improved design is the recessed plate filter press. The plates (usually constructed of polypropylene) are recessed on each side to form cavities, and they are covered with a filter cloth. The two types of presses work in basically the same manner. At the start of a cycle, a hydraulic pump clamps the plates tightly together and a feed pump



**Figure 7.7.** A picture of a filter press for sludge dewatering.

forces dilute sludge slurry into the cavities of the plates. The liquid (filtrate) escapes through the filter cloth and grooves that are molded into the plates, and is transported by the pressure of the feed pump to a discharge port. The solids are retained by the cloth and remain in the cavities. This process continues until the cavities are packed with sludge solids. The hydraulic pressure is then released and the plates are separated. The sludge solid or cake is loosened from the cavities and falls into a hopper or drum.

Modern recessed plate filter presses may be equipped with the following design enhancements:

- Lightweight polypropylene plates that exhibit good chemical resistance and provide a long service life.
- Gasketed plates that reduce leakage during the filtration cycle. These replace nongasketed types where the filter cloth extends beyond the plate to form the seal between plates.
- An air blow-down manifold that is employed at the end of the filtration cycle to drain remaining liquid in the system, thereby improving sludge dryness and aiding in the release of the cake.
- Microprocessor control, which permits unattended operation throughout the filtration cycle. Capable of automatically adjusting the feed pressure and deactivating the pump whenever hydraulic pressure falls below preset limits.
- Manual, semiautomatic or automatic plate shifters that are used to separate the plates prior to releasing the sludge cake.





**Figure 7.8.** A freezing-thawing sludge bed. (Courtesy of Falke Bruinsma at <http://photos.innersource.com>)

### ***Sludge freezing***

Freezing and then thawing sludge will transform the structure of the sludge amenable to draining of interstitial water trapped in the sludge. The expansions of sludge structures due to formation of ice crystals during freezing apparently also help loosen the binding of water molecules to the sludge solids. Freezing and thawing processes of waste-activated sludge have been investigated extensively (e.g., Reed et al., 1986). It is found that surface water can be expelled by freezing. When water in sludge begins to freeze, it creates a thin upper layer that sends needles into the sludge. As ice growth continues, the smaller the solid particles are, the faster the advancing ice front moves them. Some large particles (perhaps greater than 100  $\mu\text{m}$ ) cannot be pushed in front of the ice and are trapped within the frozen mass without being moved. In time, the ice crystals dehydrate captured sludge flocs, pushing the particles into more compact aggregates.

The freezing/thawing process can effectively take place in a “freezing bed” as proposed by Martel (1989) (see Fig.7.8). The freezing bed oper-



**Figure 7.9.** A sample of freezing-and-thawing treated sludge from anaerobic digester. (Courtesy of Falke Bruinsma at <http://photos.innersource.com>)

ates somewhat like a sludge drying bed, except that the sludge is applied in thin layers during the winter months and allowed to freeze. During warmer weather, the sludge thaws and the water drains out, leaving a dry residue (Fig. 7.9).

The freezing/thawing treatment of activated sludge is not economically feasible unless natural freezing and thawing are used. In the United States, the freezing and thawing method for dewatering of sludge is not suitable for regions south of the Mason-Dixon line, California, most of Arizona and New Mexico, and parts of the northwest coastal states. A simple equation that can be used for preliminary assessment of feasibility of the freezing and thawing method for sludge dewatering correlates the total depth of sludge that could be frozen if applied in 8 cm increments with the maximum depth of frost penetration (Equation 7.1) (Reed et al., 1995):

$$\begin{aligned}\Sigma Y &= 1.76 (F_p) - 101 && \text{(metric units)} \\ &= 1.76 (F_p) - 40 && \text{(imperial units)}\end{aligned}$$

where:

$\Sigma Y$  = the total depth of sludge that can be frozen in 8 cm (or 3 in) layers during the warmest design year, cm or in

$F_p$  = the maximum depth of frost penetration, cm or in

### ***Sludge drying***


Sludge drying is achieved through vaporization of water in sludge. There are two categories of drying sludge. One is the drying bed type; the other is a mechanical device type that requires auxiliary heat to increase vaporization of moisture in sludge. Drying by natural means is possible only during a long period of time. Faster and smaller, but also more cost-intensive, are mechanical processes. Sludge drying beds are used for small communities for dewatering sludge from wastewater treatment. The beds are basically a constructed storage area for holding sludge; dewatering (drying) is achieved by draining the sludge by gravity and vaporization of moisture in the sludge exposed to the atmosphere. Some designs employ air to create a vacuum under the draining system of the bed. After drying, the sludge is destined for landfill. The principal advantage of drying beds is low cost and low maintenance. The disadvantage is the cost of removing sludge and replacing draining bedding (sand); so the drying bed type of dewatering operations is suitable for large communities with populations over 20,000.

Mechanical processes of heating sludge include the flash dryer (Fig. 7.10), spray dryer (Fig. 7.11), rotary dryer (Fig. 7.12), and multiple-hearth incinerator (discussed below in the section "Incineration"), and multiple-effect evaporator (Fig. 7.13).

Flash dryers involve pulverizing sludge in a cage mill or in the presence of hot gases. The process is based on exposing fine sludge particles to turbulent hot gases long enough to attain at least 90% solids content. The dried sludge may be used as soil conditioner or it may be incinerated.

Spray dryers typically use centrifugal force to atomize liquid sludge into a spray that is directed into a drying chamber where it contacts with hot air that rapidly dries the sludge mist into powders. The flow directions of hot air and the sludge streams are either concurrent or counter-current.

Rotary dryers function as horizontal cylindrical kilns. The drum rotates and may have plows or louvers that mechanically mix the sludge as the




**Figure 7.10.** A schematic diagram of a flash dryer for sludge dewatering.

drum turns. There are many different rotary kiln designs, utilizing either direct heating or indirect heating systems. Direct heating designs maintain contact between the sewage sludge and the hot gases. Indirect heating separates the two with steel shells.


Multieffect evaporators in sludge drying operations use the proprietary multieffect Carver-Greenfield process in which dewatered sludge is mixed with oil. This mixture, which can be pumped easily, is pumped through a series of evaporators (multieffect evaporation system) that selectively remove the water in the sludge, which has a lower boiling point than the oil. The oil maintains the mixture in a liquid state, even when virtually all the water has been removed. The product of this process, an oil and dry sludge mixture, is put through a centrifuge to separate the dry sewage sludge solids from the oil. The recovered oil can be reused in the process.

### **Land Applications and Surface Disposal**


Land application of sludge is defined as the beneficial use of the sludge at agronomic rates; all other land displacements are considered as surface



**Figure 7.11.** A schematic diagram of a spray dryer for sludge dewatering.



**Figure 7.12.** A schematic diagram of a rotary dryer for sludge dewatering.



**Figure 7.13.** A schematic diagram of a multieffect evaporator for sludge dewatering.

disposal of sludge. The detailed regulation regarding land application and surface disposal of sludge from wastewater treatment plants are discussed in 1993 EPA 40 CFR Part 503. It stipulates that landfilling of sludge is considered as “beneficial use” only when such disposal includes methane gas recovery for fuel. However, methane operations are relatively rare. Alternative beneficial uses are receiving greater attention because of a decline in available landfill space and an interest in conserving nutrients, and utilizing soil conditioning properties and other recoverable qualities

of sludge. Thus, land application for soil conditioning and fertilization is the primary beneficial use of sludge from food and agricultural wastewater treatment plants.

Sludge may be disposed of by liquid injection to land or by disposal in a landfill. There are concerns about sludge incineration because of air pollutants in the emissions, along with the high cost of supplemental fuel, making this a less attractive and less commonly constructed means of sludge treatment and disposal. There is no process that completely eliminates the requirements for disposal of sludges (there is ash from incineration that needs to be properly disposed of).


Similar to land application of wastewater, land application of sludge is also affected greatly by characteristics of wastes, including organic contents (volatile solids), nutrients, pathogens, metals, and toxic organics, and soil characteristics. Metcalf and Eddy, Inc. (1991) and Reed et al. (1995) provide the concise procedures regarding site selection, process design, and land application and surface disposal methods. The reader is encouraged to explore all aspects of sludge management issues in these references.

## **Incineration**

Incineration, or complete combustion, is a rapid exothermic oxidation of combustible elements in fuels. The use of incineration for sludge disposal is the result of tightening limits for land disposal and/or sea disposal of sludge by regulatory agencies. The use of combustion to reduce wastewater sludges into inert ash is an effective but costly process unless there is a cheap fuel resource available. The ash from incineration operations is usually disposed in a landfill. The fuel requirement for incinerating sludges depends on two parameters: the amount of water in the sludges and fuel value of the contents of the sludges. For example, FOG scum from preliminary treatment or primary treatment processes of food and agricultural wastewater can be readily burned in the incinerator, which reduces the fuel requirement and lowers the cost of the operation. Raw primary and undigested secondary sludges will have fuel values ranging from about 14,000 to 28,000 kJ/kg (6,000 to 12,000 Btu/lb) dry solids (Metcalf and Eddy, Inc., 1991). If sludges are managed to dewater to about 25% solids, incineration will be self-sustaining.

Oxygen requirements for incineration of sludge may be determined

from knowledge of its constituents, assuming C and H are oxidized to the ultimate end product (Equation 7.2):



The theoretical quantity of air will be 4.23 times the calculated quantity from Equation 7.2 ( $O_2$  is about 23% of air by weight). Excessive amount of air (about 50% of the theoretical quantity) will be used to ensure the complete combustion of the sludge.

The heat requirement for incineration operations is the following (Equation 7.3):

$$Q = \sum C_p m (T_2 - T_1) + m_w \lambda$$

where:

$C_p$  = specific heat for each constituent of substances in ash and in flue gases

$m$  = mass of each substance

$T_1, T_2$  = initial and final temperatures

$m_w$  = mass of water in sludge

$\lambda$  = latent heat of evaporation of water per unit mass

It is obvious that any reduction in moisture in sludge will lower the fuel requirements; thus, moisture content determines whether additional fuel will be required in incinerating a particular sludge.

There are two popular incinerators used for sludge incineration: multiple-hearth type and fluidized bed type. The first multiple-hearth incinerator for sludge incineration was built in 1935 in Dearborn, Michigan. From that time on through the late 1960s, the multiple-hearth type was the choice for sludge incineration. At present, there are still some 150–175 multiple-hearth incinerators in operation in North America.

A multiple-hearth incinerator is a vertical, cylindrical, refractory-lined, steel-shell furnace. It consists of 6 to 12 horizontal hearths and a rotating center shaft with rabble arms. Cooling air is introduced into the shaft, which extends above the hearths. The sludge enters the top hearth and flows downward while combustion air flows from the bottom to the top. The rabble arms are shaped to sweep the sludge in a spiral motion, alter-




nating in direction from the outside in, to the inside out, between hearths. The effect of the rabble motion is to break up solid material to allow better surface contact with heat and oxygen. Depending on the shaft speed and on the number of hearths, the retention time of the sludge in the incinerator ranges from 0.5–3 hr.

Ambient air is first pumped through the central shaft and its associated rabble arms. A large portion of this air is then taken from the top of the shaft and recirculated back to the lowermost hearth as preheated combustion air and mixed with additional ambient combustion air. The temperature of the mixed air is limited because the lower hearths serve as an ash-cooling zone. Sludge burns in the center hearths, where it is the hottest, and releases heat and combustion gas. The combustion gas flows upward through the drop holes in the hearths, countercurrent to the flow of the sludge, before being exhausted from the top hearth.

The flue gases rising through the furnace are cooled in the upper hearths by the evaporation of sludge moisture, which degrades or stops combustion on the top hearths. In this drying zone, some volatiles are released from the sludge and exit the furnace without exposure to the full combustion temperatures. The feed sludge must contain more than 15% solids due to limitation of evaporating capacity of the incinerator. Average loading rates range from 5 to 15 lb/ft<sup>2</sup>·h (25 to 75 kg/m<sup>2</sup>·h). Auxiliary fuel is often required when the feed sludge has a solids content ranging from 15–30% (Metcalf and Eddy, Inc., 1991). Additional ash-handling, such as wet or dry scrubbing, is needed to minimize the air pollution.

In the 1970s, fluid bed incinerators became the preferred choice for incinerating sludge mainly due to tighter emission regulations and to increasing cost of auxiliary fuel. The advantages of the fluid bed are lower emission, reduced auxiliary fuel use, and reduced operating and maintenance costs. The fluidized bed incinerator is a vertical, cylindrically shaped, refractory-lined steel shell that contains a sand bed called the *combustion zone* and the refractory arch containing alloy tuyeres or nozzles that allow hot air to be distributed homogeneously throughout the bed in order to produce and sustain combustion (Fig. 7.14). The air from the refractory distributor causes the bed of sand to fluidize to a height of 5 ft. Sludge and auxiliary fuel, if required, are fed into fluidizing sand bed through lateral feed ports. The intensive mixing of the solid and combustion air in the fluidized state yields a high heat transfer rate resulting in rapid combustion of the sludge fed into the furnace. In the lower section, the area below the refractory arch distributor of the furnace is called the



**Figure 7.14.** A schematic diagram of an incinerator for sludge dewatering.

*windbox*; it acts as a plenum in which the air is received. The refractory arch distributor and the refractory-lined windbox are designed to allow combustion air to be preheated up to 1,250°F. The section above the bed is called the *freeboard* or *disengagement* zone. It is typically 15 ft high and usually is expanded laterally along its height to maximize residence time and to reduce sand usage. The freeboard typically provides 6 to 7 seconds of gas residence-time, which completes the combustion of any volatile hydrocarbons escaping from the bed. The freeboard thus acts as an integral afterburner and normally operates at 50 to 100°F higher than the bed, ensuring complete combustion of the volatiles. Combustion exhaust and ash

leave the bed and are transported through the freeboard area to the gas outlet through the top of the furnace. Because of the fine size of the ash, there is no ash exit from the bottom of the incinerator. The entrained ash is scrubbed with a venturi scrubber as part of an air pollution control system.

### Further Reading

- Metcalf and Eddy, Inc. 1991. *Wastewater Engineering, Treatment, Disposal, and Reuse*, 3rd edition. New York: McGraw-Hill, Inc.
- Turovskiy, I.S. and Mathai, P.K. 2006. *Wastewater Sludge Processing*, 354 pp. New York: John Wiley & Sons.

### References

- Davison, L., Headley, T., and Pratt, K. 2005. "Aspects of design, structure, performance and operation of reed beds—Eight years experience in north eastern New South Wales, Australia." *Water Science and Technology* 51: 129–138.
- Martel, J.C. 1989. "Development and design of sludge freezing beds." *Journal of Environmental Engineering* 115: 799–808.
- . 2001. Design of Freezing Bed for Sludge Dewatering at McMurdo, Alaska. ERDC/CRREL TR-01-3. Hanover, NH: U.S. Army Corps of Engineers, Engineering Research and Development Center.
- Metcalf and Eddy, Inc. 1991. *Wastewater Engineering, Treatment, Disposal, and Reuse*, 3rd edition. New York: McGraw-Hill, Inc.
- Neyens, E., Baeyens, J., De heyder, B., and Weemaes, M. 2004. "The potential of advanced treatment methods for sewage sludge." *Management of Environmental Quality: An International Journal* 15: 9–16.
- Neyens, E., Baeyens, J., Weemaes, M., and De heyder, B. 2002. "Advanced biosolids treatment using H<sub>2</sub>O<sub>2</sub>-oxidation." *Environmental Engineering Science* 19: 27–35.
- Reed, S., Bouzoun, J., and Medding, W. 1986. "A rational method for sludge dewatering via freezing." *Journal of Water Pollution Control Federation* 58: 911–916.
- Reed, S.C., Crites, R.W., and Middlebrooks, E.J. 1995. *Natural Systems for Waste Management and Treatment*, 2nd edition. New York: McGraw-Hill, Inc.
- USEPA. 1987. *Design Manual: Dewatering Municipal Wastewater Sludge*. EPA 625/1-87-014. Cincinnati, OH: Office of Research and Development, USEPA.
- Wang, H., Li, X., and Zhao, C. 2004. "Surface properties of activated sludge and their effects on settleability and dewaterability." *Journal of Tsinghua University (Science and Technology)*: 44:766–769.

8

INNOVATIVE TECHNOLOGIES FOR  
VALUE-ADDED SUBSTANCE/ENERGY  
RECOVERY FROM WASTEWATERS

---

**Introduction**

In essence, wastes are the products whose values have yet to be determined. However, this is a not widely shared view; throughout the developed world, food and agricultural wastewater is the scourge that needs to be kept out of sight and hopefully destroyed. Most wastewater management approaches are methods of concentration, conversion, and/or relocation of wastes, such as physicochemical and biological treatment, incineration, or land/sea disposal. This is in stark contrast to the early days of human development when agricultural and food wastewaters were fully utilized as fertilizers and animal feeds. Even today in some much less-developed nations, there are practices of utilizing food and agricultural wastewater for a variety of applications. It seems, as human beings get more affluent, the attitudes toward food wastewaters get more negative.

Management and treatment of agricultural and food wastewaters incur costs, and this is more than an annoying nuisance for food processors and other agribusiness sectors: As the environmental regulations and laws tighten, the costs will undoubtedly go up. This is certainly not good news for food and agriculture industries whose profit margins are thin and subject to volatile international agriculture commodity price swings. The best remedy for reducing the costs of treating and disposing food and agricultural wastewater is to reduce the amount of water used in the food and agricultural processing operations and to recycle spent water for reuse. Water consumption in the food industry is enormous, and any reduction of its use will ultimately ease the shortage in many parts of the world and environmental degradation. Still, certain use of water in food and agricultural processing is inevitable because the hygienic requirement is that any-

**Table 8.1.** Typical characteristics, estimated volume, and estimated organic loading of wastewater generated by the food processing industry in Georgia (Magbunua, 2000).

Industry Sector	Estimated Wastewater Volume, Mgal/yr	Typical Characteristics	Estimated Organic Loading, Tons/yr BOD
Meat and poultry products	10,730	1,800 mg/l BOD 1,600 mg/l TSS 1,600 mg/l FOG	80,600
Dairy products	500	2,300 g/l BOD 1,500 mg/l TSS 700 mg/l FOG	14,900
Canned, frozen, and pre-served fruits and vegetables	2,080	500 mg/l BOD 100 mg/l TSS	4,300
Grain and grain mill products	130	700 mg/l BOD 1,000 mg/l TSS	300
Bakery products	530	2,000 mg/l BOD	4,400
Sugar and confectionery products	140	500 mg/l BOD	300
Fats and oils	350	4,100 mg/l BOD 500 mg/l FOG	7,000
Beverages	3,660	8,500 mg/l BOD	91,000
Miscellaneous food Preparations and kindred products	700	6,000 mg/l BOD 3,000 mg/l TSS	5,600

BOD: biochemical oxygen demand; TSS: total suspended solids; FOG: fats, oils, greases; TKN: total Kjeldahl nitrogen.

thing that handles foods must be clean and safe. Table 8.1 provides a glimpse of the amount and characteristics of food and agricultural wastewater generated in the state of Georgia, U.S. Imagine what it is like for the food and agricultural wastewaters generated in the whole nation!

There is, however, a forward-looking way of viewing wastewater as commodity whose value in our society has yet to be determined. With this perspective, food and agricultural wastewater is nothing but the by-product of food and agricultural processing and should be carefully explored for its possible value-added recovery and recycle.

The food industry as a whole is no stranger to this notion of recovering values from “wastes”—it has been a pioneer in using food wastes for animal foods and other nonfeed uses such as pectin recovery from apple pomace and edible oil from grape seeds (now nutraceuticals from the same “waste”). Many sources of food and agricultural wastewater contain substantial amounts of proteins, lipids, and polysaccharides, and flavoring compounds. Their recovery will undoubtedly reduce the organic loadings of wastewater treatment plants but also could offer financial returns that can be used to offset the cost of wastewater treatment and management. However, it must be emphasized that waste utilization in food and agricultural processing operations can be feasible only if the additional cost of processing and recovering products from wastewaters is lower than the alternative, i.e., an in situ wastewater treatment facility or paying service fees for discharging into a municipal sewage system. It is also important to remember that the utilization of solid wastes in food and agricultural wastewaters depends largely on whether the usable fraction of the wastes can be economically separated from the wastewater streams of processing plants.

There are just as many ways of recovering valuable materials as the food materials in the waste. Recovered food materials from wastewater pretreatment can be used as animal feed or used for fermentation to produce ethanol and even hydrogen gas that is microbially produced with glucose and sucrose in the absence of oxygen. Anaerobic digestion of scum, food debris, and primary and secondary sludges can produce biogas (methane as main useful component) as fuel. Table 8.2 is a tabulated list of the potential beneficial uses of food processing wastewaters in various sectors of the food processing industry.

Even sludges from wastewater treatment plants can be utilized beyond traditional agricultural applications; new applications of sludge products as heating fuels, ingredients for cement production, and other innovative products present a real prospect of zero-discharge bioresource utilization.

### **Recoverable Carbohydrates, Fats, and Proteins for Human and Animal Consumption**

Currently, whey proteins are recovered from liquid whey for both human consumption and animal feed in limited quantities in the dairy industry. Whey proteins have found uses in infant formulae, in health foods, and in

**Table 8.2.** Potential products from wastewaters generated from different food-processing sectors of the food industry.

Sector	Waste Residuals in Water	Potential Applications
Meat, poultry, and fishery	Offal, blood, soluble proteins, DAF sludge	Animal feed, protein isolates, hormones, enzymes, savory compounds, vitamins, glue, gelatin, fish oils, and biodiesel
Bakery and grain processing	Spent brewer's yeast, starch, and waste grains	Animal feed, lactic acid fermentation ingredients, fermentation feedstock, paper, and ethanol
Fruits and vegetables	Trimblings, fruit pomace, and flavors	Feed ingredients in lactic acid fermentation, animal feed, flavors, and biofuels
Nut and oilseed	Oil, hulls, meal	Fermentation feedstock, biofuels, and plastic filler (nutshell)
Dairy	Whey, lactose	Food ingredient, animal feed, fermentation feedstock for specialty chemicals, and biofuel
Beverage (nonalcohol)	Beverage spills, sugars	Fermentation feedstock for specialty chemicals
Beverage (alcohol)	Beverage spills, wine grape residuals, brewery grain residuals	Biofuels and specialty chemicals (e.g., tartrate)

bakery goods. However, some cheese manufacturing plants in which whey is produced as a by-product of cheese making (80% of liquid milk ends up as whey) still don't have the technology (ultrafiltration) to process it. Only 70% of the total available whey is sold as a value-added commodity. In addition to unfamiliarity with the technology and the cost associated with the implementation of the technology to recover whey proteins, the supply and demand issue also plays a role in this imbalance. This imbalance problem can be solved only through discovery of new uses of whey proteins. The potential applications of recovered whey proteins (either as a whole

or as individual components) as edible oxygen-barrier coatings on foods and grease barrier coating on paper used for the food service industry or gross coating of confectionery (being developed by the University of California at Davis) and pharmaceutical intermediate specialty chemicals in the future look promising.

Wastewaters generated in seafood and fish processing plants are enormous but contain no toxic substances and thus are readily available for recovery of food materials, some of which are soluble proteins. However, recovery of food materials from seafood and fish processing facilities are usually limited to large-scale operations because wastes from small processors do not have enough recoverable materials to justify the cost of operating even a small batch recovery unit. But where the recovery operation is applicable it is an excellent way to reduce BOD<sub>5</sub> in wastewater and produce additional products to offset wastewater treatment. It is feasible to recover soluble proteins with a properly selected membrane separation process and then process the proteins into flour after fish oil is removed while screens and flotation devices can recover fish debris and greases from wastewater streams for used in animal feeds. As described in Chapter 3, membrane-based technologies have great potential to concentrate, to fractionate, and to purify organic and inorganic materials in aqueous solutions or suspensions, or they can be used as intermediate separation steps to facilitate efficient and economical recovery of value-added materials. In early days, membrane separations had been used primarily to recycle the wash water in seafood and fish processing operations (Pavia and Tyagi, 1972); the aim of the processing of wastewater from fish processing was not material recovery. Steadily, attentions have been paid to the economical effect of protein or enzyme recovery from fish processing wastewaters (Pedersen et al., 1987, 1989; Alfonso and Bérquez, 2002).

In potato chip manufacturing facilities, a large amount of water is used for washing, peeling, slicing, blanching, and frying, and consequently, the wastewater generated in the plants contains a high content of starch (from washing, peeling, slicing, and blanching) and oil (from frying). Thus recovery of these materials can produce benefits of low BOD<sub>5</sub> wastewater suitable for directly discharging into a municipal sewage system and useful materials sold for profits. Catarino et al. (2006) developed an integrated system to recover starch from wastewaters collected before frying using a series of hydrocyclones and a vacuum filter unit, whereas grease and oil were removed from a gravity settling tank.



### **Recoverable Aroma Flavoring Compounds from Food Processing Wastewaters**

Recovery of flavors and savory compounds from food wastewaters has long been contemplated; however, it was not economically and technically possible (with few exceptions) until the advent of membrane-based technologies. Today, pervaporation technology has been used successfully for recovering flavor products from fermentation broth in bioreactors and for aroma recovery (Trifunovic and Trägårdh, 2002; Peng and Liu, 2003). Wastewaters from fruit and vegetable processing operations, in particular, are good candidates for flavor recovery. For example, blanching waters from vegetable processing contain aroma compounds that could be harvested for used in a number of food and nonfood applications. Blanching is the process of heating vegetables to a temperature high enough to destroy enzymes (and possibly some microorganisms) present in the tissue. It stops the enzyme action that causes loss of color and flavor during storage. In water blanching, the vegetables are submerged in boiling water. In steam blanching, the vegetables are suspended above the boiling water and heated only by the steam. Water blanching usually results in a greater loss of nutrients through leaching, but it takes less time than steam blanching. The blanched foods are usually submerged in cooling water immediately after blanching. The combined wastewater from blanching and cooling contains a certain amount of soluble solids, coarse debris, fine particles, and small molecules such as odorous (aroma) compounds. Aroma compounds in blanching water are varied depending on the vegetable being blanched. For example, more than 33 aroma compounds have been found in cooked cauliflower, cabbage, Brussels sprouts, and runner beans (MacLeod and MacLeod, 1970). Some of the aroma compounds that could be present in the blanching water of several common vegetables are listed in Table 8.3. The flavors listed in Table 8.3 are either characteristic in cooked (blanched) vegetables or relatively abundant in terms of approximate percentage relative abundance. These compounds can all be recovered with pervaporation technology; however, separation or fractionation of these molecules is difficult at present.

### **Recoverable Food/Agricultural By-Products for Nonfood Uses**

As shown in Table 8.2, specialty chemicals such as tartrate can be produced from wine grape wastes; glue and gelatin can be extracted from

**Table 8.3.** Abundant volatile flavor compounds in commonly blanched vegetables.\*

Broccoli	Brussels Sprouts	Cauliflower	Beans
5-(methylthio) pentanenitrile	2-propenyl isothiocyanate	Dimethyl sulfide	1-Octen-3-ol
4-(methylthio)butyl isothiocyanate	Dimethyl sulfide	Dimethyl disulfide	(Z)-5-octen-2-one
Dimethyl sulfide	Dimethyl disulfide	(S)-methylthio-butylate	(Z)-3-hexenol
Dimethyl disulfide	(Z)-3-pentenol	Acetone	n-Hexanol
Nonanal	acetaldehyde	Acetaldehyde	Acetaldehyde
(E,E)-2,4-heptadienal	Diethyl ketone	Allyl cyanide	Dimethyl disulfide
(Z)-3-hexenol	Acetone	Trans-but-2- een-1-ol	Ethyl alcohol
Allyl cyanide	Allyl cyanide	Allyl isothio- cyanate	Diethyl ketone

\*Data from MacLeod and MacLeod (1970), Maruyama (1970), Buttery et al. (1976), and Whitfield and Last (1991).

wastes from meat and poultry processing operations. Hormones and vitamins may also be produced from meat, poultry, and fishery processing. Using wastewaters from food processing as substrates for various bioproductions of potential economic interest has been reported (Murado et al., 1993; Roukas, 1999; Guerra and Pastrana, 2003). For example, wastes from mussel processing have been used to produce single-cell protein and a highly stable amylolytic preparation from different *Aspergillus* strains (Murado et al., 1993). Recently, Hernández et al. (2006) have produced amylase and protease by *Aspergillus niger* strain UO-1 using the wastewaters from brewery and meat processing. Amylase is widely used in the food industry, fermentation in general, and in the textile and paper industries; protease can be used in cheese production, meat tenderizer, baking, textiles, and leather tanning, as well as an additive to detergents.

In addition to ethanol or methane, which can be used either as fuel or chemical, there are many examples of specialty chemical products that result from fermentation of carbohydrates by different species of microorganisms (Leeper et al., 1991). Lactic acid, succinic acid, aliphatic acids, sor-

bitol, stearic acid, and linoleic acid are just a few of many possible chemical products from fermentation of sugars (glucose and sucrose), and lactose.

### **Energy or Fuel Generation from Wastewaters**

Ethanol is now being used in gasoline blends and fuel for specifically designed automobile engines. Ethanol can be produced from food and agricultural wastewaters as long as there are sufficient amounts of sugar or starch. The fermentation-produced ethanol has relatively low ethanol content, which has to be enriched to 95% or higher for use as fuels for internal combustion engines. A combination of distillation and pervaporation will produce an almost 100% pure ethanol (Peng et al., 2003).

Biogas from anaerobic processes such as anaerobic sludge digesters or anaerobic reactors for reducing high-strength wastewaters has been well known and utilized to a certain degree on a small scale. But the enthusiasm for its energy generation capacity never lasts very long as people soon realize the costs associated with enriching methane gas from biogas, collection of this gas, and transportation of this gas in such small quantity. Landfills produce biogas naturally under anaerobic conditions and this gas had, for a long time, generated little interest until recently. The reasons for the attention to biogas from landfills have shared little common ground with one another. People concerned with global warming feel more depressed because methane, which is a worse greenhouse gas than CO<sub>2</sub>, and CO<sub>2</sub>, comprises the majority of biogas from landfill, whereas entrepreneurs see the same biogas as “diamond in the rough,” a part of new “green revolution” that will usher in a green economy.

Biogas is not the only combustible gas produced from food and agricultural wastewaters. Research on producing hydrogen gas through fermentation of sugars in wastewaters has shown promising results (Ueno et al., 1996; Van Ginkel et al., 2005; Hussy et al., 2005). Although hydrogen production from fermentation of wastewaters reduces no significant amount of solid content, another approach, which combines hydrogen gas production and electricity generation in a single system, is gaining new attention and interests because of its waste reduction as well as energy generation (Logan, 2004; Oh and Logan, 2005). The amount of electricity generated in the microbial cell was small, but the potential of application of this technology looks bright.

Pyrolysis, particularly fast pyrolysis, offers the opportunity to obtain

heating oil from solid or semisolid biomass from food and agricultural wastewaters. Pyrolysis is a thermal decomposition of organic compounds in the absence of oxygen. This process has been used for hundreds of years to produce charcoal and has been applied commercially to recover methanol, acetic acid, and turpentine. The process of fast pyrolysis produces a liquid, whose yield depends on the biomass composition and rate and duration of heating, and a char. Although the liquid (which contains up to 15–20% water) looks like oil and is called *bio-oil*, the elemental composition of bio-oil resembles that of the biomass rather than that of typical petroleum oils with highly oxygenated compounds providing lower heat values. Because of several organic acids in the pyrolysis liquid, the liquid is very corrosive. The char can be used as adsorbent; the components in the liquid can theoretically be separated in order to achieve their full potentials as specialty chemicals. However, the problem of chemical or physical separations is formidable in both technical and economical senses.

If the biomass is sludge, the pulverized sludge is heated to 250°C and compressed to 40 MPa. The hydrogen in the water inserts itself between chemical bonds in natural polymers such as fats, proteins, and cellulose. The oxygen of the water combines with carbon, hydrogen, and metals. The result is oil; light combustible gases such as methane, propane, and butane; water with soluble salts; carbon dioxide; and a small residue of inert insoluble material that resembles powdered rock and char. This process is called *thermal depolymerization* and uses hydrous pyrolysis to convert reduced complex organics to oil.

All organisms and many organic toxins are destroyed. Inorganic salts such as nitrates and phosphates remain in the water after treatment at sufficiently high levels that further treatment is required. The energy from decompressing the material is recovered, and the process of heat and pressure is usually powered from the light combustible gases. The oil is usually treated further to make a refined useful light grade of oil, such as No. 2 diesel and No. 4 heating oil.

### **Potential Applications of Industrial Commodities Derived from Sludge Treatment**

Treated sludges are used beneficially in land application for agriculture as fertilizers or soil conditioners. These practices have been going on for cen-

turies. Other unconventional uses of sludge products have also been vigorously explored around the world. This phenomenon is more prominent outside the United States of America where land available for sludge disposal is limited, and ocean disposal of sludges are banned in European Union nations. Many proposals of potential uses of sludge products have been put forth, and some of them have been tried in laboratory or in commercial-scale operations. For example, dewatered treated sludges have been used successfully for manufacturing building materials, such as concrete and bituminous mixes, and also as a road subsoil additive utilizing chemical fixation processes (Aziz and Koe, 1990). The chemical fixation process involves combining treated sludge with stabilizing agents, such as cement, sodium silicate, pozzolan (fine-grained silicate), or lime, to chemically react with or encapsulate sludge particles (Metcalf and Eddy, Inc., 1991). The process produces a product with high pH that inhibits viruses and bacteria, and for many chemical treatment products, the product has the consistency of natural clay. Final residuals of incineration or other thermal processes have also been used to generate road subbase material or concrete aggregate (Takeda et al., 1989). Since the main ingredients for Portland cement powder are limestone, clay, silica, iron, etc., and incinerated sludge ash usually contains the same ingredients as clay, it has been successfully used as a part of the cement materials. Pulverized sludge ash, limestone, and dewatered sludge/clay slurries have been used successfully in lightweight concrete applications without influencing the product's bulk properties (Tay and Show, 1991, 1993). Sludge-based concrete has been deemed suitable for load-bearing walls, pavements, and sewers (Lisk, 1989). The cement industry is highly energy-intensive; however, the large energy costs of creating *clinker* (powdered cement produced by heating a properly proportioned mixture of finely ground raw materials in a kiln) at 1500°C can be offset by utilizing sludge as a low-cost and readily available supplemental energy source, depending on the percentage of volatile solids in the sludge. Furthermore, sludge can be injected into the exhaust gas chamber to eliminate NO<sub>x</sub> emissions using heat of the hot exhaust gases reacted with ammonia contained in the sludge to convert NO<sub>x</sub> to nitrogen gas (Kahn and Hill 1998).

Solidification of hazardous materials and heavy metals has long been an effective method to prevent harmful materials from leaching into the environment when these materials are disposed. This process can also be used for production of sludge-based products. However, the sludge from a food processing plant is unlikely to have these metals or other inorgan-

ics that are necessary to produce these products. Because some streams of food and agricultural wastewater have been discharged into a municipal sewage system (maybe after some forms of treatment to reduce BOD<sub>5</sub> and TSS), the description below has certain relevancy. It is possible to incorporate sludge enriched with heavy metal into the manufacture of bio-bricks. In this approach, incinerator sludge ash is used as a clay substitute during the manufacture of these bricks. The process is said to improve the ceramic properties and product strength of the resulting construction materials (Anderson et al., 1996). It is reassuring to know that these biobricks do not release heavy metals during firing in the production or weathering in use (Alleman et al., 1990). Additional benefits of the biobrick technologies include volume reduction and substantial savings on water and fuel consumption as well as treatment costs. In Tokyo, Japan, a product called Metro-Brick made of 100% incinerated ash through mechanical compression under high temperature (1,050°C) has been used as pavement materials for sidewalks, community roads, public open spaces, and parks. Attempts have also been made to use sludge as an “activated carbon” for odorous gas treatment via adsorption and for flue gas treatment via desulfurization (Krogmann et al., 1997). Palasantzas and Wise (1994) investigated the possibility of producing calcium magnesium acetate using residual biomass from sewage sludge. It is reported that this technique would generate an overall cost savings of 68% over conventional disposal costs.

A technology called *sludge-to-fuel (STF)* utilizes the volatile solids in many biosolids for producing combustible oil. STF involves a process that converts sludge organic matter into combustible oil using a solvent under atmospheric pressure with temperatures ranging from 200–300°C (Millot et al., 1989). Alternatively, STF using hydrous pyrolysis can produce combustible oil under high pressures in the range of 10 MPa and high temperatures (Itoh et al., 1994). One STF system employs a hydrothermal reactor to convert mechanically dewatered sludge to oil, char, CO<sub>2</sub>, and wastewater. The char, making up 10% of the product, is sent to a landfill, the wastewater returns to the wastewater treatment system, and the gaseous emissions are treated and released to the atmosphere. The produced oil has approximately 90% of the heating value of diesel fuel and can be sold to off-site users or refineries (Hun, 1998). This is an example of thermal depolymerization to transform reduced complex organics to oil.

Other STF processes produce oils from sludge by employing activated alumina pyrolysis of digested, dried sludges, or toluene-extracted sludge

lipids (Abu-Orf and Jarnrah, 1995). In either case of the sludge sources, sludge-associated metals seem to bind to the residuals, with final product conversion efficiency being dependent on the sludge particulate size, temperature, and heating rate (Takeda et al., 1989). Metals in sludges tend to be trapped in the residual of STF process and, thankfully, organochlorine compounds that survive treatment within a typical sewage treatment plant are likely destroyed in the STF processes (Bridle et al., 1990). Oils produced with the STF technology have the potential to be used as heating oil and possible chemical feedstocks (Boocock et al., 1992). Much lipid-rich sludge from mechanical food wastewater treatment plants appear to be a good candidate for the STF technology.

### Further Reading

- Metcalf and Eddy, Inc. 1991. *Wastewater Engineering: Treatment, Disposal, and Reuse*. 3rd edition, Tchobanoglous, G. and Burton, F.L., eds. New York: McGraw-Hill, Inc.
- Brown, R.C. 2003. *Biorenewable Resources: Engineering New Products from Agriculture*. Ames, IA: Blackwell Publishing Professional.

### References

- Abu-Orf, M.M. and Jarnrah, A.I. 1995. "Biosolids and sludge management." *Water Environment Research* 67: 481–487.
- Alfonso, M.D. and Bérquez, R. 2002. "Review of the treatment of seafood processing wastewaters and recovery of proteins therein by membrane separation processes—Prospects of the ultrafiltration of wastewaters from the fish meal industry." *Desalination* 142: 29–45.
- Alleman, J.E., Bryan, E.H., Stumm, T.A., Marlow, W.W., and Hocevar, R.C. 1990. "Sludge-amended brick production: Applicability for metal-laden residues." *Water Science and Technology* 22: 309–317.
- Anderson, M., Skerratt, R.G., Thomas, J.P., and Clay, S.D. 1996. "Case study involving fluidised bed incinerator sludge ash as a partial clay substitute in brick manufacture." *Water Science and Technology* 34: 507–515.
- Aziz, M.A. and Koe, L.C.C. 1990. "Potential utilization of sewage sludge." *Water Science and Technology* 22: 277–285.
- Boocock, D.G.B., Konar, S.K., MacKay, A., Cheung, P.T.C., and Liu, J. 1992. "Fuels and chemicals from sewage sludge. 2. The production of alkanes and alkenes by the pyrolysis of triglycerides over activated alumina." *Fuel* 71: 1291–1297.
- Bridle, T.R., Hammerton, I., and Hertle, C.K. 1990. "Control of heavy metals and organochlorines using the oil from sludge process." *Water Science and Technology* 22: 249–258.

- Buttery, R.G., Gaudagni, D.G., Ling, L.C., Seifert, R.M., and Lipton, W. 1976. "Additional volatile components of cabbage, broccoli, and cauliflower." *Journal of Agricultural and Food Chemistry* 24: 829–832.
- Catarino, J., Mendonça, E., Picado, A., Anselmo, A., da Costa, J.N., and Partidário, P. 2006. "Getting value from wastewater: By-products recovery in a potato chips industry." *Journal of Cleaner Production*. In press.
- Guerra, N.P. and Pastrana, L. 2003. "Enhancement of nisin production by *Lactococcus lactis* in periodically re-alkalized cultures." *Biotechnology and Applied Biochemistry* 38: 157–167.
- Hernández, M.S., Rodríguez, M.R., Guerra, N.P., and Rosés, R.P. 2006. "Amylase production by *Aspergillus niger* in submerged cultivation on two wastes from food industries." *Journal of Food Engineering* 73: 93–100.
- Hun, T. 1998. "Compact solids-to-oil process cuts costs." *Water Environment and Technology* 10: 22–24.
- Hussy, I., Hawkes, F.R., Dinsdale, R., Hawkes, D.L. 2005. "Continuous fermentative hydrogen production from sucrose and sugarbeet." *International Journal of Hydrogen Energy* 30: 471–483.
- Itoh, S., Suzuki, A., Nakamura, T., and Yokoyama, S. 1994. "Production of heavy oil from sewage sludge by direct thermochemical liquefaction." *Desalination* 98: 127–133.
- Kahn, R. and Hill, P. 1998. "An uncommon use: County sanitation districts of Los Angeles county send biosolids to a cement plant to reduce manufacturing emissions." *Water Environment and Technology* 10: 44–49.
- Krogmann, U., Boyles, L.S., Martel, C.J., and McComas, K.A. 1997. "Biosolids and sludge management." *Water Environmental Research* 69: 534–550.
- Leeper, S.A., Ward, T.E., and Andrews, G.E. 1991. *Production of Organic Chemicals via Biocconversion: A Review of the Potential*. Idaho Falls, ID: Report EGG-BG-9033, Idaho National Engineering Laboratory.
- Lisk, D.J. 1989. "Compressive strength of cement containing ash from municipal refuse or sewage sludge incinerators." *Bulletin of Environmental Contamination and Toxicology* 42: 540–543.
- Logan, B.E. 2004. "Biologically extracting energy from wastewater: Biohydrogen production and microbial fuel cells." *Environmental Science and Technology* 39: 5488–5493.
- MacLeod, A.J. and MacLeod, G. 1970. "Flavor volatile of some cooked vegetables." *Journal of Food Science* 35: 734–738.
- Magbunua, B. 2000. *An Assessment of the Recovery and Potential of Residuals and By-Products from the Food Processing and Institutional Food Sectors in Georgia*. Athens, GA: University of Georgia Engineering Outreach Services.
- Maruyama, F.T. 1970. "Identification of dimethyl trisulfide as a major component of cooked brassicaceous vegetables." *Journal of Food Science* 35: 540–543.
- Metcalf and Eddy, Inc. 1991. *Wastewater Engineering: Treatment, Disposal, and Reuse*, 3rd edition. Tchobanoglous, G. and Burton, F.L., eds. New York: McGraw-Hill, Inc.
- Millot, N., Huyard, A., Faup, G.M., and Michel, J.P. 1989. "Sludge liquefaction by conversion to fuels." *Water Science and Technology* 21: 917–923.
- Murado, M.A., Siso, M.I.G., González, M.P., Montemayor, M.I., Pastrana, L., and Miron, J. 1993. "Characterization of microbial biomasses and amylolytic preparations obtained from mussel-processing waste treatment." *Bioresource Technology* 43: 117–125.



- Oh, S. and Logan, B.E. 2005. "Hydrogen and electricity production from a food processing wastewater using fermentation and microbial fuel cell technologies." *Water Research* 39: 4673–4682.
- Palasantzas, I.A. and Wise, D.L. 1994. "Preliminary economic analysis for production of calcium magnesium acetate from organic residues." *Resource Conservation and Recycling* 11: 225–231.
- Pavia, E.H. and Tyagi, A.D. 1972. *Safe Economical Rescue of Transport Water in the Fish Meal and Oil Industry*. New York: ASME.
- Pedersen, L.D., Rose, W.W., Brewbaker, D.L., and Merlo, C.A. 1987. *Hyperfiltration Technology for Recovery and Utilization of Protein Materials in Surimi Process Waters, Final Report Phase I*. Dublin, CA: National Food Processors Association.
- Pedersen, L.D., Rose, W.W., Deniston, M.F., and Merlo, C.A. 1989. *Hyperfiltration Technology for Recovery and Utilization of Protein Materials in Surimi Process Waters, Final Report Phase II*. Dublin, CA: National Food Processors Association.
- Peng, M. and Liu, S.X. 2003. "Recovery of aroma compound from dilute model blueberry solution by pervaporation," *Journal of Food Science* 68(9): 2706–2710.
- Peng, M., Vane, L.M., and Liu, S.X. 2003. "Recent advances in voc removal from water by pervaporation." *Journal of Hazardous Materials* B98: 69–90.
- Roukas, T. 1999. "Pullulan production from brewery wastes by *Aureobasidium polluans*." *World Journal and Biotechnology* 106: 23–32.
- Takeda, N., Hiraoka, M., Sakai, S., Kitai, K., and Tsunemi, T. 1989. "Sewage sludge melting process by coke-bed furnace system development and application." *Water Science and Technology* 21: 925–935.
- Tay, J.H. and Show, K.S. 1991. "Properties of cement made from sludge." *Journal of Environmental Engineering* 117: 236–246.
- . 1993. "Manufacture of cement from sewage sludge." *Journal of Materials in Civil Engineering* 5: 19–29.
- Trifunovic, O. and Trägårdh, G. 2002. "Transport of diluted volatile organic compounds through pervaporation membranes." *Desalination* 149: 1–2.
- Ueno, Y., Sato, S., and Morimoto, M. 1996. "Hydrogen production from industrial wastewater by anaerobic microflora in chemostate culture." *Journal of Fermentation and Bioengineering* 82: 194–197.
- Van Ginkel, S.W., Oh, S., and Logan, B.E. 2005. "Biohydrogen gas production from food processing and domestic wastewaters." *International Journal of Hydrogen Energy* 30: 1535–1542.
- Whitfield, F.B. and Last, J.H. 1991. Vegetables. In *Volatile Compounds in Foods and Beverages*, Maarse, H., ed. New York: Marcel Dekker, pp. 203–281.

9

ECONOMICS OF FOOD AND  
AGRICULTURAL WASTEWATER  
TREATMENT AND UTILIZATION

---

**Introduction**

In designing an on-site wastewater treatment plant, the primary criterion for selection of one design over another is protection of the public health and health of the workers while preventing environmental degradation. Secondary criteria are cost and ease of operating and maintaining the system. The fate of any residuals resulting from the treatment and disposal system must be considered in the selection process. There are a variety of wastewater treatment options available for a specific wastewater problem; it is rather difficult to make a decision on the selection of the design option that prevents public health hazards and maintains environmental quality at the least cost.

The first step in the design of an on-site system is the selection of the most appropriate components to make up the system. Because the site characteristics constrain the method of disposal more than other components, the disposal component must be selected first. Selection of wastewater modification and treatment components follow. To select the disposal method properly, a detailed site evaluation is required. However, the site characteristics that must be evaluated may vary with the disposal method. Because it is neither economical nor practical to evaluate a site for every conceivable system design, the purpose of this first step is to eliminate the disposal options with the least potential so that the detailed site evaluation can concentrate on the most promising options. To effectively screen the disposal options, the wastewater stream to be treated and disposed of must be characterized as detailed as possible, and an initial site investigation made.

The estimated daily wastewater volume and any short- or long-term

variations in flow affect the size of many of the system components. In addition, the concentrations of various constituents can affect the treatment and disposal options chosen.

Once a process designer or engineer has completed a survey of characteristics of the wastewater and an on-site evaluation of perspective treatment facilities, he or she needs to choose a set of wastewater treatment processes that are able to achieve the objective of the design at a cost that is acceptable. Among all factors that are relevant to the selection of the treatment processes, economical consideration is the most important factor in deciding which process(es) to be included in the final selection.

In order to estimate the costs of the processes in consideration, the data from the wastewater characterization should be available along with the design parameters for the processes and the empirical cost correlations for these processes. The costs related to alternative processes and information on the quality of effluent should also be collected prior to the development of cost estimation in compliance with the regulations regarding wastewater discharge.

### **Estimating the Unit Cost of Treating Food and Agricultural Wastewater**

Cost estimation of a yet-to-be-built wastewater treatment facility is difficult; as an engineer or process designer, your responsibility is not to try to outsmart the experts that are hired to do cost forecasting if a decision of building a specific design of wastewater treatment facility is finalized; rather, your job is to estimate the total costs of a particular wastewater project in order to compare the one under the study to other treatment/management alternatives or options. The estimation of costs in this exercise could be as much as 30% off the actual costs, which is not unusual. The total costs of building and operating a wastewater treatment facility consist of capital costs and operating costs.

#### ***Capital costs***

These include the unit construction costs, the land costs, the cost of the treatment units, and the cost of engineering, administration, and contingencies. The location should be carefully evaluated in each case because it affects the capital costs more than the operating costs. The cost of equip-

**Table 9.1.** Construction costs for selected unit operations of wastewater treatment adapted from USEPA (1983).

Liquid Stream	Correlation
Preliminary treatment	$C = 5.79 \times 10^4 \times Q^{1.17}$
Flow equalization	$C = 1.09 \times 10^5 \times Q^{0.49}$
Primary sedimentation	$C = 1.09 \times 10^5 \times Q^{1.04}$
Activated sludge	$C = 2.27 \times 10^5 \times Q^{0.17}$
Rotating Biological Contactor (RBC)	$C = 3.19 \times 10^5 \times Q^{0.92}$
Chemical addition	$C = 2.36 \times 10^4 \times Q^{1.68}$
Stabilization pond	$C = 9.05 \times 10^5 \times Q^{1.27}$
Aerated lagoon	$C = 3.35 \times 10^5 \times Q^{1.13}$
Chlorination	$C = 5.27 \times 10^4 \times Q^{0.97}$
<b>Solids Stream</b>	<b>Correlation</b>
Sludge handling	$C = 4.26 \times 10^4 \times Q^{1.36}$
Aerobic digestion	$C = 1.47 \times 10^5 \times Q^{1.14}$
Anaerobic digestion	$C = 1.12 \times 10^5 \times Q^{1.12}$
Incineration	$C = 8.77 \times 10^4 \times Q^{1.33}$

Q = the flow rate of the raw wastewater stream (unit = million gallons per day).

ment may also be a significant portion of the capital costs in more automated and elaborate installations. USEPA (1983) compiled a list of construction costs for most common unitary processes of wastewater treatment. Some of the cost correlations are shown in Table 9.1. These unitary cost estimates are developed for municipal wastewater treatment and may not be totally suitable for food and agricultural wastewater treatment plants or small-scale wastewater treatment plants; however, they are quite useful for preliminary estimation and process comparison among different alternatives.

Wright and Woods (1993) compiled capital costs for several processes of physical treatment where capital cost correlations are given for oil-water separators, equalization basins, primary clarifiers, secondary clarifiers, reverse osmosis and ultrafiltration units, gravity filters, and micro-screens. Data are included for raw sewage, intermediate and recirculation pumping stations preliminary treatment (including bar screens, grit removal, overflow and bypass chamber, and Parshall flume), and for grit removal, comminution, and gas stripping. They have also compiled capital cost estimations for several biological wastewater treatment processes

where capital cost correlations are given for aeration basins, mechanical aerators, diffused aeration, conventional activated sludge process, extended aeration, contact stabilization, oxidation ditch, Rotating Biological Contactor (RBC), trickling filter, aerobic lagoons, facultative lagoon, aerated lagoons, and liners (Wright and Woods, 1994). A similar demonstration for capital cost estimations of several chemical processes in wastewater treatment was also provided in a later paper (Wright and Woods, 1995). Other useful sources on estimation of capital costs can be found in the literature (Peters and Timmerhaus, 1980; Ulrich, 1984; Brown, 2003). However, some of these cost estimations are based on process chemical industry and may not be entirely relevant to wastewater treatment plant design and economics.

### ***Operating costs***

Operating costs are annually based costs that are required to operate the constructed facility, including direct costs and indirect costs. If a loan occurs in order to construct the wastewater treatment facility, the operating costs should also include capital charges or financial charges. Direct costs consist of chemicals, supplies and materials, labor, utilities (mainly energy), maintenance, and repairs; indirect costs include overhead, local taxes, and insurance. Chemicals, supplies, and materials are those used in chemical and/or advanced treatment processes depending on the implementation of the treatment processes and the throughput of each process. Labor cost represents wages for personnel for people who operate the facility. The cost can be estimated as two operators per unit per shift (Ulrich, 1984); however, if the operation in the wastewater treatment facility is more or less labor-intensive, the cost needs to change accordingly. Additionally, supervisory labor and clerks should be counted separately as 10–20% of the labor cost. Utilities include electricity, natural gas or heating oil, potable water, and steam. Electricity cost, by far, accounts for the majority of the cost of utilities. Maintenance and repairs typically represent 2–10% of fixed capital depending on the reliability and the complexity of the equipment in each unit. Fixed capital is the investment in the construction of the wastewater treatment facility, which cannot be recovered easily once spent. If a patent is involved in the process, a royalty has to be paid yearly and the cost of royalty should be included as a part of direct costs.

Overhead, local taxes, insurance, and general expenses comprise indi-

rect costs. Overhead cost represents fringe benefits (mainly medical, dental, and life insurance), Social Security and Medicare taxes (U.S. only; other nations may have different but similar social benefit programs), and retirement obligations. Depending on the locality and composition of employees, the cost of overhead could be as high as 70% of costs for labor, supervisory and clerical employees, and maintenance and repairs. Local taxes are difficult to pinpoint and should be decided on case-by-case basis; 1–2% of fixed capital is suggested as a rough, initial estimation. In the United States, insurance costs can account for 0.4–1% of fixed capital. General expenses include administrative expenses and other corporate expenses; they can be estimated as 15% of the labor cost.

A loan of capital may be required to construct a wastewater treatment facility. Depending on the interest rate and the number of the years of the loan, annual capital charges could run as high as 20% of the total capital and may impact significantly on operating costs.

The main factors that influence the costs of operation and maintenance are energy; labor, including the personnel for operation; maintenance and administrative services; material and chemical costs; capital charges; and cost of transportation of sludges for final disposal and discharge of treated wastewater. The relative importance of these cost items vary significantly with the location, the quality of the effluent discharged, and the specific characteristics of the wastewater. A summary of operating costs is provided in Table 9.2.

### ***Estimation of total costs***

Total costs of a wastewater treatment plant are the totals of capital costs and operating costs. In case capital and operating costs are difficult to estimate, a shortcut formula for small wastewater treatment plants can be employed to save the time of estimating total costs. If one knows the capital costs of a similar plant with a different capacity, the capital costs of the plant of interest can be estimated through cost scaling. The idea originates from the chemical industry and recognizes that capital costs are strong related to equipment size. It further follows that capital costs are proportional to  $2/3$  power of the ratio of their capacity. This fundamental idea can be expressed as the following (Equation 9.1) (Ulrich, 1984):

$$C_A = C_B (\text{Capacity of plant A/Capacity of plant B})^n$$

**Table 9.2.** A summary of operating costs in wastewater treatment facilities (adapted from Brown, 2003).

<b>Direct Costs</b>	<b>Estimation</b>
Chemicals, supplies, and materials (CSM)	$CR(\$/kg) \times m(\text{kg/s}) \times 31.5 \times 10^6\text{s/yr} \times f_0 (\text{hr/yr})$ Where $C_R$ is unit cost of CSM; $m$ is feed rate; $f$ is capacity factor
Labor cost	10–15% of fixed capital
Supervisory and clerical labor	10–12% of labor cost
Utilities	Dependent on current energy market
Maintenance and repairs	2–10% of fixed capital
Patent royalty payment	Up to 3% of other direct expenses
Direct subtotal	Sum of all direct expenses
<b>Indirect Costs</b>	
Overhead	50–70% of labor, supervisory/clerical labor, and maintenance and repairs
Local taxes	1–2% of fixed capital—may vary greatly
Insurance	0.4–1.0% of fixed capital
General expenses	15% of labor + 5% of direct expenses
Capital charge	Annual payment of interest and principle on loan: $C_{\text{payment}} = C_{\text{loan}} i (1+i)^n / [(1+i)^n - 1]$ , where $n$ is duration of loan in year
<b>Annual operating costs</b>	Sum of direct costs and indirect costs

where:

$C_A$  = predicted capital costs of plant A

$C_B$  = known capital costs of baseline plant B

$n$  = economy of scale sizing component (<1). For capital cost estimation,  $n = 2/3$ .

Operating costs can also be estimated by an expression similar to Equation 9.1 (Equation 9.2):

$$O_A = O_B (\text{Capacity of plant A/Capacity of plant B})^n$$

where:

$O_A$  = predicted operating costs of plant A

$O_B$  = known operating costs of baseline plant B

$n$  = economy of scale sizing component ( $<1$ ). For operating cost estimation,  $n = 0.85$ .

An alternative procedure for the development of cost models for wastewater treatment systems includes the preparation of kinetic models for the possible treatment alternatives, in terms of area and flow rates at various treatment efficiencies, followed by the computation of mechanical and electrical equipment, as well as the operation and maintenance costs as a function of the flow rates (Uluatam, 1991). The models so developed can be used to select the most appropriate treatment process.

For a more completely user-friendly and computerized cost estimation for wastewater treatment plants, there are several companies marketing commercial software tools for designers and those who contemplate installing or running a wastewater treatment facility on-site. One of these companies is Hydromantis, which just released CapdetWorks<sup>®</sup> version 2.1.

CapdetWorks<sup>®</sup> is a planning-level design and costing tool that allows the user to drag and drop unit processes to build a wastewater treatment plant schematic; automatically calculate a design; and then estimate the cost to build, operate and maintain the facility. At the planning level, current engineering practices primarily use empirical modeling techniques in combination with cost databases. This involves gathering historical capital and operating costs of similar size plants with similar wastewater and treatment characteristics. These techniques often estimate the cost based on only a single wastewater parameter, such as the wastewater flow rate. CapdetWorks<sup>®</sup> is a more comprehensive system since the design is based on all the characteristics of the wastewater being treated.

CapdetWorks<sup>®</sup> 2.1 uses both empirical costing models and design algorithms for individual processes and pieces of equipment. About 60 treatment processes are provided, including physical/chemical, biological, sludge stabilization, handling, and dewatering technologies. From the user's plant layout, the software automatically calculates the required unit process dimensions and equipment. It also allows the engineer to override any of the calculated designs. There is a sophisticated scenario management feature that encourages the user to lay out many treatment alternatives and rapidly calculate and compare costs between them. Capital and operational costs for each process technology can be localized, or users can create their own cost index or apply published industry cost indexes to the default values.



CapdetWorks® version 1.0 is available for most Microsoft Windows operating systems and costs U.S. \$2,450 per license. Free evaluations can be downloaded from the company website at <http://www.hydrumantis.com>.

### **Estimating Overall Costs of Wastewater Treatment Processes with Substance and Energy Recovery**

Overall costs of wastewater treatment processes with substance/energy recovery in a treatment facility are the sum of capital costs and operating costs minus sale price or savings of recovered substances and/or energy. However, forecasting cost savings as a result of recovered substances and/or energy is difficult. Whether a new product or energy from a wastewater treatment facility will be accepted in the marketplace depends on several factors, including additional costs of producing the product, properties of the product, environmental impact, public acceptance, and governmental subsidies. An additional hurdle to forecasting the fate of a recovered product from the food and agricultural wastewater treatment process is that price and/or availability of the competing alternative to the recycled product is also changing constantly; thus, any meaningful long-term forecasting of economical benefits of energy/substance recovery from wastes is contentious. Biofuel is a case in point; if the petroleum oil price in the world market is through the roof or there is a widespread shortage of petroleum products due to catastrophes or wars in oil-producing nations or regions, biofuel will be very competitive in price provided that the energy of producing it is from sources other than petroleum oil or mined natural gas.

### **Further Reading**

- Zall, R.R. 2004. *Managing Food Industry Waste: Common Sense Methods for Food Processors*. Ames, IA: Blackwell Publishing Professional.
- Qasim, S.R. 1998. *Wastewater Treatment Plants: Planning, Design, and Operation*, 2nd edition. Boca Raton, FL: CRC Press.
- Vesilind, P.A. 2003. *Wastewater Treatment Plant Design*. Alexandria, VA: Water Environment Federation & IWA Publishing.

## References

- Brown, R.C., 2003. *Biorenewable Resources: Engineering New Products from Agriculture*. Ames, IA: Blackwell Publishing.
- Peters, M.S. and Timmerhaus, K.D. 1980. *Plant Design and Economics for Chemical Engineers*, 3rd edition. New York: McGraw-Hill, Inc.
- Tsagarakis, K.P., Mara, D.D., and Angelakis, A.N. 2004. "Application of cost criteria for selection of municipal wastewater treatment systems." *Water, Air, and Soil Pollution* 142: 187–210.
- Ulrich, G.D. 1984. *A Guide to Chemical Engineering Process Design and Economics*. New York: John Wiley & Sons.
- Uluatam, S.S. 1991. "Cost models for small wastewater treatment plants." *International Journal of Environmental Studies* 37: 171–181.
- USEPA. 1983. *Construction Costs For Municipal Wastewater Treatment Plants: 1973–1982*. EPA Publication 430983004. Washington D.C.: USEPA.
- Wright, D.G. and Woods, D.R. 1993. "Evaluation of capital cost data. Part 7. Liquid waste disposal with emphasis on physical treatment." *Canadian Journal of Chemical Engineering* 71: 575–590.
- . 1994. "Evaluation of capital cost data. Part 8: Liquid waste disposal with emphasis on biological treatment." *Canadian Journal of Chemical Engineering* 72: 342–351.
- . 1995. "Evaluation of capital cost data. Part 9: Liquid waste disposal with emphasis on chemical treatment." *Canadian Journal of Chemical Engineering* 73: 546–561.

## INDEX

---

- Acinetobacter*, 150
- Activated energy:  
Arrhenius correlation, 118  
temperature dependence of reaction rates, 118
- Advanced oxidation techniques, see  
Chemical oxidation
- Advanced wastewater treatment, 145
- Adsorption:  
adsorbate, 74  
adsorbent, 74  
bed efficiency, 77  
breakthrough curves, 77  
definition, 73  
eluent, 76  
Freundlich, 74, 76  
isotherms, 75  
kinetics, batch reactors, 121-122  
kinetics, flow reactors, 122-125  
Langmuir, 74-75  
linear, 74  
processes, 78  
rates, 74-78  
sorption, 73  
system design,  
temperature,  
unfavorable, 74  
van der Waals forces, 67, 73
- Aerated lagoon, 174
- Aeration:  
diffuse air, 172  
mechanical devices, 172
- Aerobic ponds, 174
- Agricultural crops:  
function of, in overland flow, 192  
management of, 182-184  
selection of, 188, 200
- Air stripping,  
of ammonia, 149  
of VOCs, 146
- Alcaligenes*, 49
- Alcohols, 254
- Algae, 41
- Alkaline chlorination, 80
- Alum:  
flocculant, 67  
for phosphate removal, 156  
sludge with, 154
- Ammonia, 146, 192, 201
- Ammonification, 146
- Anaerobic digesters for sludge  
stabilization, 222-223
- Application methods:  
in hyacinth systems, 208  
in duckweed systems, 208-209  
in land systems, 239-242  
in wetland systems, 198-202
- Application rates:  
for overland flow, 184  
for rapid infiltration, 184  
for slow rate, 184
- Aquatic systems:  
description of, 204-206  
design considerations, 209-211

- Aquatic systems (*continued*)  
 organic removal, 201  
 nitrogen removal, 201  
 phosphorus removal, 201  
 temperature effects, 203
- Aroma recovery, 252
- ATP:  
 structure of, 44  
 synthesis of, 44-45
- Bacteria:  
 aerobic, 115  
 anaerobic, 116  
 facultative, 115  
 in activated sludge, 40  
 in trickling filters or biofilters, 40  
 in stabilization pond systems, 40  
 in sludge treatment, 40  
 in biological phosphorus removal, 40  
 in wetland systems, 198  
 in natural systems, 192, 197
- Bacterial kinetics, 27
- Biofilm, 42
- Biofilters, see Trickling filters
- Biological nutrient removal:  
 biological nitrogen removal, see  
 Nitrification and Denitrification  
 biological phosphate removal,  
 150-153
- Biochemical Oxygen Demand (BOD):  
 definition, 7, 18  
 testing, 18-19
- Biogas, 221, 254
- Biological Oxygen Demand, see  
 Biochemical Oxygen Demand
- Bio-oil, 255
- Biosolids, 221
- Blanching, 252
- Bulking agents, 226
- Bulrush, 200-201
- Carbonaceous compounds, 4
- Carmen-Kozeny equation, 86
- Capital costs, 262-264
- Catalyst, 26
- Cattail, 200-201
- Chemical coagulants, 67
- Chemical oxidation, 79-80
- Chemical Oxygen Demand (COD),  
 18-20
- Chemical potential, 83
- Chemical precipitation, 84
- Chemoorganotrophs, 46
- Chemolithotrophs, 46
- Chick's law, 162
- Chlorination, 161
- Chlorine, 161
- Clarifier, 59, see also Sedimentation  
 tank
- CMAL - Completely Mixed Aerated  
 Lagoon, 125-127
- Coagulation  
 coagulant, 66  
 coagulant aid, 67-68  
 colloid stability, 68  
 destabilization of colloidal  
 dispersion, 66-68  
 jar test, 68-70  
 polyelectrolytes, 67-68  
 sludges, 215, 229-230
- Combined aerobic processes:  
 contact aerobic systems, 138-139  
 anaerobic contact processes,  
 139-144  
 AF, 141-142  
 AFBR, 142-144  
 UASB, 140
- Composting, 225
- Completely Stirred Tank Reactor  
 (CSTR), 30, 43
- Conventional processes, see Primary  
 treatment and Secondary treat-  
 ment
- Corrosion, 255
- Darcy's law, 72
- Denitrification, 48-50

- DESAL process, 109
- Dissolved air flotation (DAF), 57
- Diatomaceous earth, 71
- Digestion, 221
- Dilution rate, 31, 125
- Discrete settling, 60
- Disinfectants:
  - calcium hypochlorite, 161
  - chlorine, 161
  - chlorine dioxide, 161
  - hydrogen peroxide, 162
  - ozone, 162
- Duckweed, 168, 204-205, 210-211
  
- Earthworm, 224
- E. coli*, 39
- Electrode, 89
- Electrodialysis, 88-90
- Enzymatic catalyst, 26
- Enzymes, 116
- Equalization basins, 52-54
- Ethanol, 254
- Eukaryotes, 115
- Eutrophication, 146
  
- Faraday constant, 89
- Faraday's law, 89
- Fats, oils, and grease (FOG), 7
- Ferric and ferrous iron, 80
- Fenton's reagents, 80
- Filtration:
  - applications, 70-73
  - backwashing, 159
  - Kozeny-Carman equation, 86
  - Darcy's law, 72
  - filter coefficient, 72
  - mathematical models, 72
  - mechanisms, 71
  - rates, 72
  - sludge dewatering, 231
  - vacuum, 231
- First order reaction rate equation, 24-25
- Floc, 67-69
  
- Flocculation:
  - collision efficiency, 66
  - definition, 65-66
  - jar test, 68-70
  - transport of colloidal particles, 67
- Flocculent settling, 60
- Flotation, 57-58
- Flow reactors, 24
- Fluidized bed reactors, 238-239
- Flux, 90, 93, 95
- Freundlich isotherm (equation), 76
  
- Gas transfer systems:
  - aspirators, 174-175
  - mechanical, 174-175
- Gravity filters, 71
  
- Heavy metal, 208
- Hydrogen, peroxide:
  - chemical disinfection, 162
  - decomposition, 162
- Hydrophobic attraction, 102
- Hyperfiltration, 87
- Hydrochlorite, 161
  
- Ion exchange:
  - applications, 102, 149
  - exchange capacity, 106
  - reactions, 103-106
  - regenerations, 104
  - resins, 103-105
  - sorption reactions, 103
  - strong acidic, 105
  - strong basic, 106
  - synthetic materials, 104
  - weakly acidic, 105
  - weakly basic, 106
- Ion exchange systems:
  - DESAL process, 109
  - design efficiency, 107-108
  - exchange systems, 107-109
  
- Kinetics of reactions, 24-28, 117-118
- Kozeny-Carman equation, 86

- Lagoon, 169, 206
- Land application:  
 description, 181-186  
 design, 188-190, 192-195, 197  
 overland flow, 184, 190-195  
 rapid infiltration, 184, 195-198  
 slow rate, 184, 186-190
- Langmuir equation, adsorption  
 isotherm, 75
- Lime:  
 coagulation, 67, 154-155  
 sludge conditioning, 230
- Lineweaver-Burk linearization, 28
- Lithotrophs, 46
- Mass loading, 24
- Material balances:  
 conservation of mass, 23  
 enzymatic reactions, 26-28  
 reaction rates, 24-25  
 reactors, 28-31
- Membranes:  
 Clausius-Claperyron relationship, 94  
 concentration polarization, 84, 89,  
 92, 158  
 cross-flow flow, 86, 87  
 dead-end flow, 86  
 design, 94-97  
 electro dialysis, 80, 88-90, 158  
 enrichment factor, 91  
 flux, 82, 86, 90, 93  
 fouling, 101-102, 159  
 hollow fiber, 98  
 ion selective, 89  
 Lévêque's equation, 92  
 mass transfer coefficient, 90-92  
 membrane contactor, 94-95  
 membrane distillation, 93  
 membrane mass transport resistance,  
 91-92  
 microfiltration, 80, 86  
 modules, 97-101  
 nanofiltration, 80, 88  
 nanomembrane technology, 81  
 osmotic distillation, 93  
 osmotic pressure, 83  
 permeability, 83  
 permselective, 83  
 pervaporation, 81, 90-92  
 plate-and-frame, 99  
 processes, 80-81, 83  
 reverse osmosis, 80, 87-88, 157  
 Schmidt number, 85  
 selectivity, 82  
 separation factor, 91  
 Sherwood number, 85  
 solute rejection, 84  
 spiral wound, 97  
 tubular, 100  
 ultrafiltration, 80, 87
- Metazoa, 42
- Methane, 254
- Michaelis kinetic equation, 27
- Michaelis-Menten constant, 27
- Michaelis plot, 28
- Microorganisms classifications,  
 36-42
- Monod kinetics, 47, 121
- Multiple hearth furnaces, 242-246
- Nitrobactor*, 47, 148
- Nitrococcus*, 47
- Nitrosocystis*, 47
- Nitrosogloea*, 47
- Nitrosomonas*, 47, 148
- Nitrospira*, 47
- Nitrate:  
 removal by biological processes,  
 147-148  
 removal by electro dialysis, 149  
 removal by ion exchange, 149  
 removal by physicochemical  
 processes, 149  
 removal by membranes, 156-159
- Nitrification, 46-48, 146
- Odor, 17
- Operating costs, 264-265

- Organic matters:  
removal by adsorption, see Chapter 3  
removal by aeration, see Chapter 6  
removal by bioconversion, see Chapter 2  
removal by coagulation, see Chapter 3  
removal by oxidation, see Chapter 3  
sludges, see Chapters 3, 4, 7
- Organotrophs, 46
- Oxidizing agents, 162
- Ozone:  
chemical oxidation, 80  
decomposition, 162  
disinfection, 162
- Photoorganotrophs, 46
- Photolithotrophs, 46
- Phragmite, 227
- Physicochemical nutrient removal:  
physicochemical nitrogen removal, 149-150  
physicochemical phosphate removal, 153-156
- Plug-flow reactors, 122-123
- Polarization, concentration, see Concentration polarization
- Polyelectrolyte:  
filtration aid, 67-68  
sludge conditioning, 215, 229-230
- Precipitation:  
alum, 156  
iron, 155  
lime, 154  
metal ions, 154  
phosphate, 154-156
- Pressure filters, 71
- Primary treatment, 51, 51-112
- Prokaryotes, 115
- Protista, 36
- Protozoa, 42
- Pseudomonas*, 49
- Putrefaction, 221
- Pyridine nucleotide, 46
- Pyrolysis, 255, also see Thermal depolymerization
- Radicals, 80
- Rapid mix, 68
- Rate constant, 25
- Rates of reaction:  
activation energy, 118  
dissolved oxygen (DO), 119  
enzymatic reactions, 116-117  
ion exchange, see Ion Exchange  
material balance, 121, 124  
pH, 118-119  
reactor design, 121-125  
stoichiometry, 21, 23  
temperature, 117-118  
Van't Hoff equation, 118
- Reaction rates, see Rates of reactions
- Reed beds, 225-226
- Residence time, hydraulic, 203; see also Hydraulic detention time
- Reynolds number, 85
- Rotary drum screen, 56
- Rotating biological contactor (RBC), 131-137
- Runoff, 192
- Sand, filtration, 71
- Screening, 54-56
- Second-order reaction rate, 25
- Secondary treatment, 51, 113-144
- Sedimentation:  
biological solids, 114  
coagulation, 60, 65-70  
compression, 60  
filtration, 70-73  
isoconcentration, 64  
sludges, 114  
sludge thickening, 217-220  
tank holding, 61  
terminal velocity, 61-62  
type I, 60  
type II, 60, 62  
type III, 60, 64

- Sedimentation (*continued*)
  - type IV, 60, 65
  - velocity, 60-61
  - zone settling (also hindered settling), 60, 64
- Selectivity, ion exchange, 103
- Selectivity, membranes, 82
- Settling, see Sedimentation
- Settling velocity, 60-61
- Sludges, Biological properties:
  - characteristics, 216-217
  - concentration, 217-220
  - dewatering properties, 216-217
  - fuel values, 242
  - land application, see Chapter 6
  - plasticity, 216
  - settling properties, 216
- Sludge-to-Fuel, 257-258
- Sludge Treatment:
  - aerobic digestion, 222
  - anaerobic digestion, 222-223
  - belt press filtration, 231
  - centrifugation, 232-234
  - chemical conditioning, 230
  - combustion, 243
  - conditioning, 218, 229-230
  - dewatering, 231
  - disposal to land, 239
  - drying, 238-239
  - drying bed, 238
  - filter pressing, 231, 234-236
  - flash drying, 238-239
  - flotation, 218
  - fluidized bed, 239
  - freezing, 236-238
  - gravity thickening, 218-219
  - heat treatment, 230
  - multiple hearth incineration, 242-246
  - rotary dryer, 238, 240
  - sludge management, alternative, 255-258
  - spray dryer, 238, 240
  - thickening, 217-219
- Sodium hypochlorite, 161
- Soluble solids, 17
- Solute rejection, 84
- Sorption, 73
- Stabilization ponds:
  - aerated ponds, 171, 174
  - aerobic ponds, 171, 174
  - anaerobic ponds, 171, 175-176
  - design, 176-181
  - facilitative ponds, 171
  - hydraulic detention time, 179
  - maturation ponds, 171, 173-174
  - model, 181
  - volumetric loading, 179
- Stoichiometry, 21, 23
- Stoke's law, 61
- Surface overflow rate, Sedimentation tank, 61
- Suspended solids, 16
- Temperature, wastewater characteristics, 17
- Terminal settling velocity, 61-62
- Thermal depolymerization, 255
- Total Kjeldahl Nitrogen (TKN), 7
- Total Organic Carbon (TOC), definition, 20
- Total Suspended Solids (TSS), definition, 7
- Trickling filters (Biofilters):
  - description, 128-130
  - design, 130-131
- Underdrain systems, 131
- Universal gas constant
- Vacuum filters, 71
- van der Waals attraction in coagulation, 67, 73
- Vermistabilization, 223-224
- VOC - Volatile Organic Compound, 160
- Volatile fatty acids, 150
- Water hyacinth, 201, 204, 206-208
- Wetland, Natural, 168



- Wetland, Constructed:  
  design, 202-204  
  hydraulic residence time, 203  
  natural, 168  
  rock-reed-filters, 198  
  root-zone systems, 198  
  subsurface flow, 200  
  surface flow, 199  
  vegetated submerged bed systems,  
    198
- Xanthomonas*, 49
- Zeolites, 74
- Zero-order reaction rate, 25
- Zeta potential, 66